


# ***BIRO***<sup>®</sup>

## **MODEL 31 PRO CUT HORIZONTAL SLICER**

### **OPERATING AND SERVICE MANUAL**



---

**THE BIRO MANUFACTURING COMPANY**  
**MARBLEHEAD, OHIO 43440-2099**  
**Power Cutters Since 1921**

# MODEL 31 PRO-CUT HORIZONTAL SLICER

## WARNING TO ALL PURCHASERS, OPERATORS AND OPERATION SUPERVISORS:

### FAILURE TO READ AND ADHERE TO THE FOLLOWING IMPORTANT INSTRUCTIONS COULD RESULT IN BODILY INJURY.

- (1) Do not electric wire this horizontal slicer. Have only a qualified and certified electrician wire this horizontal slicer as required. Be sure machine is grounded. Failure to ground this machine could result in electric shock.
- (2) Do not place machine on sloping floor. Always place machine on flat non-skid floor.
- (3) Do not use this horizontal slicer for non-food products.
- (4) Do not attempt to operate this horizontal slicer until this machine has been inspected and demonstrated by the seller — recognized BIRO Representative.
- (5) Do not attempt to operate this horizontal slicer unless you or the operator has been properly trained. Improper use or operation of this horizontal slicer could result in bodily injury.
- (6) Do not leave horizontal slicer in operation — unattended.
- (7) Do not tamper, bypass, remove fixed guards, safety interlock electrical switches or any other safety device.
- (8) Do not at any time force feed product through this horizontal slicer.
- (9) Do not alter or modify this horizontal slicer in any way from its original form.
- (10) Do not touch any moving parts.
- (11) Always disconnect power supply before removing shrouds, removable guards, covers, doors, fences, panels for servicing, cleaning or any other reason.
- (12) Use only BIRO parts and accessories properly installed. Contact your nearest service agency or The BIRO Manufacturing Company for authorized referral assistance.
- (13) Horizontal slicer operating manuals as supplied with this horizontal slicer are available from BIRO.

### FAILURE TO COMPLY WITH THIS WARNING NOTICE COULD RESULT IN BODILY INJURY.

THE BIRO MANUFACTURING COMPANY, 1114 WEST MAIN STREET, MARBLEHEAD, OHIO  
43440-2099 U.S.A. — Phone (419) 798-4451 — Telex No. 241103 BIRO MBL E UD

## LIMITED WARRANTY

**WARRANTY:** The BIRO Manufacturing Company warrants that Model 31 Pro-Cut Horizontal Slicer will be free from defects in material and workmanship under normal use and with recommended service. BIRO will replace defective parts, which are covered by this limited warranty, provided that the defective parts are authorized for return, shipping charges prepaid, to a designated factory for inspection and/or testing.

**DURATION OF WARRANTY:** The warranty period for all parts covered by this limited warranty is one year from the date of purchase, except as noted below.

**PARTS NOT COVERED BY WARRANTY:** The following are **NOT** covered by this limited warranty: knife blade, item number 30; compress spring, item number 39; slice holder end weight number 43; and claw attachment number 36. This limited warranty does not apply to machines sold as used, rebuilt, modified, or altered from the original construction in which the machine was shipped from the factory. Water contaminated electrical systems are not covered under this limited warranty. BIRO is not responsible for electrical connection of equipment, adjustments to switch gear or any other electrical requirements, which must be performed only by a certified electrician. BIRO is not responsible for service charges or labor required to replace any part covered by this limited warranty or for any damages resulting from misuse, abuse, lack of proper or recommended service.

**EXCLUSION OF WARRANTIES AND LIMITATION OF REMEDIES:** BIRO gives no warranties other than those expressly stated in this limited warranty. THE IMPLIED WARRANTY OF MERCHANTABILITY, THE IMPLIED WARRANTY OF FITNESS FOR PROCESSING OF FOOD PRODUCTS, AND ALL OTHER IMPLIED WARRANTIES ARE SPECIFICALLY EXCLUDED. BIRO IS NOT LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, EXPENSES, OR LOSSES. THE REMEDIES PROVIDED IN THIS BIRO LIMITED WARRANTY ARE PURCHASER'S SOLE AND EXCLUSIVE REMEDIES AGAINST BIRO.


**REGISTRATION CARDS:** You must sign, date and complete the warranty card supplied with each machine. The warranty card must be returned to The Biro Manufacturing Company for proper registration. If no warranty card is returned to BIRO, the warranty period will begin from the date the machine was originally shipped from the factory.

### HOW TO GET SERVICE:

1. Contact the agency from whom you purchased the machine.
2. Consult the yellow pages of the phone directory for the nearest authorized dealer.
3. Or call BIRO Service Department (419) 798-4451 who will put you in contact with the nearest service agency.

## OPERATING INSTRUCTIONS — MODEL 31 PRO-CUT HORIZONTAL SLICER

1. UNCRATING: After uncrating is completed, check for damage. Contact freight carrier and file a freight claim.
2. LEFT RECEIVING TROUGH WING: If the left wing (product receiving trough) is received removed, installation can be made by fastening the hinge of the left wing to the main body of the machine using the (3) hex head bolts supplied with the unit. See diagram below.
3. LEFT WING (RECEIVING TROUGH) SAFETY SWITCH: If the machine is received with the left wing removed, the receiving trough safety switches (Item Nos. S1 and S2) will also be disconnected. The leads from these safety switches will have to be connected directly to the electrical enclosure (Item No. 50) inside the front of the machine. Connect the numbered safety switch leads #1 thru #8 to the corresponding numbered terminals on the side of the safety switch monitor, #A1.



4. FLOOR SET-UP OF MACHINE: The machine must be installed level on the floor, so that no vibrations or distortions develop during cutting operation (shims may have to be placed under legs). Floor lag mounting is optional. Two leg adjusting pads are provided, see Item No. 23.
5. ELECTRICAL CONNECTION OF MACHINE: The machine is wired for a voltage of 220 volt 3-phase and supplied less plug. Plug and socket have to be installed to match electrical wiring of the facility. See connecting diagram. Use No. 12 wire.

With other than 220 volt supplies, the adjustable safety thermal overload relay must be set to the amperage value shown on the name plate of the motor.

It may be necessary to install a thermal overload relay with a higher range. A corresponding transformer to match the line voltage must also be fitted.

6. DIRECTION OF ROTATION — TEST RUN: Observe correct direction of rotation. A test run of the machine must be carried out without cutting material. Knife blade (ITEM No. 30) must rotate clockwise when looking at machine from left side. See diagram above.

REVERSING DIRECTION OF ROTATION — Reverse rotation is achieved by interchanging any two wires in the plug. This work should be carried out only by a certified electrical technician.

7. FEEDING AND CUTTING: The material to be cut has to be placed with its straight side against the front face of the feed chamber and pressed hard against the spikes (ITEM NO. 31) of the transporter (ITEM NO. 31). Claws (ITEM NO. 36) are fitted to the transporter (ITEM NO. 31). The claws (ITEM NO. 36) are pierced into the material to be cut. The supplied slice holder (ITEM NO. 43) must be placed inside the left receiving chamber so that the cut slices rest against each other as the product is being sliced.

When cutting chops, care must be taken so the rib bone rests against the front face of the feed channel. See Diagram.



8. LEAF SPRINGS: Leaf springs (ITEM NO. 51 & ITEM NO. 52) are used to press the product to be cut against the front face of the feed chamber.

When cutting varying sizes of material — i.e., fillet — the springs (ITEM NO. 51 & ITEM NO. 52) should be removed.

REMOVAL OF LEAF SPRINGS (ITEM NO. 51 & ITEM NO. 52): The springs are removed by depressing knobs (1) (ITEM NO. 53) and sliding spring to the right.

9. THE PRODUCT TO BE CUT: Is fed automatically by the transporter (ITEM NO. 31) in conjunction with the worm shaft (ITEM NO. 25). After lifting the right safety cover (ITEM NO. 42) of the feed chamber, the transporter (ITEM NO. 31) can be pushed back to the right by lifting the lever (ITEM NO. 33) and disengaging and moving the transporter (ITEM NO. 31) to the right end of the feed chamber.
10. ADJUSTMENT OF CUTTING THICKNESS: After opening the sliding gate (ITEM NO. 44) on the right hand side (top) of the machine, the thickness of cut can be infinitely varied in thickness on an **overall** scale from  $\frac{1}{16}$  inch to approximately  $1\frac{1}{8}$  inch or from 1.5 mm to 29 mm.

There are two thickness setting scales (ITEM NO. 11-04) which is fastened to the overrunning clutch. The A Scale or inside thickness scale ranges from 1.5 mm ( $\frac{1}{16}$  inch) to 6 mm or approximately  $\frac{1}{4}$  inch. The

outside scale (B Scale) ranges from 7 mm or approximately  $\frac{9}{32}$  inch to 29 mm or approximately  $1\frac{1}{8}$  inches.

It is important to understand how to achieve thickness settings for Scale A and for Scale B.

For thickness ranges from  $\frac{1}{16}$  to  $\frac{1}{4}$  inch on Scale A, loosen hexagon screw (ITEM NO. 18-04) located on the eccentric sleeve (ITEM NO. 18). The hexagon screw is a sliding screw, therefore, move the hexagon screw **inward** toward the center of the eccentric sleeve until the bolt stops. Retighten the hexagon screw (ITEM NO. 18-04).

EXAMPLE 1: To obtain a  $\frac{1}{4}$  " thickness (6 mm) setting on the A Scale, loosen the adjusting wing screw (ITEM NO. 16) and slide the pointer (ITEM NO. 17), attached to the draw lever arm (ITEM NO. 14), to No. 26 or  $\frac{1}{4}$  " setting on the scale and retighten the adjusting wing screw.

EXAMPLE 2: To obtain a 1 " cut or approximately 25 mm on the outside B Scale, the machines overrunning clutch setting must be changed from A Scale to B Scale. Therefore, loosen the hexagon screw (ITEM NO. 18-04) on the eccentric sleeve (ITEM NO. 18) and slide the hexagon screw **OUTWARD** or away from the center of the eccentric sleeve and retighten the hexagon screw (No. 18-04).

Loosen the adjustable wing screw (No. 16) and slide the pointer to No. 25 on the B Scale and retighten the adjusting wing screw (No. 16).

The machine is now ready to cut 1 " thick product.

11. LUBRICATION: The worm shaft (ITEM NO. 25) and slide bar (ITEM NO. 47-07) must be **lubricated daily** with resin free grease, so that the transporter (ITEM NO. 31) can be moved easily. An approved food machine oil is recommended. See oil drop label and holes for oil drops to enter slide bar. Oil entrance holes are located on top cover of machine.
12. SAFETY SYSTEM: The machine can be switched on only after the two protective lids (ITEM NO. 40 and ITEM NO. 41), (on left side and right side), thickness adjusting cover door on the right side, and left blade cover door assembly have been closed.  
The machine will not operate with any one of the four (4) safety covers in the open position.
13. REMOVAL OF CUTTING BLADE: With the left blade cover assembly open and by depressing the motor brake release push switch (ITEM NO. 7) located on the back side "Brake Release", the blade (ITEM NO. 30) can be moved into the most advantageous position for installing or removing the blade (ITEM NO. 30). Note: Always wear safety mesh gloves when removing knife blade.
14. CLEANING OF MACHINE AFTER USAGE: All machine parts can be cleaned with a damp cloth, sponge, brush or power washer. **ALWAYS DISCONNECT MAIN POWER SUPPLY BEFORE DISMANTLING AND/OR CLEANING.**
15. CUTTING BLADE: The steel of the cutting blade (ITEM NO. 30) is 4 mm thick and must be the same for all replacement blades.

The regrinding of the blade (ITEM NO. 30) is done on an exchange basis if so desired.

A clean cut is only achieved with well ground and cleanly honed blades.

Claims which are caused through non-observance of the Operating Instructions, are not covered by guarantee.


## TROUBLE SHOOTING GUIDE FOR MODEL 31K

- I. Machine does not have cutting speed
  - A. Several machines operating on the same electrical line.
  - B. Wire gauge used in field connection may be too small.
  - C. Three phase may be operating on two phase.
  - D. Voltage conditions.
- II. Machine will not operate
  - A. Wired improperly.
  - B. Short in wiring.
  - C. Motor burned out.
  - D. Fuse blown at panel.
  - E. Magnetic safety switch not making positive contact with safety magnet. Recycle right sliding door (ITEM NO. 44). Lift plexiglass lids (No. 40), right plexiglass lid (No. 41) and left wing assembly by opening and reclosing left wing; also, check the lighted safety switch monitor inside the front cover of the electrical panel (ITEM NO. 50). All 4 safety switch monitor lamps must be out in order for the machine to operate. If any lamp is not out, the faulty safety switch must be traced and replaced. Therefore, check magnetic safety switch 31-50-S1, S2, S3, S4 and magnet for safety switch 31-50-1A, 2A, 3A, 4A.
- III. Machine operates short period/time then stops
  - A. Adjust overload relay; perhaps relay is set too low.
  - B. Short in electrical connection.


## MODEL 31 OPERATIONS CHECK LIST

1. Ensure the adjustable slice thickness setting is set at the required measurement and then shut door.

*Slice thickness setting and stop button*



2. Attach blade springs if necessary.
3. Place product into feed chamber and secure one end in clamp of transporter.



*Clamp and clamp release grip.*

4. Move product by means of the clamp release grip to within 1" of the blade cutting slot in the trough.
5. Place plastic meat stop in discharge chamber, as near to the blade as possible in order to allow the sliced product to stack neatly in the chamber.
6. Check stop button is released, both plexiglass doors are closed and other safety doors secured.
7. Press start button.
8. Blade will rotate and clamp will engage onto the single worm conveyor. Product will move toward blade and start to slice.
9. 31 will stop automatically after the product has been sliced. Lift both plexiglass doors, release meat from clamp.
10. Remove sliced product from discharge chamber.


## PRODUCT GUIDELINES

### PORK LOIN BONE-IN/BELLY PORK

#### 1. Pork Loin


- a) Suggest slice thickness setting 18.
- b) Remove chump from loin.
- c) Ensure all trimming of fat and excess bone (tip of spinal vertebrae) is done before slicing.
- d) Insert blade spring to assist in holding product (especially those with bone) giving stability while it is being sliced. Therefore, uniformity of the required cutting thickness will be achieved.

*Blade springs inserted.*



- e) Place product in feed chamber. Note the spinal vertebrae lies flat onto base of chamber and the rib bones stand against the near side wall of feed chamber.

*Pork chops in feed and discharge chambers.*



#### 2. Belly Pork Bone-in

- a) Suggested slice thickness setting 18.
- b) Place in feed chamber rind upwards and secure chump end in clamp.
- c) If boneless end is floppy it is best to cut it off first and then slice the rest in the 31K.

## Beef Boneless

Striploin/Rump/Chuck Steak/Beef Topside/Buttock.

### General Guide

With any of these products ensure that any trimming of fat, gristles or veins is done prior to slicing on the 31K.

#### 1. Striploin

- a) Suggested slice thickness setting 17.
- b) Always ensure that the fat covering is facing upwards in the feed channel.

#### 2. Rump

- a) Suggested slice thickness setting 17.
- b) Cut rump in half. (Sirloin end to hip joint.)
- c) Traditionally cut rump will not fit in channel therefore has to be cut. As with striploin fat covering must be facing upwards.
- d) If product is wedge shaped place thicker end nearest the blade when placing in feed chamber. This is important if product is to be cut fresh 3° to 4°C (37°-39°F).


#### 3. Chuck Steak

- a) Suggested slice thickness 18.
- b) Cut chuck lengthways in order for product to fit chamber.
- c) If product has **no** fat covering and has a clean cut surface place that surface at bottom of feed chamber. If there are thin membranes of gristle on upper surface the cut is far superior.

#### 4. Beef Olives (Topside)

- a) Suggested slice thickness setting 5.
- b) To achieve thin slices ensure that the product is firm. The nearer to 0° to 0.5° (32°-33°F) the material is the better the slice.

*No clamps needed if product is fresh  
or fills feed chamber.*




#### 5. Buttock (Top Rump, Thick Flank)

- a) Suggested slice thickness 16.
- b) Place knuckle end in clamp. This ensures maximum yield.
- c) Ideal for thin slices.

CONNECTING DIAGRAM FOR MD 31 SLICER

Motor: 220 V three-phase current  
 Brake: 220 V three-phase current



Wire Color Code  
 Braun = Brown  
 Grün = Green  
 Weiss = White  
 Gelb = Yellow


- S1 prot. switch-gener.
- M1 gear brake motor
- K3 contactor 10E
- K2 contactor DSL6-53UE
- K1 contactor DSL6-53UE
- F2 overcurrent relay
- F1 control fuse
- A1 central unit for 4 gens
- S10 switch for change
- X2 terminal row
- X1 terminal row
- T1 disc. transf. 220 V/24 V
- S9 SWItch (attention off)
- S8 limiter key conv/off
- S7 key seitch "BRAKE RELEASE"
- S6 appr. sw. blade standstill
- S5 key switch "ON"
- S4 prot. sw.-generator
- S3 prot. sw.-generator
- S2 prot.sw.-generator

Model 31 K


CIRCUIT Diagramm

Motor: 220 V three-phase current

Brake: 220 V three-phase current




**WIRING DIAGRAM**  
**MOTOR: 208/240/440-60-3**  
**CONTROL CIRCUIT 24V AC**  
**BRAKE: 24V DC**



- X1 Terminal Row
- X2 Terminal Row
- A1 Safety Switch Monitor
- F1 Fuse 1A  
(Control Circuit 24V AC)
- F2 Overcurrent Relay  
(208/240V=5A; 440V=2.5A)
- F3 Fuse 2A  
(Brake Coil 24V DC)
- K1 Contactor DSL 6-53UE
- K2 Contactor DSL 6-53UE
- M1 Brake Motor With Gear Reducer
- T1 Transformer 208/240/440V to  
24V AC for Control Circuit &  
24V DC for Brake Release
- S1 Receiving Chamber Door Safety Switch
- S2 Blade Access Door Safety Switch
- S3 Meat Chamber Door Safety Switch
- S4 Thickness Adjustment Access Door  
Safety Switch
- S5 Main On Switch
- S6 Proximity Switch (Blade Position)
- S7 "Brake Release" Switch
- S8 Transporter Limit Switch
- S9 Main Off Switch
- S10 First Cut Selector Switch

**CIRCUIT DIAGRAM**  
 MOTOR: 208/240/440-60-3  
 CONTROL CIRCUIT: 24V AC  
 BRAKE: 24V DC






<b>Item No.</b>	<b>Description</b>	<b>Item No.</b>	<b>Description</b>
<b>31-9</b>	Coupling	<b>31-32</b>	Transporter pin
<b>31-10</b>	Motor, gear box & brake	<b>31-32-01</b>	Bushing for transporter
<b>31-10A</b>	Motor and brake	<b>31-33</b>	Transporter handle
<b>31-10B</b>	Brake unit	<b>31-33-01</b>	Spring for transporter handle
<b>31-10C</b>	Gear box only	<b>31-34</b>	Pin for transporter handle
<b>31-10-01</b>	Drive key	<b>31-34-01</b>	Retainer caps
<b>31-10-02</b>	Drive key	<b>31-35</b>	Slide bushings
<b>31-11</b>	Overrunning clutch	<b>31-36</b>	Claw attachment
<b>31-11-01</b>	Locking pin	<b>31-36-01</b>	Claw bracket
<b>31-11-02</b>	Washer	<b>31-36-02</b>	Flat head screws
<b>31-11-03</b>	Flathead screw	<b>31-36-03</b>	Locknut
<b>31-11-04</b>	Scale strip	<b>31-36-04</b>	Oval head screw
<b>31-12</b>	Underrunning clutch	<b>31-37</b>	Claw plate
<b>31-13</b>	Washer	<b>31-37-01</b>	Flathead screw
<b>31-14</b>	Draw lever	<b>31-38</b>	Ball knob
<b>31-14-01</b>	Ball bearing	<b>31-38-01</b>	Stud for ball knob
<b>31-14-02</b>	Locking ring	<b>31-38-02</b>	Hexagon nut
<b>31-15</b>	Washer	<b>31-39</b>	Torsion spring
<b>31-16</b>	Adjusting knob	<b>31-39-01</b>	Hinge bolt
<b>31-17</b>	screw indicator	<b>31-39-02</b>	Locknut
<b>31-18</b>	Eccentric ring	<b>31-39-03</b>	Washer
<b>31-18-01</b>	Washer	<b>31-40</b>	Door for receiving chamber
<b>31-18-02</b>	Washer	<b>31-41</b>	Door for feed chamber
<b>31-18-03</b>	Flathead screw	<b>31-42</b>	Handle
<b>31-18-04</b>	Hexagon screw	<b>31-43</b>	End weight
<b>31-19</b>	Self aligning ball bearing	<b>31-44</b>	Slide door handle
<b>31-19-01</b>	Adapter sleeve	<b>31-45</b>	Base
<b>31-20</b>	Shaft seal	<b>31-46</b>	Hinge, complete
<b>31-21</b>	Angular contact ball bearing	<b>31-47</b>	Motor support plate
<b>31-21-01</b>	Locking ring	<b>31-47-01</b>	Clutch support plate
<b>31-22</b>	Shaft seal	<b>31-47-02</b>	Angle (motor side) for slide bar support
<b>31-23</b>	Base adjusting leg	<b>31-47-03</b>	Slide bar angle
<b>31-24</b>	Shaft seal	<b>31-47-04</b>	Angle for slide bar support
<b>31-25</b>	Worm shaft	<b>31-47-05</b>	Hexagon screw
<b>31-25-01</b>	Spacer ring	<b>31-47-06</b>	Hexagon nut
<b>31-25-02</b>	Drive key	<b>31-47-07</b>	Slide bar
<b>31-26</b>	Coupling shaft	<b>31-48</b>	Window frame w/chamber (feed side)
<b>31-26-01</b>	Collar	<b>31-49</b>	Window frame w/chamber (receiving side)
<b>31-26-02</b>	Locking ring	<b>31-50</b>	Electrical box and parts (See Electrical Component Chart)
<b>31-26-03</b>	Hexagon screw	<b>31-50-A1</b>	Safety switch monitor
<b>31-26-04</b>	Washer	<b>31-50-F1</b>	Control fuse
<b>31-26-05</b>	Control ring	<b>31-50-F2</b>	Overcurrent relay
<b>31-26-06</b>	V-seal	<b>31-50-K1</b>	Contactors DSL6-53UE
<b>31-26-07</b>	Control screw	<b>31-50-K2</b>	Contactors DSL6-53UE
<b>31-26-08</b>	Hexagon nut	<b>31-50-K3</b>	Contactors 10E
<b>31-26-09</b>	Set screw	<b>31-50-M1</b>	See #31-10A
<b>31-26-10</b>	Drive key	<b>31-50-S1</b>	Magnetic safety switch w/magnet
<b>31-26-11</b>	Drive key	<b>31-50-S2</b>	Magnetic safety switch w/magnet
<b>31-27</b>	Door latch angle	<b>31-50-S3</b>	Magnetic safety switch w/magnet
<b>31-28</b>	Door handle assembly complete — top	<b>31-50-S4</b>	Magnetic safety switch w/magnet
<b>31-28A</b>	Door handle assembly complete — bottom	<b>31-50-S5</b>	"ON" switch
<b>31-28A-1</b>	Threaded stud, long (for door lock, bottom)	<b>31-50-S6</b>	Proximity switch
<b>31-28-G</b>	Door handle	<b>31-50-S7</b>	Brake release switch
<b>31-28-H</b>	Splined bushing	<b>31-50-S8</b>	Limit switch for transporter
<b>31-28-I</b>	Threaded stud, short (for door lock, top)	<b>31-50-S9</b>	"OFF" switch
<b>31-28-K</b>	Lock cam	<b>31-50-S10</b>	Jog switch
<b>31-29</b>	Blade flange	<b>31-50-T1</b>	Transformer 220V/24V
<b>31-30</b>	Knife blade — smooth edge — 4 mm — std	<b>31-50-X1</b>	Terminal strip
<b>31-30A</b>	Knife blade — serrated — 4 mm	<b>31-50-X2</b>	Terminal strip
<b>31-30B</b>	Knife blade smooth edge — 3 mm — special	<b>31-50-1A</b>	Magnet for safety switch S1
<b>31-31</b>	Transporter	<b>31-50-2A</b>	Magnet for safety switch S2
<b>31-31-01</b>	Transporter bracket	<b>31-50-3A</b>	Magnet for safety switch S3
<b>31-31-02</b>	Brass slider	<b>31-50-4A</b>	Magnet for safety switch S4
<b>31-31-03</b>	Hexagon screw	<b>31-51</b>	Leaf spring (top)
<b>31-31-04</b>	Taper pin	<b>31-52</b>	Leaf spring (bottom)
<b>31-31-05</b>	Transporter stop limit angle	<b>31-53</b>	Leaf spring release button
<b>31-31-06</b>	Washer		
<b>31-31-07</b>	Socket head screw		



### 31-11 OVERRUNNING CLUTCH

### 31-12 UNDERRUNNING CLUTCH



- 31-11-1 Cover with slotted handle
- 31-11-2 Input shaft
- 31-11-4 Seal 35 x 47 x 7
- 31-11-5 Bearing #16006 2 ea.
- 31-11-6 Main body
- 31-11-7 One way clutch #BF91
- 31-11-9 Seal 30 x 42 x 7
- 31-11-10 Spacer washer
- 31-11-14 Cap

- 31-12-3 Torque Arm
- 31-12-11 OneWay clutch #BF5007-10
- 31-12-12 Cover washer
- 31-12-13 Snap ring

**Prefix All Item No.'s with 31- Plus Number Shown**

**IMPORTANT!**  
 In case of spare part orders,  
 please refer to machine  
 number, type, and spare part  
 number.

