

DUTCHESS

Model JN

Semi-Automatic Dough Divider/Rounder
Fixed Pocket Design



**General Safety, Installation,
Instruction & Parts Manual**

NSF, USDA, UL Listed

*4 Machines in 1 Capability
36, 18, 9, & 6 Part Divisions
1-ounce up to 26-ounces each piece*

"Dutchess . . . Proven Leadership through Research & Development"

"DUTCHESS ALL-AMERICAN"

MODEL JN

Semi-Automatic Dough Divider/Rounder

NSF, USDA, UL Listed

- Patented -

TABLE OF CONTENTS

| | Page No. |
|--|-----------------|
| General Rules | 3-5 |
| Machine Specifications | 5 |
| Uncrating | 6 |
| Installation | 6-7 |
| Operating Instructions | 7-8 |
| Adjustments | 9-10 |
| Head Removal | 11-12 |
| Head Replacement | 12-14 |
| Head Cleaning | 14-15 |
| Machine Cleaning | 15-16 |
| Maintenance | 17 |
| Lubrication | 18 |
| Troubleshooting | 19-20 |
| Dough Scaling Charts (English & Metric) | 20-21 |
| Assemblies | 22-30 |
| Head Assemblies | 31-34 |
| Electrical Schematics | 35-36 |
| Safety Labels | 37 |

© 2002 Dutchess Bakers' Machinery Company, Inc.
302 Grand Avenue, Superior, WI 54880-0039

DUTCHESS TOLL FREE CUSTOMER SERVICE HOTLINE:
1 - 800 - 777 - 4498

Catalog: A4-441-0001F

General Rules

GENERAL SAFETY RULES:

- 1. Equipment should not be operated with safety devices or guards removed.**
- 2. Only qualified personnel should operate this machine.**
- 3. Machines should not be started until all personnel are clear.**
- 4. Service and maintenance procedures should never be performed on a machine in motion.**
- 5. To avoid shock or serious injury, only qualified personnel should perform maintenance on the electrical system.**
- 6. The electric power MUST be OFF before servicing the machine.**

GENERAL OPERATING RULES:

- 1. DO NOT operate this machine until you read and understand the operating instructions and become familiar with the machine and its controls.**
- 2. Never operate the machine with safety devices or guards removed or disconnected.**
- 3. DO NOT start the machine until all other personnel have been warned and have moved clear of the machine.**
- 4. Remove any tools and other foreign objects from the area around the machine.**
- 5. DO NOT have loose clothing or unrestrained long hair near operating machinery.**
- 6. Never sit or stand on anything that might cause you to fall against the machine.**
- 7. Horseplay around the machine is prohibited and could cause serious injury.**
- 8. Know the emergency stop procedure for the machine, see Pg. 9, "Emergency Stop".**
- 9. Electrical power MUST be OFF when the machine is not in use.**
- 10. The power switch is to be in the OFF position, and the machine disconnected from the power source, BEFORE servicing the machine.**
- 11. DO NOT operate faulty or damaged equipment.**
- 12. Avoid placing fingers, hands, or any part of your body into the machine, or near moving parts, while operating machine.**

SERVICE & MAINTENANCE:

- 1. DO NOT service a machine until you are thoroughly qualified, trained and familiar with the tasks to be performed.**
- 2. Never operate any controls while other persons are performing maintenance on the machine.**
- 3. DO NOT bypass a safety device.**
- 4. Always use the proper tool for the job.**
- 5. Never open covers with power on.**
- 6. Electrical power switch is to be turned off, and machine disconnected from the power source, unless absolutely required for a specific service being performed.**

ELECTRICAL:

- 1. All electrical maintenance and service should be performed only by trained and authorized electricians.**
- 2. Always assume that the power is ON.**
- 3. To remove load (power) from circuit, open disconnect or breaker, and lock in open position.**
- 4. Make certain that the circuit is open by using the proper test equipment. Test equipment MUST be checked at regular intervals.**
- 5. There may be circumstances where "Trouble Shooting" on live equipment may be required. Under such conditions special precautions must be taken such as, but not limited to:**
 - a. Your body and tools must be clear of the ground.**
 - b. Take extra safety measures in damp areas.**
 - c. Be alert and avoid any outside distractions.**
- 6. Before applying power to any equipment, make certain that all personnel are clear of the machine.**
- 7. Electrical panel doors, where applicable make certain the disconnect handle mechanism for electrical panel doors are operating properly.**
- 8. Close all covers on junction panels before leaving any job.**

CLEANING:

- 1. Turn off electrical power prior to cleaning machine.**

2. DO NOT use toxic and/or flammable solvents to clean machine. Use only mild soap and water.
3. Keep panel covers closed and power off when washing a machine.
4. Always clean up spills around machine as they occur and after operating and/or cleaning.
5. Never attempt to clean a machine while it is ON or operating.

"DUTCHESS ALL-AMERICAN"
MODEL JN
Semi-Automatic Dough Divider/Rounder

Machine Specifications

Machine:

| | |
|-----------------------------------|--|
| Weight (with 36-part head) | 450 lb. (168 Kg.) |
| Size (without handle) | Width: 26-1/2" (673 mm) Depth: 22" (558.8 mm) Height: 60" (1524 mm) |

Divider Head w/2 same division Dough Pallets:

| Head | Part Number | Weight Lb. | Weight Kg. |
|---------|-------------|------------|------------|
| 36-Part | C4-436-0066 | 42 lb. | 15.68 kg. |
| 18-Part | C4-436-0067 | 39 lb. | 14.56 kg. |
| 9-Part | C4-436-0068 | 34 lb. | 12.7 kg. |
| 6-Part | C4-436-0069 | 32 lb. | 11.94 kg. |

Dough Pallets:

| Pallet | Part Number | Pallet | Part Number |
|---------|-----------------------------|--------|-------------|
| 36-Part | C4-150-0003 | 9-Part | C4-150-0001 |
| 18-Part | C4-150-0002 | 6-Part | C4-150-0004 |

Electrical:

Standard: 208-240v 60hz 3phase (10 amp.) UL Listed

Available Options:

- 120v 60hz 1phase (15 amp.) UL Listed
- 240v 60hz 1phase (10 amp.) UL Listed
- 120v 50hz 1phase (15 amp.)
- 240v 50hz 1phase (10 amp.)
- 208v 50hz 3phase (10 amp.)
- 230v 50hz 3phase (10 amp.)

UNCRATING

This unit weighs 450 pounds, and proper equipment must be used to lift and move.

1. Set the total carton, with machine, on a flat, level surface.

CAUTION!

Carton staples are sharp - use proper tools to remove staples. Do not pull flaps by hand before removing staples!

2. Cut carton at dotted line at bottom. Lift carton over machine, and remove plastic bag.
3. The rear and side covers on the machine must be removed. Turn the two latches $\frac{1}{4}$ turn and top edge will move outward. Lift cover upward off retainers.

IMPORTANT

The covers must be reinstalled on the machine after installation!

4. The handle, pallets, and miscellaneous components are located inside the lower base of the machine. Remove through the rear opening.
5. Remove the (4) lag bolts, one in each corner.
6. Using proper equipment, lift machine from packing skid. Do not push or lift on the spring covers!

OPTIONAL HEAD ASSEMBLIES

1. Optional head assemblies are shipped in a separate carton. Remove staples from smaller carton top flaps.
2. Lift inner carton from carton. Remove head assembly from carton and packing materials. There are two dough pallets in the bottom of the outer carton. Remove the protective paper from the pallets.
3. Dispose of all cartons and packing properly.

INSTALLATION

1. Locate the (4) foundation holes inside the base in all four corners. The machine is designed to be secured to the floor, See Fig. 1. Arrange on 18 inch square pattern, (4) $\frac{3}{8}$ " diameter bolts or studs. (Bolts or studs supplied by others.)




Figure 1

2. Set machine in place with bolts and/or studs properly set and tightened. Seal around the base with an approved silicone sealant, GE RTV 102 or equal.
3. Each machine must be direct wired. See proper wiring diagrams on pages 35 - 36.

CAUTION!

All electrical connections should be installed by an electrician. All state, local and national electrical codes MUST be complied with.

4. Reinstall side covers.
5. Install handle, with hole topside, fully into socket on ram lever. Tighten supplied set-screw, through hole in handle, with hex key wrench.
6. Apply a thin coat of sealant (RTV 102) at top edge of plastic plug supplied in package of components. Tap plug into hole over the set-screw. See Fig. 2.
7. Seal around handle at lever arm with sealant (RTV 102).




Figure 2

8. To change or install head and pallet, see instructions on pages 11 - 14.

OPERATING INSTRUCTIONS

CAUTION!

Machine must be fully assembled before starting or operating. Please refer to Fig. 3, Page 9 for operation:

1. Refer to dough weight charts for required dough piece size. See chart on pages 20 - 21

CAUTION!

Use only pallets supplied! Never use two pallets or shim the pallet, as damage will occur, voiding your warranty.

2. Place a pallet (No. 2) on a worktable. Knead or roll out the weighed dough within the inscribed circle on the pallet. (Do not use flour on pallet, as this will affect the quality of rounding)

IMPORTANT

- a. If the dough is sticky, lightly dust the top surface only with flour to prevent the dough from sticking to the head assembly (No. 3). Never flour the pallet. Do not flour the top, unless necessary.
- b. Do not use grease or oil on the dough or pallet.
- c. The dough to be divided/rounded must not have a crust.
- d. All levers and handle must be in the starting, normal position.

3. Flip the power switch to ON, and leave the motor running until the day's dividing/rounding is complete.
4. Place pallet (No. 2) with weighed dough onto the crankplate (No 4).

CAUTION!

The pallet must fit snugly and flat on the crankplate with the handle in the forward position. Damage will occur to pallet, divider, and/or crank plate, if pallet is not in proper position.

5. Pull handle (No. 1) down, lowering ring (No. 5) until head assembly (No. 3) comes in contact with the dough. Now it is important for you to exert firm, even pressure on the dough for 3-4 seconds, by pulling or pushing down on the handle, forcing the dough to level, and become equal in thickness within the confines of the ring.
6. Relax the down pressure on the handle, but continue holding handle down with your right hand. With the other hand, release the trip lever (No. 6) which will release the divider. You can now push the handle to its furthest down position, dividing the dough.
7. While still holding the handle down, pull forward on the rounding lever (No. 7). This will rotate the crankplate (No. 4) and round the divided dough pieces into dough balls, (approximate rounding time required: 5-15 seconds).
8. When sufficient rotations have taken place, return the rounding lever (No. 7) to its idle position. Raise the handle (No. 1) to its uppermost position.

NOTICE

Too many, or too few revolutions during rounding will affect the final results of your dough balls. Experiments should be made to determine the correct number of revolutions necessary for your dough, and product requirements.

IMPORTANT

The further forward you pull the rounding lever, the wider, and faster the rounding motion becomes.

IMPORTANT

Pocket size may be adjusted higher or lower to accommodate various dough sizes and rounding consistency. This will require experimenting to obtain the correct pocket height for various products and doughs. See adjustments on Page 9, Item 1.

9. Remove the pallet (No. 2) with the finished dough balls from the machine. Remove these pieces from the pallet. Repeat the above procedure for additional dividing and rounding.

NOTICE

Achieving the best results with your dough will require some experimenting with the pocket settings and rounding action. See Adjustments Pg. 9 Item 1.

WARNING!

Do not operate this machine without covers and canopies on and in a secured position.



Figure 3

WARNING!

Keep hands and clothing clear of all moving parts.

EMERGENCY STOP

In case of emergency, release rounding lever, flip power switch to OFF, and raise handle.

ADJUSTMENTS

All adjustments have been made at the factory, however, readjusting may be required upon installation, and periodically during use.

1. Your new Dutchess Divider/Rounder comes equipped with a "fixed pocket" design. Experimentation will be required to determine the correct pocket height for each size dough ball. To

increase the pocket height, loosen the locking nut by turning counter clockwise. Turn the stop rod clockwise to decrease pocket height (for smaller rolls) and counter clockwise to increase pocket height (for larger rolls). Retighten locking nut before rounding by turning clockwise. See Fig. 4




Figure 4




Figure 5

2. Motor Belt tension will require tightening as belts wear and stretch.

WARNING!

Before removing cover, place power switch in the OFF position and disconnect the machine from the power source.

To adjust, see Fig. 5. Remove cover from side of base. With a wrench, loosen locking nut, turn knob clockwise by hand to tighten belts. The belts should have approximately 1/16 inch deflection. Retighten the lock nut and replace the cover. This adjustment must be tested after being made.

3. Drive Slide adjustment is to stop the crank plate in the center, when releasing the rounding lever, See Fig.6. The crank plate must be removed to make this adjustment. (To remove crankplate, see instructions on page 18, Item 7) Loosen lock nut and turn set screw counter clockwise, to allow drive slide to come back to center. Tighten lock nut. If drive slide is coming back beyond center, loosen lock nut, turn set screw clockwise, pushing drive slide to center, tighten lock nut.




Figure 6

HEAD REMOVAL

To remove the head assembly for cleaning, or for interchanging with one of the optional head assemblies of other divisions.

CAUTION!

A pallet must be in place on the crank plate when removing and installing the head assembly.

1. Remove front and rear canopies (Fig. 7, No. 5 & No. 6) by lifting up, and out.
2. Pull handle (Fig. 7, No. 1), down until ring (No. 2) is resting on pallet (No. 3).




Figure 7




Figure 8

WARNING!

Do not release the handle from your hand, until the handle is returned to its uppermost position.

3. Hold handle in this position, grasp outer edges of the ring (Fig. 8, No. 1) keep fingers out of the divider/plug area. Rotate ring $\frac{1}{4}$ turn until slots are in line with the arms (Fig. 8, No. 2).
4. Slowly raise the handle and watch arms (No.2) for interference. If interference occurs, lower handle and reposition the ring (No. 1). Raise handle, with no interference, to its uppermost position.
5. Remove ring (Fig. 8, No. 1) from machine, set ring aside on work bench. Do not drop or bump ring, as this can cause nicks or other damage to ring.
6. Loosen the two hand knobs (Fig. 10, No. 3) fully.
7. Set pocket height on the stop rod, Fig. 9, at least 1" off the trip plate. Release the trip lever (Fig 10, No. 1).




Figure 9




Figure 10

WARNING!

Do not release the handle from your hand, until the handle is raised to its uppermost position.

8. Pull handle down until head rests on pallet (Fig. 10).

9. Rotate head assembly (Fig. 10, No 2) ¼ turn clockwise.

10. Raise handle slowly, watch ram (Fig. 11) making sure it causes no interference. Continue to raise handle to uppermost position. Head assembly should be resting on the pallet.




Figure 11



Figure 12

11. Remove head assembly (Fig 12, No. 1). This head can now be cleaned. (See pages 14 - 15).

HEAD REPLACEMENT

1. With pallet in place, position head assembly (Fig. 13, No. 1) in center of pallet with handle in front.



Figure 13



Figure 14

2. Release the trip lever, and slowly lower the handle. Watch the lower end of the ram (Fig. 11) insertion into the head. Align the head as necessary to complete insertion.

WARNING!

Keep hand from between the head (Fig. 14, No. 2) and the trip plate (No. 3).

WARNING!

Do not release handle from your hand, until the handle is raised to its uppermost position.

3. Rotate the head assembly, Fig. 15, No. 1, $\frac{1}{4}$ turn clockwise. Alignment pin at front of trip plate, Fig. 15, No. 2, will engage in hole in head assembly, No. 1.




Figure 15




Figure 16

4. Raise handle to its uppermost position.
5. Tighten both hand knobs (Fig 15, No. 3).
6. Set ring (Fig 16, No. 1) on center of pallet.
7. Lower handle slowly and align ring (No. 1) with head (No. 2) continue down with handle, align ring slots with arms (Fig. 16, No. 3).

8. Hold handle in this position, rotate ring clock-wise $\frac{1}{4}$ turn, grasp ring at outer edge, keeping fingers out of divider/plug area.
9. Raise the handle to its highest upright position.
10. Replace front and rear canopies by aligning key holes with pins and sliding downward.

CAUTION!

The ring must be rotated clockwise until the pin rests against the ring arm.

HEAD CLEANING

CAUTION!

Do not use solvents; use only mild soap and water, or you may place entire head in dishwasher. Use care that washer sprayers will not hit head assembly as damage could occur to head and/or dishwasher.

For the best cleaning results, remove the ring and head assembly, (see instructions pages 11-14) and place on table. Remove divider from head assembly by removing the screws with a flat blade screwdriver through the holes in the upper plate (Fig. 17). Next, lift head by the handles. The divider will remain on the table (Fig. 18). Remove the screws and set aside for re-assembly.



Figure 17




Figure 18

The divider may then be washed in hot water with soap, rinsed and dried - avoid bumping dividers on solid objects as this will cause damage.

The remaining head assembly may be washed in hot water with soap, rinsed and allowed to air dry. Air drying is necessary so components will cool and allow for proper operation.

To reassemble the divider into the head, place the head upside down on a table, align the longer dividers in the slots with the screw holes below. Align all the dividers with the head (Fig 19). Slip the divider into place, adjust the screw slots (Fig. 20). While holding the divider in place, turn the entire head right side up and set on bench.




Figure 19




Figure 20

Install the screws into the divider through the holes in the top plate. Tighten the screws with the flat blade screwdriver (Fig. 21).




Figure 21

Wash the outside ring in hot soapy water, rinse and dry. Do not drop or bump this ring as this will cause nicks or damage to ring.

Wash the pallets using hot soapy water, rinse and dry. A soft brush will assist in cleaning the pallets. Never use solvents or metal scrapers on pallets.

The entire head assembly (head, divider, ring, and pallets) can be placed in a dishwasher for daily cleaning. These components must be allowed to cool to room temperature before operating. Special care should be taken when placing into dishwasher to be sure sprayer heads can not hit head assembly or damage could occur to head and/or dishwasher.

CAUTION!

Do not drop or bump the dividers or damage will occur and the machine will not operate properly.

UPPER MACHINE CLEANING

The upper section must be cleaned, using a soap and water solution. Perform this operation with the head assembly off the machine.

1. Remove the front and rear canopies by lifting up and out.

CAUTION!

Place a solid block between the crank plate and the trip plate, to prevent movement, before proceeding.

2. Remove trip spring assembly by loosening and removing the shoulder bolt (Fig 22).



Figure 22




Figure 23

3. Remove the four pull pins, four links, and one roller (Fig. 22).
4. Remove the trip lever by loosening and removing the shoulder bolt (Fig. 23).
5. Wash the entire upper area with soap and water. Rinse, then wipe dry all shafting and components.
6. Shafts, spindles, pins and pivot points should have lubrication applied. Lubrication should be a USDA approved oil ONLY! This oil should be applied sparingly. Apply oil to a clean, soft cloth and wipe these moving parts, see Lubrication on page 18.

Reassemble the components:

1. Replace links and pins, longer link in-board with roller, shorter link outer most (Fig. 22).
2. Place the trip lever set in slot on shaft, then install shoulder bolt and tighten (Fig. 23).
3. For trip spring replacement, place rod end on trip lever pin, install shoulder bolt and tighten (Fig. 22).
4. Install head assembly per instructions on pgs. 12 - 14.

WARNING!

Machine must be fully assembled before operating.

Wipe total exterior of machine with hot soapy water. Rinse with clear water, and wipe dry.

MAINTENANCE

WARNING!

The power switch is to be in the OFF position, and the machine disconnected from the power source, before servicing or cleaning. Always check before beginning these operations. This machine requires minimal maintenance, but a regular maintenance schedule should be established to assure many years of trouble-free service.

1. The head assembly should be cleaned daily. See "head removal and installation", pages, 11-12, for removal of head. The head assembly can be placed in a dishwasher, or washed by hand..
2. The pallets are made of Lexan, and can be washed daily. The pallets will scratch during regular use, however, do not use metal, or other sharp objects on the pallets.
3. The crank plate should be wiped clean before each installation of the pallet. If soiled, a soap and water solution should be used. Scrape with a plastic scraper if soil build up has occurred.
4. The exterior should be wiped down with a soap and water solution. (Do not use solvents).
5. The paint is abrasion, impact, moisture resistant, and USDA approved. If the paint should become damaged, a similar type paint should be applied.
6. The motor belts will require tightening, and when worn, replacement. For tightening, see adjustments Item 2, page 10.

BELT REPLACEMENT

To replace the belts, see Fig. 24. Remove covers, loosen belt adjusting lock nut and knob totally. Remove sheaves canopies by pulling straight down. Remove belts from motor sheaves at top. Belts will slip down off driven sheaves over bearing cup. Pull pin from lift arm and remove belt.




Figure 24



Figure 25

To install belts, reverse procedure and complete tightening belts as shown in Adjustments, item 2 page 10.

7. To service crank bearings, slide pins, and follower (Fig. 25), remove crank plate, page 22, Item 37, by removing the forward center plastic plug, Item 2, and hex shoulder bolt, Item 1 from the crank plate. To do this, the silicone in the center of the plug must be pried out, then insert the bolt provided with your warranty packet into the plug, and turn clockwise until the plug can be removed. After removing the hex shoulder bolt, grasp both sides of the crank plate and lift. (See maintenance schedule, page 18) Replace crank plate. Remove bolt from plug and tap plug back into crank plate until flush with surface. Apply a small amount of silicone into hole in plug. Save the bolt for future use.

The components of this machine require very little maintenance, but all mechanical equipment does require periodical service for proper operation and extended life. A regular lubrication schedule should be established and followed. The frequency of lubrication must be determined by the user. Use inside of front cover for recording maintenance performed.

LUBRICATION

Type of Lubrication: OIL: Must be a USDA approved food grade. May be a spray type.
Grease: must be a USDA approved grease.

CAUTION!

The power switch is to be in the OFF position and the machine disconnected from the power source before servicing.

IMPORTANT

Always clean excess grease and oil from the machine and surrounding area.

MAINTENANCE SCHEDULE

The following information is to be used as a guide:

| ITEM | LUBE | METHOD | FREQUENCY | FIG./PG. |
|------------------|--------|--------|----------------|-----------------|
| 1. Spindles | Oil | Wipe | After Cleaning | Fig. 7, Pg. 11 |
| 2. Ram Pin | Oil | Wipe | After Cleaning | Fig. 7, Pg. 11 |
| 3. Linkage Pins | Oil | Drop | After Cleaning | Fig. 22, Pg. 15 |
| 4. Follower | Oil | Wipe | Yearly | Fig. 25, Pg. 17 |
| 5. Crank Bearing | Grease | Pack | Yearly | Fig. 25, Pg. 17 |
| 6. Slide Pins | Oil | Wipe | Yearly | Fig. 25, Pg. 17 |

TROUBLESHOOTING

If a problem should continue AFTER having attempted the corrective SOLUTIONS found on Pages 18 - 20, Please call the Dutchess Customer Service Hotline Number 1 - 800 - 777 - 4498

Problem

Solution

Rounding will not take place:

- | | |
|------------------------------|---|
| 1. Drive belts slipping: | - Adjust belts, see Adjustments, Item 2 Page 10. |
| 2. Motor not operating: | |
| a. Motor overload tripped | - Set switch to stop position, allow motor to cool, push reset on lower end of motor. Replace cover, start machine. |
| b. Switch faulty | - Replace switch. |
| c. No incoming power | - Check circuit breaker of fuses, incoming power. |
| 3. Lift arm loose: | - Reposition and tighten in lower base. |
| 4. Slide rod/drive sticking: | - Clean slide rods and lubricate under crank plate. |
| 5. Follower sticking: | - Clean follower tracks and lubricate bearings under crank plate. |
| Dough Balls Vary In Size: | - Dough needs to be pressed out with more pressure on handle. - Knead or roll dough evenly within the inscribed circle on the dough pallet before pressing. |
| Dough Sticks To Head: | - Dust the top of the dough only, with a light dusting flour prior to pressing. - Head assembly not clean, wash and dry head assembly, see Cleaning Instructions on pages 14 - 15. |

TROUBLESHOOTING

Problem:

Solution:

Partial Rounding of Dough Balls

- | | |
|--------------------------------|--|
| 1. Pocket height set too high: | - Readjust pocket height, see Adjustments, Pg. 9 - 10. |
| 2. Rounding time too short: | - Increase rounding time. |
| 3. Pallet is oily or floured: | - Wash and dry pallet. |
| 4. Drive Belts slipping: | - Adjust or replace belts, see Adjustments, Item 2, |

- Flour Pocket in Dough Ball: - Use less flour on top of dough.
- Imperfection of Dough Ball:
 - Usually caused by over, or under rounding. (Normal rounding time: 5 - 15 seconds.)
 - Pocket height set too high or too low. (Raise or lower as needed.)
- Rounding Action Will Not Stop:
- Rounding lever not returning to idle position:
 - Lubricate linkage.
 - Check slide springs.
- Crank Plate will Not Center: - Adjust drive slide centering, see adjustment pg.10
- 1. Broken slide spring: -Replace spring.
- 2. Slides/drive slide sticking: - Clean slides, lubricate.

WARNING!

The power switch is to be in the OFF position, and the machine disconnected from the power source, before servicing or cleaning.

DOUGH SCALING CHARTS IN POUNDS & OUNCES

The weights listed on this chart, are based on an average viscosity dough. The minimum and maximum dough weights indicated on this sheet may increase, or decrease, according to dough viscosity.

| 36-Part Head Assembly | | 18-Part Head Assembly | |
|--|------------------------|--|------------------------|
| Total wt. of dough in Pounds & Ounces | Each roll in Ounces | Total wt. of dough in Pounds & Ounces | Each roll in Ounces |
| 2 lb. 4 oz. | 1 oz. | 3 lb. 6 oz. | 3 oz. |
| 2 lb. 13 oz. | 1-1/4 oz. | 3 lb. 15 oz. | 3-1/2 oz. |
| 3 lb. 6 oz. | 1-1/2 oz. | 4 lb. 8 oz. | 4 oz. |
| 3 lb. 15 oz. | 1-3/4 oz. | 5 lb. 1 oz. | 4-1/2 oz. |
| 4 lb. 8 oz. | 2 oz. | 5 lb. 10 oz. | 5 oz. |
| 5 lb. 1 oz. | 2-1/4 oz. | 6 lb. 3 oz. | 5-1/2 oz. |
| 5 lb. 10 oz. | 2-1/2 oz. | 6 lb. 12 oz. | 6 oz. |
| 6 lb. 3 oz. | 2-3/4 oz. | 7 lb. 4 oz. | 6-1/2 oz. |
| 6 lb. 12 oz. | 3 oz. | 7 lb. 13 oz. | 7 oz. |
| | | 8 lb. 6 oz. | 7-1/2 oz. |
| | | 8 lb. 12 oz. | 7-3/4 oz. |

9-Part Head Assembly

| Total wt. of dough in Pounds & Ounces | Each roll in Pounds & Ounces |
|--|---------------------------------|
| 4 lb. 8 oz. | 8 oz. |
| 5 lb. 1 oz. | 9 oz. |
| 5 lb. 10 oz. | 10 oz. |
| 6 lb. 3 oz. | 11 oz. |
| 6 lb. 12 oz. | 12 oz. |
| 7 lb. 5 oz. | 13 oz. |
| 7 lb. 14 oz. | 14 oz. |
| 8 lb. 7 oz. | 15 oz. |
| 9 lb. | 1 lb. |
| 9 lb. 9 oz. | 1 lb. 1 oz. |
| 10 lb. 2 oz. | 1 lb. 2 oz. |

6-Part Head Assembly

| Total wt. of dough in Pounds & Ounces | Each roll in Pounds & Ounces |
|--|---------------------------------|
| 6 lb. 12 oz. | 1 lb. 2 oz. |
| 7 lb. 2 oz. | 1 lb. 3 oz. |
| 7 lb. 8 oz. | 1 lb. 4 oz. |
| 7 lb. 14 oz. | 1 lb. 5 oz. |
| 8 lb. 4 oz. | 1 lb. 6 oz. |
| 8 lb. 10 oz. | 1 lb. 7 oz. |
| 9 lb. | 1 lb. 8 oz. |
| 9 lb. 6 oz. | 1 lb. 9 oz. |
| 9 lb. 12 oz. | 1 lb. 10 oz. |

DOUGH SCALING CHARTS IN GRAMS

The weights listed on this chart, are based on an average viscosity dough. The minimum and maximum dough weights indicated on this sheet may increase, or decrease, according to dough viscosity.

36-Part Head Assembly

| Total wt. of dough in Grams | Each roll in Grams |
|--------------------------------|-----------------------|
| 1080 | 30 |
| 1260 | 35 |
| 1440 | 40 |
| 1800 | 50 |
| 2160 | 60 |
| 2340 | 65 |
| 2700 | 75 |
| 2880 | 80 |
| 3660 | 8 |

18-Part Head Assembly

| Total wt. of dough in Grams | Each roll in Grams |
|--------------------------------|-----------------------|
| 1800 | 100 |
| 2016 | 112 |
| 2250 | 125 |
| 2520 | 140 |
| 2790 | 155 |
| 3150 | 175 |
| 3330 | 185 |
| 3600 | 200 |
| 3780 | 210 |

9-Part Head Assembly

| Total wt. of dough in Grams | Each roll in Grams |
|--------------------------------|-----------------------|
| 2070 | 230 |
| 2250 | 250 |
| 2520 | 280 |
| 2790 | 310 |
| 3060 | 340 |
| 3330 | 370 |
| 3555 | 395 |
| 3825 | 425 |
| 4082 | 450 |


6-Part Head Assembly

| Total wt. of dough in Grams | Each roll in Grams |
|--------------------------------|-----------------------|
| 3060 | 510 |
| 3240 | 540 |
| 3420 | 570 |
| 3570 | 595 |
| 3750 | 625 |
| 3930 | 655 |
| 4080 | 680 |
| 4260 | 710 |
| 4410 | 735 |

BASE ASSEMBLY PARTS

| Item | Qty. | Description | Part Number |
|------|------|-----------------------------------|--------------|
| 1 | 1 | Shoulder Screw | A4-033-0009 |
| 2 | 1 | Plug with Insert | A4-139-0010 |
| 10 | 1 | Frame, Painted | B4-436-0018 |
| 29 | 4 | Wheels, Dual-Vee W3SSX | P4-905-0001 |
| 30 | 2 | Bushings, Stationary | P4-902-0002 |
| 31 | 2 | Bushings, Adjustable | P4-905-0003 |
| 32 | 4 | Hex Head Cap Screw | 11-S-0514 |
| 33 | 4 | Intl. Tooth Lock Washer | 64-H-05 |
| 37 | 1 | Crank Plate Sub-Assembly | B4-436-0035 |
| 49 | 1 | Rounding Lever w/Stop | A4-045-0003 |
| 51 | 1 | Sq. Hd. Set Screw | 30-E-0508 |
| 52 | 1 | Hex Jam Nut | 45-E-05 |
| 53 | 1 | Rounding Lever | A4-045-0006 |
| 56 | 1 | Knob, Ball | P4-939-0004 |
| 57 | 1 | Lift Arm Shaft | A4-053-0007 |
| 58 | 1 | Hex Jam Nut | 45-E-60 |
| 87 | 8 | Flat Hd. Ph. Mach. Screw | 22-E-0308 |
| 88 | 1 | Thrust Washer, Crank Plate | A4-020-0015 |
| 89 | 2 | Bearing | P4-903-0021 |
| 90 | 1 | Drive Sub-Assembly | B4-436-0037 |
| 91 | 4 | Hex Hd. Cap Screw | 11-E-0810 |
| 92 | 4 | Intl. Tooth Lock Washer | 64-H-08 |
| 93 | 1 | Follower Sub-Assembly | B4-436-0038 |
| 101 | 1 | Arm Shaft Thrust Washer | A4-020-0002 |
| 102 | 1 | Lift Arm, Drive | A4-044-0005 |
| 103 | 1 | Bushing, Lift Arm | P4-909-0019 |
| 104 | 1 | Sq. Hd. Set Screw | 30-E-0612 |
| 105 | 1 | Hex Jam Nut | 45-E-06 |
| 106 | 1 | Key | S-E-05-05-12 |
| 107 | 1 | Pin | P4-957-0002 |
| 163 | 2 | Skt. Set Screw, Knurled Cup Point | 32-Y-0805 |
| 188 | 1 | Plug, Set Screw | A4-436-0012 |
| 892 | 4 | Hex Nut | 41-E-07 |
| 893 | 4 | Intl. Tooth Lock Washer | 64-H-07 |


YOKE ASSEMBLY SCHEMATIC



YOKE ASSEMBLY PARTS

| Item | Qty. | Description | Part Number |
|------|------|------------------------------------|-------------|
| 10 | 1 | Frame, Painted | B4-436-0018 |
| 108 | 1 | Shrink Tubing | P4-921-0036 |
| 109 | 1 | Trip Plate Sub-Assembly | B4-436-0040 |
| 120 | 1 | Ring Yoke Sub-Assembly | B4-436-0039 |
| 126 | 2 | Plug | A4-139-0025 |
| 132 | 1 | Stop Rod | B4-074-0008 |
| 133 | 1 | Locking Nut for Stop Rod | A4-019-0009 |
| 149 | 4 | Post for Canopy | A4-033-0007 |
| 154 | 1 | Ring Lift Support | B4-091-0122 |
| 155 | 2 | Hex Hd. Cap Screw | 11-E-0610 |
| 156 | 2 | Bushing | P4-909-0002 |
| 157 | 2 | Bushing, Spindle Top | A4-024-0030 |
| 158 | 2 | Bushing, Yoke | P4-909-0018 |
| 159 | 1 | Pivot Arm | B4-044-0004 |
| 160 | 2 | Pivot Bolt | A4-033-0008 |
| 161 | 1 | Ram Lever | B4-045-0029 |
| 162 | 1 | Torsion Spring Shaft, Fixed Pocket | A4-053-0070 |
| 163 | 2 | Skt. Set Screw, Knurled Cup Point | 32-Y-0805 |
| 164 | 1 | Ram | B4-064-0005 |
| 165 | 1 | Stop Collar, Fixed Pocket | B4-022-0008 |
| 166 | 1 | Torsion Spring, R/H | A4-082-0005 |
| 167 | 1 | Torsion Spring, L/H | A4-082-0006 |
| 168 | 1 | Ram Pin | A4-066-0025 |
| 169 | 2 | Plug | A4-139-0024 |
| 170 | 2 | Bushing, Ram | P4-909-0020 |
| 171 | 1 | Skt. Set Screw | 29-Y-0603 |
| 172 | 2 | Swing Link | A4-044-0007 |
| 173 | 2 | Lift Link | A4-044-0008 |
| 174 | 1 | Lift Roller | A4-076-0003 |
| 175 | 4 | Pin | P4-957-0003 |
| 176 | 1 | Spindle, Fixed Pocket | A4-145-0004 |
| 177 | 1 | Shaft Collar | P4-935-0015 |
| 181 | 2 | Spring Cover | B4-063-0026 |
| 182 | 4 | Drive Screw | 71-E-0606 |
| 185 | 1 | Sq. Hd. Set Screw | 30-E-0810 |
| 186 | 1 | Hex Jam Nut | 45-E-08 |
| 187 | 1 | Shrink Tubing | P4-921-0035 |
| 188 | 2 | Plug, Set Screw | A4-139-0026 |
| 891 | 4 | Carriage Bolts | 15-E-0708 |
| 1591 | 2 | Bushing | P4-909-0015 |
| 1593 | 2 | Spacer Washer | A4-021-0011 |
| 1601 | 2 | Bushing | P4-909-0016 |
| 1602 | 2 | Spacer Washer | A4-021-0010 |
| 1711 | 1 | Plug | A4-139-0007 |
| 1720 | 2 | Spindle Spring, Compression | P4-965-0011 |
| 1730 | 2 | Retaining Ring | P4-957-0001 |


CRANK PLATE SUB-ASSEMBLY SCHEMATIC



CRANK PLATE PARTS

| Item | Qty. | Description | Part Number |
|------|------|-------------------------|-------------------------------|
| 38 | 1 | Crank Plate Hard Coated | B4-147-0031-P |
| 39 | 1 | Bearing, Crank Plate | P4-903-0020 |
| 40 | 2 | Cam Follower | P4-903-0018 |
| 41 | 2 | Cam Follower, Eccentric | P4-903-0019 |
| 42 | 4 | Spring Lock Washer | 63-E-07 |
| 43 | 4 | Hex Nut | 41-E-57 |
| 47 | 4 | Crank Plate Plugs | A4-139-0023 |


TRIP SPRING SUB-ASSEMBLY SCHEMATIC



TRIP SPRING SUB-ASSEMBLY PARTS

| Item | Qty. | Description | Part Number |
|------|------|------------------|-----------------------------|
| 10 | 1 | Cylinder | P4-919-0002 |
| 20 | 1 | Mounting Bracket | A4-091-0127 |
| 40 | 1 | Rod End | A4-127-0002 |
| 50 | 1 | Filter | P4-935-0017 |


TRIP PLATE SUB-ASSEMBLY SCHEMATIC



TRIP PLATE SUB-ASSEMBLY PARTS

| Item | Qty. | Description | Part Number |
|------|------|------------------------------|-----------------------------|
| 109 | 1 | Trip Plate, Fixed Pocket | B4-147-0082 |
| 110 | 1 | Trip Spring Sub-Assembly | A4-436-0041 |
| 111 | 2 | Pin | 73-E-0816 |
| 112 | 1 | Trip Lever | B4-436-0042 |
| 113 | 1 | Slotted Shoulder Screw | 83-E-0301 |
| 115 | 1 | Slotted Shoulder Screw | 83-E-0804 |
| 114 | 1 | Knob, Tapered Grasp | P4-939-0006 |
| 117 | 2 | Trip Plate Knob Sub-Assembly | A4-436-0043 |


FOLLOWER SUB-ASSEMBLY SCHEMATIC



FOLLOWER SUB-ASSEMBLY PARTS

| Item | Qty. | Description | Part Number |
|------|------|-------------------------|-----------------------------|
| 33 | 1 | Track Support | B4-091-0123 |
| 34 | 4 | Hex Hd. Cap Screw | 11-E-0406 |
| 35 | 1 | Follower Bar | A4-136-0003 |
| 36 | 2 | Hex Hd. Cap Screw | 11-E-0508 |
| 37 | 2 | Track, Dual-Vee | A4-100-0001 |
| 38 | 4 | Intl. Tooth Lock Washer | 64-H-04 |
| 39 | 2 | Intl. Tooth Lock Washer | 64-H-05 |


MOTOR BASE SUB-ASSEMBLY SCHEMATIC



MOTOR BASE SUB-ASSEMBLY PARTS

| Item | Qty. | Description | Part Number |
|------|------|--------------------|-------------|
| 60 | 1 | Motor Base | B4-030-0005 |
| 65 | 1 | Motor Pin | A4-066-0008 |
| 66 | 1 | Motor Adjust Arm | A4-044-0009 |
| 67 | 1 | Sq. Head Set Screw | 30-E-0810 |
| 68 | 2 | Hex Jam Nut | 45-E-08 |
| 69 | 1 | Knob, Fluted | P4-939-0005 |
| 70 | 1 | Collar | P4-935-0016 |


RING YOKE SUB-ASSEMBLY SCHEMATIC



RING YOKE SUB-ASSEMBLY PARTS

| Item | Qty. | Description | Part Number |
|------|------|---------------------------|-------------|
| 121 | 1 | Ring Yoke | B4-088-0007 |
| 122 | 2 | Bushing, Ring Yoke | P4-909-0017 |
| 123 | 2 | Ring Arm | B4-091-0125 |
| 124 | 2 | Bushing, Ring Yoke | P4-909-0013 |
| 125 | 2 | Flat Hd. Socket Cap Screw | 13-E-0510 |
| 127 | 2 | Bushing, Ring Lever | P4-909-0021 |
| 128 | 1 | Ring Lever | B4-045-0030 |
| 129 | 2 | Drive Pin | 75-D-0824 |
| 130 | 2 | Pivot Bolts | A4-033-0010 |


DRIVE SUB-ASSEMBLY SCHEMATIC



DRIVE SUB-ASSEMBLY PARTS

| Item | Qty. | Description | Part Number |
|------|------|----------------------|--------------|
| 2 | 1 | Bearing Mount | B4-058-0024 |
| 3 | 2 | Bearing, Drive | P4-903-0017 |
| 4 | 1 | Slide Yoke, Drive | C4-088-0003 |
| 5 | 2 | Bushing | P4-909-0016 |
| 6 | 1 | Socket Set Screw | 29-E-0510 |
| 7 | 1 | Hex Jam Nut | 45-E-05 |
| 8 | 1 | Drive Slide | B4-142-0003 |
| 9 | 2 | Bushing, Long Slide | P4-909-0011 |
| 10 | 2 | Bushing, Short Slide | P4-909-0010 |
| 11 | 4 | Pin | 77-D-1020 |
| 12 | 1 | Connecting Link | A4-044-0012 |
| 13 | 2 | Bushing | P4-909-0005 |
| 14 | 1 | Push Rod | A4-064-0006 |
| 15 | 2 | Pin | A4-066-0026 |
| 16 | 2 | Slide Rod | A4-064-0007 |
| 17 | 2 | Socket Set Screw | 29-Y-0404 |
| 18 | 2 | Spring, Drive Slide | A4-082-0003 |
| 19 | 1 | Key | S-F-06-06-08 |
| 20 | 1 | Two Groove S heave | B4-098-0001 |
| 21 | 1 | Socket Set Screw | 29-Y-0604 |
| 22 | 1 | Yoke Cap, Drive | A4-016-0004 |
| 23 | 1 | Bearing | P4-903-0022 |
| 24 | 1 | Flat Washer | P4-927-0015 |
| 25 | 1 | Hex jam Nut | 45-E-06 |
| 26 | 1 | Drive Bearing Cup | C4-058-0026 |
| 27 | 3 | Hex Head Cap Screw | 11-E-0508 |
| 28 | 3 | Spring Lock Washer | 63-E-05 |


Final Assembly Schematic



Final Assembly (Electrical) Parts

| Item | Qty. | Description | Part Number |
|------|------|--|-----------------------------|
| 10 | 2 | Square Hd. Set Screw | 30-E-0812 |
| 20 | 2 | Hex Jam Nut | 45-E-08 |
| 30 | 1 | Motor Base Sub-Assembly | B4-436-0020 |
| 31 | 4 | Hex Hd. Cap Screw | 11-E-0508 |
| 32 | 4 | Hex Nut | 41-E-05 |
| 33 | 4 | Intl. Tooth Lock Washer | 64-H-05 |
| 34 | 4 | Flat Washer | 61-E-05 |
| 40 | 1 | Motor (Standard Electrical, 208-240v/60hz/3ph) Call for Part Number of other electrical | P4-923-0004 |
| 50 | 1 | Sheave (60 HZ) | P4-951-0004 |
| | | Sheave (50 HZ) | P4-951-0009 |
| 52 | 2 | V-Belt | P4-951-0010 |
| 70 | 2 | Side Panel Sub-Assembly | A4-436-0046 |
| 80 | 1 | Rear Panel Sub-Assembly | A4-436-0047 |
| 120 | 1 | Front Canopy | C4-151-0005 |
| 130 | 1 | Rear Canopy | C4-151-0006 |


36-Part Divider Head Assembly Schematic



36-Part Divider Head Assembly Parts

| Item | Qty. | Description | Part Number |
|------|------|----------------------------------|-----------------------------|
| 1 | 1 | 36-Part Divider | B4-141-0012 |
| 7 | 1 | Divider Plate, 36 & 18 - Part | C4-147-0061 |
| 8 | 4 | Fil. Hd. Slotted Mach. Screw | 25-E-0406 |
| 9 | 1 | Keeper | A4-109-0006 |
| 10 | 2 | Flat Hd. Phillips Mach. Screw | 22-E-0405 |
| 11 | 1 | Plug Plate, 36 & 18 - Part | B4-147-0063 |
| 12 | 36 | Stems for Plug | A4-054-0004 |
| 13 | 4 | Inside Plug, 36-Part | A4-139-0015 |
| 14 | 12 | Intermediate Plug, 36-Part | A4-139-0016 |
| 15 | 20 | Outside Plug, 36-Part | A4-139-0017 |
| 16 | 36 | Hex Hd. Washer Type Cap Screw | A4-033-0012 |
| 17 | 1 | Cover Plate, 36 & 18 - Part | B4-147-0064 |
| 18 | 6 | Flat Hd. Ph. Mach. Screw | 22-E-0406 |
| 19 | 2 | Handle | P4-939-0010 |
| 20 | 4 | Flat Hd. Slotted Mach Screw | 21-E-0206 |
| | 2 | 36-Part Dough Pallet (Not Shown) | C4-150-0003 |


18-Part Divider Head Assembly Schematic



18-Part Divider Head Assembly Parts

| Item | Qty. | Description | Part Number |
|------|------|----------------------------------|-----------------------------|
| 1 | 1 | 18-Part Divider | B4-141-0013 |
| 6 | 1 | Divider Plate, 36 & 18 - Part | C4-147-0061 |
| 7 | 4 | Fil. Hd. Slotted Mach. Screw | 25-E-0406 |
| 8 | 1 | Keeper | A4-109-0006 |
| 9 | 2 | Flat Head Phillips Mach. Screw | 22-E-0405 |
| 10 | 1 | Plug Plate, 36 & 18 - Part | B4-147-0063 |
| 11 | 36 | Stems for Plug | A4-054-0004 |
| 12 | 2 | Inside Plug, 18-Part | A4-139-0012 |
| 13 | 6 | Intermediate Plug, 18-Part | A4-139-0013 |
| 14 | 10 | Outside Plug, 18-Part | A4-139-0014 |
| 15 | 36 | Hex Hd. Washer Type Cap Screw | A4-033-0012 |
| 16 | 1 | Cover Plate, 36 & 18 - Part | B4-147-0064 |
| 17 | 6 | Flat Hd. Ph. Mach. Screw | 22-E-0406 |
| 18 | 2 | Handle | P4-939-0010 |
| 19 | 4 | Flat Hd. Slotted Mach Screw | 21-E-0206 |
| | 2 | 18-Part Dough Pallet (Not Shown) | C4-150-0002 |


9-Part Divider Head Assembly Schematic



9-Part Divider Head Assembly Parts

| Item | Qty. | Description | Part Number |
|------|------|---------------------------------|-----------------------------|
| 1 | 1 | 9-Part Divider | B4-141-0014 |
| 3 | 1 | Divider Plate, 9 - Part | C4-147-0057 |
| 4 | 4 | Fil. Hd. Slotted Mach. Screw | 25-E-0406 |
| 5 | 1 | Keeper | A4-109-0006 |
| 6 | 2 | Flat Head Phillips Mach. Screw | 22-E-0405 |
| 7 | 1 | Plug Plate, 9 - Part | B4-147-0059 |
| 8 | 28 | Stems for Plug | A4-054-0004 |
| 9 | 1 | Inside Plug, 9 - Part | A4-139-0018 |
| 10 | 8 | Outside Plug, 9 - Part | A4-139-0019 |
| 11 | 28 | Hex Hd. Washer Type Cap Screw | A4-033-0012 |
| 12 | 1 | Cover Plate, 9 - Part | B4-147-0060 |
| 13 | 6 | Flat Hd. Ph. Mach. Screw | 22-E-0406 |
| 14 | 2 | Handle | P4-939-0010 |
| 15 | 4 | Flat Hd. Slotted Mach Screw | 21-E-0206 |
| | 2 | 9-Part Dough Pallet (Not Shown) | C4-150-0001 |

6-Part Divider Head Assembly Schematic



6-Part Divider Head Assembly Parts

| Item | Qty. | Description | Part Number |
|------|------|---------------------------------|-----------------------------|
| 1 | 1 | 6-Part Divider | B4-141-0015 |
| 3 | 1 | Divider Plate, 6-Part | C4-147-0065 |
| 4 | 3 | Fil. Hd. Slotted Mach. Screw | 25-E-0406 |
| 5 | 1 | Keeper | A4-109-0006 |
| 6 | 2 | Flat Hd. Phillips Mach. Screw | 22-E-0405 |
| 7 | 1 | Plug Plate, 6-Part | B4-147-0067 |
| 8 | 19 | Stems for Plugs | A4-054-0004 |
| 9 | 1 | Inside Plug, 6-Part | A4-139-0020 |
| 10 | 5 | Outside Plug, 6-Part | A4-139-0021 |
| 11 | 19 | Hex Hd. Washer Type Cap Screw | A4-033-0012 |
| 12 | 1 | Cover Plate, 6-Part | B4-147-0068 |
| 13 | 6 | Flat Hd. Ph. Mach. Screw | 22-E-0406 |
| 14 | 2 | Handle | P4-939-0010 |
| 15 | 4 | Flat Hd. Slotted Mach. Screw | 21-E-0004 |
| | 2 | 6-Part Dough Pallet (not shown) | C4-150-0004 |

3-Phase Electrical Schematic

To be connected to:


208-240V/ 60HZ / 3-Phase - 10 Amp Supply

- or -

460V / 60 HZ / 3-Phase - 6 Amp Supply

IF PROTECTED BY FUSES, USE TIME DELAY TYPE

CIRCIUT MUST BE PROTECTED




1-Phase Electrical Schematic

To be connected to: 120V/ 60HZ / 1-Phase - 15 Amp Supply

IF PROTECTED BY FUSES, USE TIME DELAY TYPE


CIRCIUT MUST BE PROTECTED



To be connected to: 240V/ 60HZ / 1-Phase - 10 Amp Supply









IF PROTECTED BY FUSES, USE TIME DELAY TYPE

CIRCIUT MUST BE PROTECTED



Safety Labels

Good safety practice dictates labeling hazards properly.
If you require more labels, the following are available for purchase at a nominal price.



10. (Not Shown) Head Removal an Installation Instructions Decal

**Thank you for choosing the
"Made in the USA"
Dutchess Model JN
Semi-Auto Dough Divider/Rounder**

Our staff at Dutchess is dedicated to doing everything possible to reassure you that in making the decision to buy an American Made product you have purchased the highest quality, most dependable divider/rounder available anywhere in the world.

**For solutions to product quality and results,
just give us a call and our professional
Customer Service staff will be glad to assist you.**

**For your convenience, please contact us on our
Toll Free Customer Service Hotline:
1-800-777-4498.**

**Sincerely,
Your Friends at Dutchess**

**AMERICAN BUILT QUALITY
~~ Since 1886 ~~
AFL ~ CIO
"Serving" the Food Service Industry Worldwide**