



HOSHIZAKI

www.hoshizakiamerica.com

**SERVICE MANUAL
FOR MODEL RM-26**

REQUIRED TOOLS



CORDLESS DRILL DRIVE



CUTTING TUBING



OPEN WRENCH OF 1/2"



RATCHET WITH SOCKET OF
7/16"



SCREWDRIVER SET WITH
SOCKET OF 9/32"



WISE GRIP



PIERCING VALVE



WATCHER SLOTTED
SCREWDRIVER



REQUIRED EQUIPMENT



OXIACETYLENE
EQUIPMENT



DRY NITROGEN
EQUIPMENT



VACUUM PUMP WITH
MICRON GAUGE



MANIFOLD PRESSURE
GAUGES



LEAK DETECTOR



REFRIGERANT RECOVERY
MACHINE



CONTENTS

- Instructions to replace LED Power Supply.
- Instructions to replace high intensity LED flexible strip.
- Instructions to replace interior LED strips lights.
- Instructions to replace condenser fan motor.
- Instructions to replace evaporator fan motor.
- Instructions to replace electronic thermostat.
- Instructions to replace thermostat ambient sensor.
- Instructions to replace starting relay, overload protector and starting capacitor.
- Instructions to replace compressor.
- Instructions to replace door.



DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace LED Power Supply.



1. Unscrew the two screws that hold in place the top of the header sign , using a Phillips screwdriver # 2



2. Pull out the top of the header sign.



3. Grab the acrylic sign and pull it out.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace LED Power Supply.



4. In order to remove the Power Supply, unscrew the two screws that hold it in place using a Phillips screwdriver # 2.

5. Disconnect the electrical connector of the Power Supply

6. To install the new Power Supply reverse the previous steps.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE


Instructions to Replace High Intensity LED Flexible Strips .



1. Unscrew the two screws that hold in place the top of the header sign , using a Phillips screwdriver # 2



2. Pull out the top of the header sign.



3. Grab the acrylic sign and pull it out.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace High Intensity LED Flexible Strips .



4. Disconnect the electrical connector of LED strip Light.



5. Remove the high intensity LED flexible strip by pulling it out from its base. Repeat this step to remove the other high intensity LED flexible strip.



6. To install the new high intensity LED flexible strip, reverse the previous steps.



DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace LED Strips .



1. Remove the LED profile cover of breaker strip using a slotted screwdriver.

2. Disconnect the electrical connector of LED strip light.

3. Use a slotted screwdriver to pull out the LED strip.

4. To install the new LED strip reverse the previous steps.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Condenser Fan Motor



1. Unscrew the four screws that hold in place the front grill , using a Phillips screwdriver # 2



2. Pull out the front grill.



3. Disconnect the Tyco electrical connector of the condensing unit.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Condenser Fan Motor



4. Remove the two bolts that hold in place the rails using a 1/2" open wrench, these rails support the condensing unit.



5. Pull out the condensing unit from the base of the cabinet.



6. The condensing unit can be removed all the way out for easier service.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Condenser Fan Motor



7. Disconnect the Tyco electrical connector of the condenser fan motor.



8. Unscrew the two screws that hold in place the base motor to the rails using a Phillips screwdriver # 2



9. Remove the condenser fan by pulling it out



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Condenser Fan Motor



10. Remove the bolt that hold in place the fan blade to the fan motor using a 9/32" socket screwdriver.



11. Unscrew. the two screws that hold in place the base motor to the fan motor using a 9/32" socket screwdriver.



12. To install the new condenser fan motor reverse the previous steps.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace the Evaporator Fan Motor.



1. Unscrew the four screws that hold in place the fan guard on the air baffle using a Phillips screwdriver # 2.



2. Remove the bolt that hold in place the fan blade to the fan motor using a 9/32" socket screwdriver.



3. Unscrew the four screws that hold in place the support base motor to the top of cabinet using a Phillips screwdriver # 2.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace the Evaporator Fan Motor.



4. Disconnect the Tyco electrical connector of the evaporator fan motor located in the top of cabinet.



5. Unscrew the three screws that hold in place the support base motor to the fan motor chassis using a 9/32" socket screwdriver .



6. To install the new evaporator fan motor reverse the previous steps.



DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace The Electronic Thermostat.



1. Remove the front frame of the thermostat using your fingers.



2. Turn 90° both screws to loosen their cams and the front panel will detach. Then, proceed to remove the thermostat from the panel, by keeping it horizontally.



3. Disconnect the connectors located in the back of thermostat. .



4. To install the new electronic thermostat reverse the previous steps.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to replace Ambient Sensor.




1. Remove the front frame of the thermostat using your fingers.



2. Turn 90° both screws to loosen their cams and the front panel will detach. Then, proceed to remove the thermostat from the panel, by keeping it horizontally.



3. Disconnect the connector of the ambient sensor located on the back of the thermostat, shown in the picture.





4. Unscrew the two screws that hold the wires in place of the ambient sensor using a precision flat blade slotted screwdriver.



DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to replace Ambient Sensor.



5. Unscrew the two screws that hold in place the light switch support plate on the baffle using a Phillips screwdriver # 2 .

6. Pull out the ambient sensor from its plastic clip support.

7. Use masking tape to splice the damaged ambient sensor with the new. This operation will serve as guide to remove the damage sensor and connect the new to the connector of thermostat.

8. Pull both ambient sensors through the cut out of display . Once the splice be visible, remove the tape and damage sensor and connect the new and reverse the previous steps to install the thermostat.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instruction to Replace Starting Relay, Overload Protector and Starting Capacitor.



1. Unscrew the four screws that hold in place the front grill , using a Phillips screwdriver # 2



2. Pull out the front grill.



3. Disconnect the Tyco electrical connector of condensing unit.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instruction to Replace Starting Relay, Overload Protector and Starting Capacitor.



4. Remove the two bolts that hold in place the rails using a 1/2" open wrench, these rails support the condensing unit.



5. Pull out the condensing unit from the base of the cabinet.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instruction to Replace Relay, Overload Protector and Starting Capacitor.



6. The condensing unit can be removed all the way out for easier service.



7. Insert a flat screwdriver in the slot of the plastic electrical box to remove it from the compressor. Use the flat screwdriver as a pry bar to push the box downward.



8. At the same time that the plastic electric box is being pushed downward with the slotted screwdriver, hold the box with the other hand and pull it out downward.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instruction to Replace Starting Relay, Overload Protector and Starting Capacitor.

LOCATION OF ELECTRICAL CONNECTIONS

Relay

Start Relay wire connections


Overload protector

Overload protector wires connection

Ground wire .

Starting capacitor wires connections


Starting Capacitor



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instruction to Replace Starting Relay, Overload Protector and Starting Capacitor.



9. First disconnect the two black wires connecting the starting capacitor and the blue color wire of the start relay. Then use a slotted screwdriver as a pry bar to pull out the relay / overload protector assembly from the compressor shell.



10. To install the new relay / overload protector assembly reverse the previous steps.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instruction to Replace Starting Relay, Overload Protector and Starting Capacitor.



11. Use a slotted screwdriver as a pry bar to remove the starting capacitor from its base: The base of the capacitor is attached to the top of the electrical plastic box.



12. Use a slotted screwdriver as a pry bar to disconnect the terminals of the starting capacitor.

To install the new starting capacitor reverse the previous steps.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Compressor



1. Unscrew the four screws that hold in place the front grill , using a Phillips screwdriver # 2



2. Pull out the front grill.



3. Disconnect the Tyco electrical connector of condensing unit.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Compressor



4. Remove the two bolts that hold in place the rails using a 1/2" open wrench, these rails support the condensing unit.



5. Pull out the condensing unit from the base of the cabinet.




6. The condensing unit can be removed all the way out for easier service.




HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Compressor



7. Insert a flat screwdriver in the slot of the plastic electrical box to remove it from the compressor. Use the flat screwdriver as a pry bar to push the box downward.



8. At the same time that the plastic electric box is being pushed downward with the slotted screwdriver, hold the box with the other hand and pull it out downward.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Compressor



9. The first step is to recover all refrigerant from the system by installing a piercing valve in the compressor service tube.



10. Attach the hose of the recovery machine to the service tubing. Use an Allen Key Wrench to close the piercing valve for piercing the tube and open it to release the refrigerant.



11. Open Manifold Gauge Pressure valves and turn on the recovery machine to recover all the refrigerant.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Compressor



12. Separate the discharge tubing from the compressor evaporation tray.



13. Use a knife to cut the double sided tape that holds in place evaporator tray pan on the compressor.



14. Warm the brazing of the discharge and suction tubes in order to unsolder them from the compressor.



15. To remove the filter dryer, slowly warm up the joint of the capillary tubing with the filter dryer and pull them apart by using pliers.



16. Remove the four clips, pins and washers that secure the compressor to the base rails.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Compressor



17. Remove the compressor from the base rails.



18. Not all compressor removal requires cleaning the low and high sides of the system. However, if you suspect that there are high levels of contamination, sweep the system using dry nitrogen at 250 psig.



19. Place the new compressor on the base rails



20. Insert the four clips, pins and washers in the base of the compressor to hold it in place to the base rails.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Compressor




21. Proceed to braze the service, discharge and suction tubing.



22. Place double sided tape in the compressor evaporation tray pan and fix it over the compressor applying slight pressure. Accommodate the discharge tubing into the evaporation tray pan.



23. Follow slides # 21 through # 24 to install the relay, overload protector and starting capacitor.



24. Braze the filter to the condenser discharge line and to the capillary tubing. Do not over heat the body of the filter and take great care not to block the capillary tubes with solder material. The filter dryer must be installed in a vertical position with the capillary tube inlet at the bottom of the filter.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Compressor – Vacuum & Charging the System.



25. Use the Piercing Valve already installed in the service tube of the compressor.
Proceed with the evacuation and charging process of the system. . Attach the hoses of the manifold gauge to the vacuum pumps


26. Turn on the vacuum pump to start evacuating the system. This should take up to 20 minutes for the micron gauge to reach 200 microns or less. Once this level has been reached, continue to vacuum for an additional 10 minutes to assure that non-condensable gases have been removed. Then, close the manifold gauge valves.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions to Replace Compressor – Vacuum & Charging the System.



27. After the vacuum process has been finished, close the valves of the manifold gauges and proceed to connect the hose from the refrigerant tank to the service line of the manifold. Open the low pressure valve as well as the tank valve to charge the refrigerant. Inject the amount specified in the serial name plate of R-134a refrigerant into the refrigeration system.

Wait until the pressure readings of the system have equalized and then turn on the cooler.



28. Unplug the cooler. Pinch the service tubes using a vise pinch and proceed to remove the manifold gauges and piercing valve. Check for refrigerant leaks using a leak detector.

NOTE: To avoid leaks that may originate from Schrader Valves when installed for service in the future, proceed to pinch off the tubing using a vise grip and braze it with oxyacetylene welding. Check for refrigerant leaks using a leak detector in all the soldered joints.



HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions for Replacing the Door.



1. Unscrew the four screws that hold in place the front grill , using a Phillips screwdriver # 2



2. Pull out the front grill.



3. Use a cordless drill drive with a Phillips bit # 3 to remove the three bolts that hold in place the lower hinge .




HOSHIZAKI

DISCONNECT UNIT FROM POWER SUPPLY BEFORE DOING ANY SERVICE

Instructions for Replacing the Door.



4. To remove the door, pull it downward from the upper hinge.



5. To install the new door reverse the previous steps..



HOSHIZAKI

HOSHIZAKI AMERICA, INC.

618 Hwy. 74 South, Peachtree City, GA 30269 USA

(P) 770.487.2331 (F) 770.487.3360

www.hoshizakiamerica.com