

# Manitowoc® ICE MACHINES

## INSTALLATION INSTRUCTIONS

**MODELS:**  
GR-0200A  
GR-0201W  
GD-0202A  
GD-0203W  
GY-0204A  
GY-0205W

This product qualifies for the following listings:



KEEP THESE INSTRUCTIONS WITH THE OWNER/OPERATOR USE AND CARE GUIDE FOR FUTURE REFERENCE

### GENERAL SAFETY PRECAUTIONS

The ice machine must be installed according to these Installation Instructions.

Connection to water service, drains, electrical service and grounding must comply with applicable local and state codes.

Disconnect electrical service before servicing.

Read and understand all instructions before placing the ice machine into service.

### GENERAL

The installation instructions are provided to assist the qualified installer. Check the yellow pages of your local telephone book for Manitowoc Ice Machine Distributor, or call Manitowoc Ice, Inc. for information regarding installation and start-up services available.

If any problem is encountered that is not covered by this manual, please contact your local Manitowoc Distributor or Manitowoc Ice, Inc. for assistance.


### TABLE OF CONTENTS

General Safety Precautions	1
General	1
Dimensions	2
Specifications	3
Freight Damage and Claims Procedures	3
Unpacking Cartons	4
Location of Ice Machine	4
Ice Machine Heat of Rejection	4
Mounting Single Ice Machine on Storage Bin	4
Mounting Two Ice Machines on Storage Bin	5
Electrical Service	5
Voltage	5
Fuse/Circuit Breaker	5
Minimum Circuit Ampacity	5
Connection at Ice Machine	6
Water Service/Drains	7
Water Supply	7
Inlet Water Connections	8
Drain Connections	8
Water-Cooled Models (Cooling Tower Applications)	8
Installation Check List	9
Before Starting Ice Machine	9



# DIMENSIONS

ml/3282.008/00



BIN MODEL	DIMENSION A	DIMENSION B
C170	28.25"	19.06"
C400	34.00"	31.37"
C470	29.50"	50.50"
C570	34.00"	50.50"

BASE DRAIN  
CENTERED IN  
BOTTOM OF BIN  
(C400, C470, C570)

REAR BIN DRAIN  
MODEL C170 ONLY

## SPECIFICATIONS

<b>DIMENSIONS</b>		<b>ELECTRICAL REQUIREMENTS (Cont.)</b>	
Length	23.50 in.	Fuse/Circuit Breaker	
Width	30.00 in.	Air-Cooled	20 amp
Height	16.50 in.	Water-Cooled	15 amp
<b>ELECTRICAL REQUIREMENTS</b>		<b>WATER REQUIREMENTS</b>	
Voltage	115 volts	Temperature	
Hertz	60 Hertz	Minimum	33°F
Phases	1 phase	Maximum	90°F
Circuit Ampacity (Minimum)		Pressure	
Air-Cooled	11.5 amp	Minimum	20 psi
Water-Cooled	9.8 amp	Maximum	80 psi

## FREIGHT DAMAGE AND CLAIMS PROCEDURES

### 1. SHORTAGES

Check number of cartons delivered against the quantity shown on your receipt. If quantities do not tally, have driver note shortage and file your claim with the freight company.

### 2. NO-FAULT FREIGHT CLAIM PROCEDURE

Manitowoc assumes responsibility for all freight damage claims involving participating carriers with the following exceptions:

- a. When the trucking company loses the equipment.
- b. When fire destroys the equipment en route.
- c. When a traffic accident damages the shipment en route.

### 3. VISIBLE DAMAGE

- a. If cartons appear damaged in any way, open the carton and inspect contents in the presence of the driver.

- b. To remove the ice machine carton, cut the banding on the bottom only (in case the ice machine needs to be reboxed) and slide the carton up and off the ice machine.
- c. Note the nature and extent of the damage on the freight bill.
- d. Notify your local Manitowoc distributor to inspect the merchandise within 15 days of delivery. Do not attempt to repair the damage.

### 4. CONCEALED DAMAGE

- a. If damage is noticed at the time of installation, notify the distributor immediately and ask to have the equipment inspected.
- b. Do not destroy packing materials until inspection is completed.
- c. These conditions must be met before your claim can be processed by the distributor.

### 5. CLAIMS

Manitowoc Ice, Inc. and the selling Distributor will arrange to repair or replace the equipment.

## UNPACKING CARTONS

1. ICE MACHINE
  - a. Cut bottom band on the carton.
  - b. Lift the carton up and off of the ice machine.
2. STORAGE BIN
  - a. Cut the banding on the top of the carton.
  - b. Remove carton top.
  - c. Remove the cardboard packing inside and place on the floor.
  - d. Tip the carton on its back and slide the bin out onto the cardboard packing to protect the bin from being scratched.
  - e. Screw the leveling legs onto the bottom of the bin and screw the "foot" of each leg in as far as possible, Figure 1. Set the bin upright.




FIGURE 1. LEG INSTALLATION

## LOCATION OF ICE MACHINE

### CAUTION

We do not recommend that this ice machine be installed in an area where the air temperature falls below 35°F or exceeds 110°F. If the ice machine will be subjected to below freezing temperatures, it must be protected. See REMOVAL FROM SERVICE/WINTERIZATION in the Owner/Operator Use and Care Guide.

Select a location away from heat generating equipment and direct sunlight. Manitowoc ice machines operate most efficiently when:

- LOCATED IN A CONTAMINANT-FREE AREA — Air-cooled models especially should be installed in an area that is free of air-borne contaminants. An accumulation of contaminants on the condenser will adversely affect ice production.
- INSTALLED WITH A MINIMUM OF FIVE INCHES OF CLEARANCE AT SIDES AND REAR — Adequate air flow through and around the ice machine is essential to maximum ice production and long component parts life.

## ICE MACHINE HEAT REJECTION

Ice machines, like other refrigeration equipment, reject heat through the condenser. It is helpful to know the amount of heat rejected to accurately size air conditioning equipment when self-contained air-cooled ice machines are installed in air conditioned environments. **This heat rejection information is also necessary to evaluate the benefits of using water-cooled or remote condensers to reduce air conditioning loads.** The amount of heat added to an air conditioned environment by an ice machine using a water-cooled or remote condenser is negligible. Knowing the amount of heat rejected is also important when sizing a cooling tower for a water-cooled condenser unit.

### Series 200 Heat Rejection (BTU/Hour)


Air Conditioning	Peak
*4,500	**5,700

\* Because the heat of rejection varies during the ice making cycle, the figure shown is an average.

\*\* Peak figure is to be used for sizing cooling towers.

## MOUNTING SINGLE ICE MACHINE ON STORAGE BIN

1. Move the bin into final position.
2. Level the bin to assure bin door closes and seals properly. Turn the "foot" of the appropriate leg(s) to level bin. Use level on bin top, Figure 2.



**FIGURE 2. LEG ADJUSTMENT**

3. Set the ice machine on the bin, aligning the sides and back of the ice machine with the sides and back of the bin. Take care not to tear or dislodge the mounting gasket.
4. Loosen two screws holding front panel in place and remove front panel.
5. Carefully remove tape holding instructions envelope (and air baffle — air-cooled models only) to water curtain. Install air baffle per instructions on baffle.

**MOUNTING TWO ICE MACHINES ON STORAGE BIN**

A K00056 stacking kit is required for stacking two G200 ice machines. Installation instructions are supplied with the kit.

**NOTE**

The G200 ice machine can be stacked with other models of Manitowoc ice machines and on a variety of Manitowoc bins. Consult your Manitowoc dealer or distributor for more information.

**ELECTRICAL SERVICE (Figure 3)**

**CAUTION**

All wiring must conform to local, state and national codes.

**Voltage — 115V, 60 Hertz, 1 Phase**

Provide a separate fused circuit for each ice machine. The maximum allowable voltage variation is  $\pm 10\%$  of the rated voltage at ice machine start-up (when the electrical load is highest).

**WARNING**

This ice machine requires a ground that meets the National and Local Electrical Code regulations.

**Fuse/Circuit Breaker**

Air-Cooled	20A
Water-Cooled	15A

Provide a separate fuse/circuit breaker for each ice machine. Circuit breakers must be H.A.C.R. rated (does not apply in Canada).

**Minimum Circuit Ampacity**

Air-Cooled	11.5A
Water-Cooled	9.8A


The minimum circuit ampacity is used to help select the wire size of the electrical supply. (It is not the ice machine's running amps.) The wire size, or gauge, is also dependent upon location, materials used, length of run, etc., and therefore must be determined by a qualified electrician.

### Connection at Ice Machine


A 1-1/16 inch electrical entrance is provided for routing electrical conduit.

#### CAUTION

The accompanying diagram is not intended to show proper wire routing, wire sizing, disconnects, etc., only the correct wire connections. **All electrical connections and routing must conform to local and national codes.**



**FIGURE 3. 115V, 1 PHASE, 60 Hz WIRING**



**FIGURE 4. WATER SERVICE DRAINS**

**WATER SERVICE/DRAINS (Figure 4)**

**CAUTION**  
Plumbing must conform to local and state codes.

**Water Supply**

Local water conditions may require the installation of water treatment devices in the ice making water supply line.

If water treatment systems such as deionization, reverse osmosis, or distillation are to be used, contact your Manitowoc distributor for instructions.

**Temperature:** minimum 33°F, maximum 90°F.

**IMPORTANT**

The ice machine must not be connected to a hot water supply. Be sure all hot water restrictors (check valves) installed for other equipment (sink faucets, dishwashers, etc.) are in working order.

**Ice making water pressure:** minimum 20 psi, maximum 80 psi.

If water pressure exceeds maximum psi, obtain a water pressure regulator from your Manitowoc distributor.

**Condenser pressure (water-cooled models):** minimum 20 psi, maximum 150 psi.

### **Inlet Water Connections**

**Ice making water:** 3/8 inch F.P.T.

**Condenser (water-cooled models):** 3/8 inch F.P.T.

Install a shut-off valve for both the ice making and condenser water lines. All water lines should be insulated to prevent condensation.

The ice making water supply is connected to a 3/8 inch female pipe fitting in the rear panel. Use 3/8 inch O.D. tubing.

The condenser water supply is connected to a 3/8 inch female pipe fitting in the rear panel. Use a minimum of 1/2 inch O.D. tubing up to the 3/8 inch fitting.

### **Drain Connections**

**Ice making water drain:** 1/2 inch F.P.T.

**Condenser drain (water-cooled models only):** 1/2 inch F.P.T.

**Bin drain:** 3/4 inch F.P.T.

Use the following guidelines to prevent backflow of drain water into the ice machine and storage bin.

- Drain lines must have 1-1/2 inch drop per 5 feet of run and must not create any traps.
- The floor drain must be sized to accommodate drainage from all drains.
- Run the bin and ice machine drain lines separately and insulate to prevent condensation.
- The ice machine drain lines require a minimum of 1/2 inch I.D. tubing.
- The bin drain line requires a minimum of 3/4 inch I.D. tubing.

- The ice making water drain and bin drain must be vented to the atmosphere. Do not vent condenser drain (water-cooled models).


### **Water-Cooled Models (Cooling Tower Applications)**

A water-cooling tower installation does not require modification to the ice machine; the water regulator valve for the condenser continues to control the refrigeration discharge pressure. It is necessary to know the amount of heat rejection (see page 4) and the pressure drop through the condenser and water valve (inlet and outlet of the ice machine) to apply these types of systems to the ice machine.

- Water entering the condenser must not exceed 90°F.
- Water flow through the condenser must not exceed 5 GPM.
- Allow for a pressure drop of 7 psi between the condenser water inlet and outlet of the ice machine.
- Condenser water exiting temperature must not exceed 110°F.

## INSTALLATION CHECK LIST

- Is ice machine level?
- Has all the internal packing been removed?
- Have all the electrical and water connections been completed?
- Has the supply voltage been tested and checked against the rating on the nameplate?
- Is there a minimum of 5 inches clearance around the ice machine for proper air circulation?
- Has air baffle been installed on air-cooled models?
- Is the ice machine installed where ambient temperatures will not vary below 35°F or above 110°F? Incoming water temperature range 33°F/90°F? (See Owner/Operator Use and Care Guide for winterizing.)
- Is there a separate drain for the water-cooled condenser?
- Are ice machine and bin drains vented?
- Are all electrical leads free from contact with refrigeration lines and moving components?
- Has filter screen in float valve been cleaned? See Figure 5.
- Has owner/operator been instructed regarding maintenance procedures and the use of Manitowoc Cleaner and Sanitizer?
- Has owner/operator completed the warranty registration card?
- Has Owner/Operator Use and Care Guide been left with owner/operator?
- Was bin and ice machine sanitized?



**FIGURE 5. CLEANING FLOAT VALVE FILTER SCREEN**

## BEFORE STARTING ICE MACHINE

All Manitowoc Ice Machines are factory operated and adjusted before shipment. Normally no adjustments are necessary for new installation.

To ensure proper operation, follow the OPERATIONAL CHECK in the Owner/Operator Use and Care Guide.

Starting the ice machine and completing OPERATIONAL CHECK is the responsibility of the owner/installer. Adjustments and maintenance as outlined in the Owner/Operator Use and Care Guide are not covered by warranty.





**MANITOWOC ICE, INC.**

2110 South 26th Street P.O. Box 1720

Manitowoc, WI 54221-1720

Phone: (920) 682-0161

Fax: (920) 683-7585

**Web Site:** [www.manitowocice.com](http://www.manitowocice.com)

© 1999 Manitowoc Ice, Inc.  
Litho in U.S.A.