


Service Manual

Applicable Models	Model No.
SO-BD386WE-UT	22031010000120
UL-BD386WE-SQ	22031010000112
UL-BD386WE-FQ	22031010000107



(The picture is only for reference, and specific appearance and configuration are subject to the real product)

Prepared by	R&D:Zheng Qiang
Reviewed by	QA:Wang Tao SVC:Zhang Kun
Approved by	R&D:Geng Xiuhua SVC:Guang Taoshuai



Important Safety Notice

The Maintenance Manual is only for the use of maintenance personnel with certain experience and background in electrical, electronic and mechanical field.

Any attempt to repair main devices may lead to personal injury and property loss.

Manufacturers or distributors are not responsible for the content of the Manual and interpretation thereof.

Midea Refrigerators

Technical Maintenance Manual

Copyright @2016

All rights reserved. Replication of all or part of the Manual in any forms shall not be allowed without written approval by the Overseas Sales Corporation of Midea Refrigerators.

Contents


1.SAFETY WARNING CODE.....	5
1.1 WARNING FOR OPERATION SAFETY	5
1.2 SAFETY INSTRUCTION FOR REFRIGERANT	8
2.DESRIPTION FOR PRODUCT FEATURES	9
3.INSTALLATION AND COMMISSIONING.....	10
3.1 HANDLING	10
3.2 DISASSEMBLY (NONE)	10
3.3 INSTALLATION LOCATION	10
3.4 LEVELING OF THE REFRIGERATOR	10
3.5 CHANGE THE DOOR OPENING DIRECTION(NONE)	11
3.6 INSTALLATION OF HANDLE	11
3.7 INSTALLATION OF DOOR LOCK(NONE).....	12
3.8 ADJUSTMENT TO LEVEL THE DOOR(NONE).....	12
3.9 ADJUSTMENT TO SHELVES(NONE).....	12
4.TERMS	12
4.1 DEFINITION OF MODEL(NONE)	12
4.2 LOCATION OF NAMEPLATE	12
5.PRODUCT SPECIFICATION	13
5.1 TYPE SPECIFICATION(NONE)	13
5.2 ELECTRICAL PARAMETERS	13
5.3 INSIDE TEMPERATURE	13
5.4 DEFROSTING PARTS.....	14
5.5 CIRCUIT DIAGRAM	14
6.INTERNAL VIEW AND DIMENSION	16
6.1 MAIN PARTS AND THEIR NAMES	16
6.2 EXTERNAL DIMENSION.....	16
7.REFRIGERATING PIPING SYSTEM AND CIRCULATING ROUTE OF COOLING AIR.....	19
7.1 REFRIGERATING PIPING SYSTEM.....	19
7.2 CIRCULATING ROUTE OF COOLING AIR	20
8. DISMANTLING OF PARTS	21
8.1 PARTS ON THE DOOR.....	21
8.2 PARTS INSIDE THE REFRIGERATOR	21
8.3 LIGHT SYSTEM.....	21
8.4 AIR DUCT AND FAN MOTOR	22
8.5 EVAPORATOR AND TEMPERATURE SENSING SYSTEM.....	23
8.6 COMPRESSOR CASE.....	24

8.7	DISPLAY AND MAIN CONTROL PANEL	26
8.8	BAR COUNTER(NONE).....	26
8.9	WATER DISPENSER(NONE)	26
8.10	ICE MAKER(NONE).....	27
9.	FUNCTION AND OPERATION	28
9.1	OPERATION PANEL	28
9.2	BUTTON	28
9.3	DISPLAY SCREEN.....	28
9.4	DISPLAY.....	28
9.5	SETTING OF THE GEAR.....	29
9.6	CONTROL OF STANDBY FUNCTION(NONE).....	29
9.7	CONTROL OF ICE MAKER (NONE)	29
9.8	FAULT CODE AND SOLUTIONS	29
9.9	DEFROSTING FUNCTION	30
9.10	TEST MODE	30
9.11	SELF-DIAGNOSIS	30
10.	CIRCUIT DESCRIPTION.....	31
10.1	POWER SUPPLY	31
10.2	DOOR TRIP TEST CIRCUIT	31
10.3	TEMPERATURE TEST CIRCUIT	31
10.4	FAN MOTOR CIRCUIT OF THE FREEZING CHAMBER.....	32
10.5	REFRIGERATOR FAN MOTOR CIRCUIT (NONE).....	33
10.6	CONDENSING FAN MOTOR CIRCUIT (NONE).....	33
10.7	DAMPER MOTOR CIRCUIT (NONE).....	33
10.8	RESISTANCE VALUE OF THE SENSOR (R/T)	33
11.	TROUBLESHOOTING METHOD.....	34
11.1	NO REFRIGERATION.....	34
11.2	COMPRESSOR FAILURE	35
11.3	DEFROSTING IS NOT WORKING	36
11.4	FAN IN THE FREEZING CHAMBER IS ABNORMAL	36
11.5	DAMPER IS ABNORMAL(NONE)	37
11.6	LIGHTS INSIDE THE REFRIGERATOR DON'T LIGHT UP	37
12.	FIGURES AND DETAILS OF REPAIR PARTS(DOCUMENTS ARE PROVIDED SEPARATELY)	37
12.1	FIGURE.....	37
12.2	LIST OF PARTS AND COMPONENTS	37
13	APPENDIX:	37
13.1	ELECTRICAL SCHEMATIC DIAGRAM.....	37
13.2	REFRIGERATOR MAINTENANCE TOOLING AND EQUIPMENT AND MATERIAL.....	38

1. Safety Warning Code

1.1 Warning for operation safety

Important Safety Instructions



This symbol indicates that dangerous voltage constituting a risk of electric shock is present within your freezer.



This symbol indicates that there are important operating and maintenance instructions in the literature accompanying your freezer.

WARNING

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings.
- 4 Follow all instructions.
- 5 Do not use this appliance near water.
- 6 Clean only with a damp cloth.
- 7 Do not block any ventilation openings.
- 8 Install in accordance with the manufacturer's instructions.
- 9 Do not install near any heat sources, such as radiators, heat registers, stoves, or other apparatus that produce heat.
- 10 Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 11 Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the appliance.
- 12 Do not attempt to modify or extend the power cord of this appliance.
- 13 Unplug this appliance during lightning storms or when it will not be used for long periods of time.
- 14 Make sure that the available AC power matches the voltage requirements of this appliance.

- 15 Do not handle the plug with wet hands. This could result in an electric shock.
- 16 Unplug the power cord by holding the plug, never by pulling the cord.
- 17 Do not turn the appliance on or off by plugging or unplugging the power cord.
- 18 Refer all servicing to qualified service personnel. Servicing is required when the appliance has been damaged in any way, such as the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the appliance, the appliance has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 19 To reduce the risk of fire or electric shock, do not expose this appliance to rain, moisture, dripping, or splashing, and no objects filled with liquids should be placed on top of it.
- 20 Do not use extension cords or ungrounded (two prong) adapters.
- 21 This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 22 Children should be supervised to ensure that they do not play with the appliance.
- 23 If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified person, in order to avoid a hazard.
- 24 Take off the doors and leave the shelves in place so that children may not easily climb inside.



WARNING

Electric Shock Hazard

Failure to follow these instructions can result in electric shock, fire, or death.

- 1 **WARNING**—Keep ventilation openings, in both the freezer and the built-in structure, clear of obstruction.
- 2 **WARNING**—Do not touch the interior of the freezer with wet hands. This could result in frost bite.
- 3 **WARNING**—Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- 4 **WARNING**—Do not damage the refrigerant circuit.

- 5 **WARNING**—Do not damage the refrigerant tubing when handling, moving, or using the freezer.
- 6 **WARNING–DANGER**—Never allow children to play with, operate, or crawl inside the freezer.
Risk of child entrapment. Before you throw away your old freezer:
 - 1) Take off the doors
 - 2) Leave the shelves in place so that children may not easily climb inside
- 7 Unplug the freezer before carrying out user maintenance on it.
- 8 This freezer can be used by children age eight years and older and persons with reduced physical or mental capabilities or lack of experience and knowledge if they are given supervision or instruction concerning the use of the freezer in a safe way and understand the hazards involved. Children should not play with the freezer. Cleaning and maintenance should not be performed by children without supervision.
- 9 If a component part is damaged, it must be replaced by the manufacturer, its service agent, or similar qualified persons in order to avoid a hazard.
- 10 Please dispose of the freezer according to local regulations as the freezer contains flammable gas and refrigerant.
- 11 Follow local regulations regarding disposal of the freezer due to flammable refrigerant and gas. All refrigeration products contain refrigerants, which under the guidelines of federal law must be removed before disposal. It is the consumer's responsibility to comply with federal and local regulations when disposing of this product.
- 12 This freezer is intended to be used in household and similar environments.
- 13 Do not store or use gasoline or any flammable liquids inside or in the vicinity of this freezer.
- 14 Do not use extension cords or ungrounded (two-prong) adapters with this freezer. If the power cord is too short, have a qualified electrician install an outlet near the freezer. Use of an extension cord can negatively affect the freezer's performance.

Grounding requirement

This freezer must be grounded. This freezer is equipped with a cord having a grounding wire with a grounding plug. The plug must be inserted into an outlet that is properly installed and grounded.

Improper use of the grounding plug can result in a risk of electric shock. Consult a qualified electrician or service person if the grounding instructions are not completely understood, or if doubt exists as to whether the freezer is properly grounded.

1.2 Safety instruction for refrigerant

⚠ WARNING  **Explosion Hazard.**


Keep flammable materials and vapors, such as gasoline, away from freezer. Failure to do so can result in fire, explosion, or death.

DANGER—Risk of Fire or Explosion. Flammable Refrigerant Used. To Be Repaired Only By Trained Service Personnel. Do Not Use Mechanical Devices. Do Not Puncture Refrigerant Tubing.
CAUTION—Risk of Fire or Explosion. Flammable Refrigerant Used. Consult Repair Manual/Owner's Guide Before Attempting To Service This Product. All Safety Precautions Must be Followed.
CAUTION—Risk of Fire or Explosion. Dispose of Properly In Accordance With Federal Or Local Regulations. Flammable Refrigerant Used.
CAUTION—Risk of Fire or Explosion Due To Puncture Of Refrigerant Tubing; Follow Handling Instructions Carefully. Flammable Refrigerant Used.



2. Description for product features

This product is provided with following features:



(The picture is only for reference, and specific appearance and configuration are subject to the real product)

- 1) Full air-cooling and frost-free design
- 2) Electronic temperature control system with more accurate temperature control.
- 3) Open delay alarm function

3. Installation and commissioning

3.1 Handling

- 1) Protect the refrigerator in moving it. Same as shown as left photo, please move it by hand cart with the cushion.
- 2) Remove all packing materials and bottom cushion, then move into house for placement.
- 3) After moving it to appropriate location, wait for 2 hours before power on.




3.2 Disassembly (None)

The refrigerator door needs to be dismantled if it cannot enter the room in the whole.


3.3 Installation location

Location that is easy for ventilation shall be chosen to facilitate heat dissipation, enhance its performance and reduce the energy consumption.



3.4 Leveling of the refrigerator


If the refrigerator cannot be placed steadily, adjust the footing to level it.



3.5 Change the door opening direction(None)

3.6 Installation of handle

Note: Figures in the user manual are only for reference. The actual product may differ slightly.
The refrigerator must be disconnected from the source of electrical supply before attempting the installation of accessory.



①take out the two crisscross-screw;and install them into the door holes;
turn the screws till to the bottom;

②aim at screws to install the handle;

③install the screws at the side of the handle and turn the screws till them
very tight.

NOTE:the screws and wrench are in the plastic bag.

3.7 Installation of door lock(None)


3.8 Adjustment to level the door(None)

3.9 Adjustment to shelves(None)

4.Terms

4.1 Definition of model(None)

4.2 Location of nameplate




(The picture is only for reference, and specific appearance and configuration are subject to the real product)

5. Product specification

5.1 typespecification(None)

5.2 Electrical parameters

Product Name			SO-BD386WE-UT	UL-BD386WE-SQ	UL-BD386WE-FQ
Product Code			22031010000120	22031010000112	22031010000107
Name	Item	Type	Specification	Specification	Specification
Compressor	Compressor	/	PE50H1F-4SVL	EE50H1C	HYE60Y42
	Starter	PTC	8EA19C3/QP2-15/ QP2-15	QPE2-A4R7MD3	QP2-4R7
	Overload protector	OLP	3TM166TF2/DRB 18T61A1	DRB31T61A1	DRB33S61A1
	Winding resistance of compressor wiring terminal		Rmc:10-20Ω Rsc:30-50Ω Rms=Rmc+Rsc	Rmc:10-20Ω Rsc:30-50Ω Rms=Rmc+Rsc	Rmc: 10~20Ω Rsc: 30~50Ω Rms=Rmc+Rsc
	Variable frequency driver board	/	/	/	/
Motor	Fan motor of the freezing chamber		DC12V/≤4W	DC12V/≤4W	DC12V/≤4W
	Ventilation door of the refrigerating chamber	/	/	/	
	Condensation fan	/	/	/	
Lights inside the refrigerator	Lights inside the freezing chamber		240V/40W	125V /40W	125V /40W
	Lights inside the refrigerating chamber	/	/	/	/
	Switch of the refrigerator door	mechanical switch	sector	sector	sector

5.3 Inside temperature


Temperature tolerance ≤ 2 °C


Compartment	The highest (°C)	Lowest (°C)
Freezing	-24	-26
Refrigerating	/	/
Variable temperature	/	/

5.4 Defrosting parts

Defrosting period	Initial defrosting period	Normal defrosting period
		Temperature is lower than 0 °C
Defrosting sensor	NTC	B3839
Thermal fuse	Can't be restored	77°C
Defrosting heater in freezing chamber	Steel pipe	230V/180W
		115V/180W


5.5 Circuit diagram





6. Internal view and dimension

6.1 Main parts and their names





(The picture is only for reference, and specific appearance and configuration are subject to the real product)

Freezing chamber	Refrigerator chamber
1. Air duct front plate 2. Steel wire storage rack (big) 3. Air duct assembly of freezer 4. Steel wire storage rack (small) 5. Steel wire drawer 6. Leveling feet	7. Freezer door tray 8. Reversible adjustable shelf 9. Refrigerator door tray

6.2 External dimension

Front view	Side view
------------	-----------






(The picture is only for reference, and specific appearance and configuration are subject to the real product)

7. Refrigerating piping system and circulating route of cooling air


7.1 Refrigerating piping system

1 Compressor → 2 Right condenser → 3 Anti-condensation tube → 4 Left condenser → 5 Dry filter → 6 Capillary tube → 7 Evaporator → 8 Suction tube → 1 Compressor



(The picture is only for reference, and specific appearance and configuration are subject to the real product)



7.2 Circulating route of cooling air




(The picture is only for reference, and specific appearance and configuration are subject to the real product)

8. Dismantling of parts

8.1 Parts on the door



Door seal	
<p>Door seal is installed into door liner groove.</p> <p>1) Open the refrigerator door;</p> <p>2) Take the door seal ① out of door liner;</p>	
Door tray	
<p>Lift up the bottle frame and take it out from the door liner of the refrigerator.</p>	
rollover beam	None

8.2 Parts inside the refrigerator


Shelves	
<p>1) Pull out the partition plate completely.</p> <p>2) Lift it up and take it out from the refrigerator.</p>	
Ice tray	None
Refrigerator tray	None
Drawer	None


8.3 Light system

Light



<p>Light of the refrigerating chamber is located upper chamber</p> <ol style="list-style-type: none"> 1) Remove the lamp cover 2) Remove the bulb 	
<p>Light switch</p>	
<p>There is a light switch on the side wall of the refrigerating chamber.</p> <ol style="list-style-type: none"> 1) Loosen the hook with small normal screwdriver and pull out the switch until the wire connector reveals. 	





8.4 Air duct and fan motor

<p>Air duct components in freezing chamber</p>	
<p>All accessories in the freezing chamber should be dismantled before removing the air duct components.</p> <ol style="list-style-type: none"> 1) Remove 2 screws on the cover plate of the freezing air duct using a cross screwdriver; 2) Pull out the connector terminal of the fan motor; 	
<p>Fan motor</p>	

<ol style="list-style-type: none"> 1) Remove the fixed tape on the surface of motor 2) Hold the corner, and dismantle the motor from one side(without plastic clips) 3) Remove the sealing washer by force 4) Separate the fan motor and fin blade(pull by force) 5) Change the motor, the reverse operation is for assembly 	
<p>Damper assembly</p>	<p>None</p>


8.5 Evaporator and temperature sensing system

<p>Evaporator in freezing chamber</p>	
<ol style="list-style-type: none"> 1) Remove the air duct components in freezing chamber. 2) Disconnect all connectors. 3) Remove the welding on inlet and outlet tubes. 4) Remove two screws which are used to fix the evaporator and remove the evaporator. 	
<p>Components on the evaporator</p>	
<p>Fuse The fuse is located on top of the evaporator</p> <ol style="list-style-type: none"> 1) connect the fuse connector. 2) Cut off the band which fixes the fuse. 3) Separate the fuse and the evaporator. <p>*,Don't break the welding of the evaporator in case that only the fuse needs to be replaced.</p>	

<p>Defrost sensor</p> <p>The defrost sensor is located on top of the evaporator.</p> <ol style="list-style-type: none"> 1) Disconnect the connector of defrost sensor 2) Cut off the band which fixes the sensor. 3) Separate the sensor and the evaporator. <p>*,Don't break the welding of the evaporator in case that only the sensor needs to be replaced.</p>	
<p>Defrost heater</p> <p>The defrost heater is located at bottom of the evaporator.</p> <ol style="list-style-type: none"> 1) Disconnect the connector of defrost heater. 2) Cut off the band which fixes the defrost heater. 3) Take off the defrost heater from the evaporator. <p>*,Don't break the welding of the evaporator in case that only the defrost heater needs to be replaced.</p>	
<p>Ambient temperature sensor</p>	
<p>Ambient temperature sensor</p>	<p>None</p>
<p>Ambient temperature sensor</p>	<p>None</p>
<p>The ambient temperature sensor is placed in the display panel, it send the signal to the MPU</p>	
<p>Freezer sensor</p>	
<p>Freezer temperature sensor is placed in the upper position of air duct cover</p>	

8.6 Compressor case

Rear cover and compressor case	None
Condenser fan moto	None
Terminal box of the compressor	None
Standby condenser	None
Piping system in the compressor case	



anti-condensation pipe
right condenser outlet of
anti-condensation pipe
dry filter
Suction pipe assembly

transition pipe
left condenser
anti-condensation pipe
discharge and evaporating pipe

Starter and protector of the compressor

1. Remove the screws

- 1) Two screws outside
- 2) One screw inside



2. Remove the clipping strip


Slowly pull it out





3. Remove the protective cover

- 1) Pry the protective cover slowly from the upper part,
- 2) Pull it out and remove it.



<p>4. Remove the starter and protector Unplug the starter and protector (you can use a screwdriver to pry it slowly)</p>	
<p>5. The reverse process can complete installation.</p>	<p>/</p>

8.7 Display and main control panel

<p>Display</p>	
<p>1) use slotted screwdriver to prize up the display PCB assembly slightly, to get the display PCB assembly 2) use cross screwdriver to remove the 4 pcs screws, to dismantle the display PCB 3) Unplug the wiring connector, change the display PCB, the reverse operation is for assembly</p>	
<p>main control panel</p>	
<p>1) Use cross screwdriver to remove the 2 screws, to get the main PCB assembly 2) Use slotted screwdriver to prize up the cover of main PCB box slightly 3) Use cross screwdriver remove the 1 pc screw of main PCB, and dismantle the main PCB 4) Unplug the wiring connector, change the main PCB, the reverse operation is for assembly</p>	

8.8 Bar counter(None)

Disassembly and installation of bar counter	None
Disassembly and installation bar doorseal	None

8.9 Water dispenser(None)

Disassembly and installation of water valve	None
Disassembly and installation of water tank	None

8.10 Ice maker(None)

Disassembly and installation of ice maker	None
Disassembly and installation of water system	None
Disassembly and installation ice machine sensor	None

9. Function and operation

9.1 Operation panel



9.2 Button

- A Quick Freeze button
- B. Switch button of Fahrenheit display and Centigrade display
- C. Cancellation button of alarm
- D. Lock/Unlock button
- E. Temperature adjustment button (warmer)
- F. Temperature adjustment button(Colder)

9.3 Display screen

1. Freezer/Refrigerator temperature display zone
2. Indicated lamp of door open alarm
3. Indicated lamp of high temperature alarm

9.4 Display

·when power on the refrigerator, the display panel lightens for 3 seconds, and the start-up tone rings at same time, if it is the 1st time to power on the refrigerator, the default temperature setting is -18°C

·Normal display

Digital display zone: if there is any failure happen, it will display the error code, if no, it displays the setting temperature,

·Display control(normal working mode, inspection mode)

If in locked status, the display panel will darken if there is no any operation on control panel for 30 seconds, any operation on control panel will wake up the display panel.

If there is failure happen, and there is corresponding error code related to this failure, the error code will

display for 30 seconds, then darken.

9.5 Setting of the gear

9.5.1 Lock and unlock

In unlocked status, press the button(LOCK/UNLOCK) for 3S,to enter into the locked status

In locked status, press the button(LOCK/UNLOCK) for 3S,to enter into the unlocked status

Note: All below operations must be in unlock status

9.5.2 Switch between Fahrenheit and Centigrade

When it displays Centigrade, press the switch button($^{\circ}\text{C}/^{\circ}\text{F}$),it will be switched to Fahrenheit display

When it displays Fahrenheit, press the switch button($^{\circ}\text{C}/^{\circ}\text{F}$),it will be switched to Centigrade display

9.5.3 Temperature setting and the switch between refrigerator and freezer Press temperature adjustment button(E&F) to set the temperature, during the setting ,the temperature digit will blink, the temperature setting range $-14\sim-22^{\circ}\text{C}$ (not change circularly); it will quit setting status and take effect with the setting till the digit blink for 10 seconds.(it also can take effect manually if press the Lock/Unlock(D) button after temperature setting)

9.5.4 Quick freeze function

1. Entry condition:

If the refrigerator works as a freezer, press Quick Freeze button to enter into quick freeze mode, the temperature digit displays -24°C or -11°F

2. working process

During working in quick freeze mode, the compressor switch on, the default time is 6 hours

3. Exit condition

1.The quick freeze mode will exit automatically after works for 6 hours or 48 hours

2. Press quick freeze button to exit quick freeze mode

3. when operate the temperature adjustment button, the quick freeze mode will exit

If the quick freeze mode exit, the product will work according to last temperature setting

9.6 Control of standby function(None)

9.7 Control of ice maker (None)

9.8 Fault code and solutions

Fault code	Fault content	Error Code	Steps for maintenance methods
E2	Freezer temperature sensor fail	E2	Step 1: to check whether the CN4 wiring connector connect well, unplug and plug in again; Step2: to check whether there is foreign object on the wiring connector of sensor, unplug the connector by referring to chapter 8.5, and check the Ohmic value by comparing with the resistance sheet Step3: change the main PCB Step4: Change the wiring harness
E5	Defrosting sensor fail	E5	Step 1: to check whether the CN4 wiring connector connect well, unplug and plug in again; Step2: to check whether there is foreign object on the wiring connector of sensor, unplug the connector by referring to chapter 8.5, and check the Ohmic value by comparing with the resistance sheet Step3: change the main PCB Step4: Change the wiring harness
E6	Ambient temperature	E6	Step1: to check whether the whether the wiring harness connected well

	sensor fail		Step2:change the main PCB Step3:change the display PCB
E9	F room high temp alarm	E9	Check the temperature of F room and check whether the door seal fan motor and compressor of F room operate normally

9.9 Defrosting function

1. Defrost the freezing chamber as per the accumulative operation time of the Compressor
 2. If power failure occurs abruptly to the Compressor and the defrosting sensor in freezing chamber is less than 0°C after powering on, then first conduct defrosting once. If more than 0°C, then defrosting is not needed.
 3. After that, conduct defrosting according to using condition and ambient temperature in a period between 6 and 24 hours as per the accumulative operation time of the Compressor.

9.10 Test mode

Mandatory Defrost

1) enter into

Press the button both “^” and “v” for 3 seconds, it will enter into mandatory defrost, the display panel will display figure “3”

If the defrosting sensor failure happen, the heater will work 20 minutes, then turn off. If the defrosting sensor failure happen during the defrosting, the heater only work 3 minutes after that, then turn off

2) Exit

★ exit manually: under the state of mandatory defrost, press both button both “^” and “v” for 3 seconds, it will exit the mandatory defrost after 3 minutes

★ Exit automatically : defrost for 3 minutes ,then judge the exiting condition for exiting.

3) working state, same as the normal defrosting

9.11 Self-diagnosis

Entry condition

With 3 seconds after power on, if there is no sensor failure and the actual measured temperature $\geq 0^{\circ}\text{C}$, it will enter into self-diagnosis


Process of Self-diagnosis

1. Switch on the defrosting heater for 5 seconds, then switch off for 5 seconds
2. Switch on the fan motor for 5 seconds, then switch off for 5 seconds
3. turn on the fan motor and compressor at same time
4. it will exit the self-diagnosis after 20 minutes.

If there is sensor failure happen, it will exit the Self-diagnosis immediately


10. Circuit description

10.1 Power Supply



AC input power will be treated by transformer ,and rectified when through D1~D4,then filtered by E1 capacitor .it will output stable DC12V after through there terminal regulator 7812, DC12V is for provide power to relay(control strong electricity), the relay is for control the on-off of compressor, and the defrosting heater. DC12V will be changed into DV5V after through modifier 7805, 5V is for provide power to main PCB , main PCB monitors the status of inside temperature.


10.2 Door trip test circuit



Current of strong electricity of lamp will be output onto terminal of weak curnnet side by PC817 opto-isolator, then reduced voltage by R10,and rectified by D7 and D8. When door is opened , the circuit of switch is closed, and the PWM wave is detected by the terminal of weak current, and main PCB receive the signal. When door is closed, the circuit of switch is open, no wave is detected, and main PCB judge it as the signal of door closed

10.3 Temperature test circuit

It's conducted by the sensor, making use of the characteristics that resistance value reduces as the temperature increases, and the thermistor that has temperature coefficient of resistance in medium temperature.




The characteristic that resistance value reduces as the temperature increases is deemed to have negative slope or negative temperature coefficient (NTC), and such thermistor is called as NTC thermistor. The resistance value changes sensitively with temperature and typically changes 7% ~ 3% per degree centigrade. Sensor used in the refrigerator is NTC thermistor.

There is following computing formula for the sensor: Sampling voltage / reference voltage = $R1 / (R_{NTC} + R1)$

$$AD \text{ value} / \text{reference AD value} = R1 / (R_{NTC} + R1)$$

The reference voltage is 5V, RNTC is the resistance value of the sensor, R1 is R31\R32\R33 in schematic diagram that is 5.1K

10.4 Fan motor circuit of the freezing chamber




The fan in the freezing chamber is running when the compressor is operating. Check 12V and FAN to see if there is a voltage of 12V. When in normal operation, the fan is in low level and the voltage between 12V and FAN is more than 11V. If there is no voltage when the compressor is in operation, fan motor or electric control panel can be replaced.

10.5 Refrigerator fan motor circuit (None)
10.6 Condensing fan motor circuit (None)
10.7 Damper motor circuit (None)
10.8 Resistance value of the sensor (R/T)

T _x (°C)	R (KΩ)	T _x (°C)	R (KΩ)	T _x (°C)	R (KΩ)	T _x (°C)	R (KΩ)	T _x (°C)	R (KΩ)
-30	33.81	-15	14.31	0	6.495	15	3.141	30	1.617
-29	31.85	-14	13.55	1	6.175	16	2.999	31	1.55
-28	30.01	-13	12.83	2	5.873	17	2.865	32	1.486
-27	28.29	-12	12.16	3	5.587	18	2.737	33	1.426
-26	26.68	-11	11.52	4	5.315	19	2.616	34	1.368
-25	25.17	-10	10.92	5	5.06	20	2.501	35	1.312
-24	23.76	-9	10.35	6	4.818	21	2.391	36	1.259
-23	22.43	-8	9.82	7	4.589	22	2.287	37	1.209
-22	21.18	-7	9.316	8	4.372	23	2.188	38	1.161
-21	20.01	-6	8.841	9	4.167	24	2.094	39	1.115
-20	18.9	-5	8.392	10	3.972	25	2.005	40	1.071
-19	17.87	-4	7.968	11	3.788	26	1.919	41	1.029
-18	16.9	-3	7.568	12	3.613	27	1.838	42	0.9885
-17	15.98	-2	7.19	13	3.447	28	1.761	43	0.9506
-16	15.12	-1	6.833	14	3.29	29	1.687	44	0.914


11. Troubleshooting Method

11.1 No refrigeration




11.2 Compressor failure

No working of compressor




11.3 Defrosting is not working

Inside frosting, no defrosting




11.4 Fan in the freezing chamber is abnormal



Refer to this method for other fans.

11.5 Damper is abnormal(None)

11.6 Lights inside the refrigerator don't light up



12. Figures and details of repair parts(Documents are provided separately)


12.1 Figure

12.2 List of parts and components

13Appendix:




13.1Electrical Schematic Diagram








(Model:***)



13.2refrigerator maintenance tooling and equipment and material







Tooling

No.	Name	Photo	Main Usage
1	Phillips screwdriver		screw assemble and disassemble
2	slotted screwdriver/scraper		screw and rivet assemble and disassemble
3	Socket spanner 5/16"		hinge and compressor screw assemble and disassemble

4	Sucker		display panel and air duct cover disassemble
5	Allen wrench (2.8~4mm)		handle assemble and disassemble
6	Vise grip pliers		sealing process tube
7	Pipe cutter		pipe cutting
8	Knife		assistive tool
9	Nipper pliers		assistive tool
10	Capillary tube scissors		Shear capillary






Equipment

No.	Name	Photo	Main Usage
-----	------	-------	------------

1	Vacuum pump		vacuum pumping
2	Electronic scale		weighing refrigerant/gas
3	High pressure nitrogen with piezometer		pipe and cooling system(condenser, evaporator, etc) impurities clean
4	Soldering gun		heating and welding
5	Quick coupling		connection process pipeline,vacuum or charge refrigerant will be used.
6	hand leak detector		welding point leakage detect, if no, use soap-suds

material

No.	Name	Photo	Main Usage
-----	------	-------	------------

1	Process pipeline		Charge therefrigerant
2	Dry filter		Involving a system failure to be replaced
3	Copper welding rod		tube welding
4	Refrigerant/gas		Add refrigerant to the system
5	Sealing tape		door fixing for reversible door option

Midea Refrigerators

If you need to get detailed technical information from the manufacturer, please contact:

xxx@midea.com

Refrigeration Division

Overseas Sales Company

Address: No. 176, Jinxiu Avenue, Economic-Technological Development Area, Hefei, Anhui, China