



NOTICE:

The information contained on the following page(s) was produced prior to May 1, 2014. On that date Reznor became part of Nortek, Inc.

References to any other company affiliations are no longer valid.

This manual refers to Reznor brand products that have been discontinued for more than 10 years. Some replacement parts may no longer be available from our suppliers. Compatible parts may be substituted.

Please contact your Reznor Representative with specific questions.



Indoor or Outdoor, Gas, Direct-Fired, Makeup Air/Heating Systems

**Operation/Maintenance/Service
Form RZ-NA O-DV/RDF/ADF**

Obsoletes Form RZ-NA 440-OMS, 441-OMS, and 442-OMS

REZNOR[®] Thomas & Betts

Applies to: Models DV, RDF, and ADF/ADFH

Index	Page
Air Pressure	4
Air Pressure Switches	10
Blower Bearings	3
Burner	4, 11
Circuit Indicator Board	4
Control Locations	8
Damper Motor	19
Direct-Fired Burner	11
Dirty Filter Switch	19
Door Switch	17
Drive Components	2
Electronic Circuit Board with Diagnostic Lights	8
Emergency Cut Off	9
Evaporative Cooling Module	5
Filters	3
Firestat	20
Freezestat	20
Gas Control Systems	11
Gas Pressure	3
Gas Pressure Switches	17
Ignition System	11
Inlet Air Controls	17
Limit Control	9
Maintenance Schedule	2
Maintenance Section	2-7
Maintenance/Service Access	2
Manifold Arrangements	16
Operation/Service Section	8-24
Outside Air Cutoff Control	17
Photoelectric Smoke Detector	20
Photohelic Pressure Sensor	19
Pilot Assembly	4
Potentiometer	19
Pressure Null Switch	19
Sensing Pressure Check	10
Troubleshooting	21
Wiring Diagram - In the main electrical box on the unit	

**KEEP THIS BOOKLET FOR
MAINTENANCE AND
SERVICE REFERENCE.**

FOR YOUR SAFETY
WARNING: The use and storage of gasoline or other flammable vapors and liquids in the vicinity of this appliance is hazardous.

FOR YOUR SAFETY
If you smell gas:
1. Open windows.
2. Don't touch electrical switches.
3. Extinguish any open flame.
4. Immediately call your gas supplier.

WARNING: Improper installation, adjustment, alteration, service, or maintenance can cause property damage, injury or death. Read the installation, operation, and maintenance instructions thoroughly before installing or servicing this equipment.

WARNING: On makeup air heaters which also recirculate room air, outside ventilation air must be provided in accordance with the information shown on the heater rating plate.

Recirculation of room air may be hazardous in the presence of:
(a) Flammable solids, liquids, and gases;
(b) Explosive materials (e.g. grain dust, coal dust, gun powder, etc.); or
(c) Substances which may become toxic when exposed to heat (e.g. refrigerants, aerosols, etc.).

References:
Installation Manuals:
 Model DV, Form RZ-NA I-DV
 Model RDF, Form RZ-NA I-RDF
 Model ADF(H), Form RZ-NA I-ADF
Replacement Parts Manual:
 Form RZ-NA P-DV/RDF/ADF
 or Form 740 for RDF; Form 741 for DV, and Form 742 for ADF/ADFH

Operating/Maintenance/Service

The information in this manual applies to Model Series DV, RDF, and ADF direct-fired heating/makeup air systems. As with any gas burning equipment, regular maintenance procedures are required to ensure continued safety, reliability and efficiency of the installation.

If service is required, this system should be serviced only by a qualified service person. Service information in this booklet is intended as a guideline for a qualified gas-fired equipment service person.

DANGER: The gas burner in this direct gas-fired system is designed and equipped to provide safe, controlled complete combustion. However, if the installation does not permit the burner to receive the proper supply of combustion air, complete combustion may not occur. The result is incomplete combustion which produces carbon monoxide, a poisonous gas that can cause death.

Always comply with the combustion air requirements in the installation codes and operating instructions. The amount of air over the burner must be within the specified range. The burner profile plates are set at the factory to match CFM requirements. Do not adjust the burner profile plates without contacting the factory. **FAILURE TO PROVIDE PROPER COMBUSTION AIR CAN RESULT IN A HEALTH HAZARD WHICH CAN CAUSE PROPERTY DAMAGE, SERIOUS INJURY, AND/OR DEATH.** Direct-fired installations should provide for air changes as required by the applicable installation codes.

MAINTENANCE SECTION

This direct-fired makeup air system is designed to require only a minimum amount of maintenance. Some maintenance procedures outlined in this Section require inspection only and some require action. Frequency requirements of each maintenance procedure are listed in the Maintenance Schedule. Depending on the environment and the number of operating hours, more frequent inspection and/or cleaning may be required to certain components.

Although maintenance requirements are minimal, the routine maintenance procedures in this Section are necessary to ensure safe, reliable, and/or efficient operation. The paragraphs which follow discuss the components and systems that require routine inspection/maintenance. At the beginning of each paragraph, there is a code indicating why that maintenance procedure is necessary. The legend for that code is shown on the left.

Maintenance Codes

S	= Safety (to avoid personal injury and/or property damage)
R	= Continued Reliability
E	= Efficient Operation

WARNING: Disconnect all power to the system before doing any maintenance. Failure to do so may cause electrical shock, personal injury, or death.

Maintenance Schedule

See Chart	<input type="checkbox"/> Lubricate bearings, Paragraph 1
Quarterly	<input type="checkbox"/> Check the filters, Paragraph 2
	<input type="checkbox"/> Check air pressure sensing tubes, Paragraph 4
Semi-Annually	<input type="checkbox"/> Check blower belts, Paragraph 1
	<input type="checkbox"/> Verify gas pressures, Paragraph 3
	<input type="checkbox"/> Clean air pressure sensing tubes, Paragraph 4
Annually	<input type="checkbox"/> Check indicator lights, Paragraph 5
	<input type="checkbox"/> Check main burner and pilot assembly, Paragraph 6

R 1. Drive Components

The blower, motor and drive components are located in the blower cabinet. Remove the panels required to access the component(s) being serviced.

1A. Blower Bearings


All blowers are Class I with pillow block bearings. Clean the fitting and add type NLG-2 or -2 standard grade grease. Add grease with a handgun until a slight bead of grease forms at the seal. Be careful not to unseat the seal by over lubricating.

CAUTION: If the blower is unused for more than three months, the bearings should be purged with new grease prior to startup.

Recommended Bearing Lubrication Schedule in Months

RPM	Bearing Bore Diameter (Inches)			NOTE: If unusual environmental conditions exist (temperatures below 32°F or above 200°F; moisture; or contaminants) more frequent lubrication is required.
	1/2 to 1	>1 to 1-1/2	>1-1/2 to 1-15/16	
to 1000	6	6	6	
1001 - 1500	5	5	5	
1501 - 2000	5	4	5	

FIGURE 1 - Belt Tension



R E 2. Filters

Quantity and Size of Filters by Model

1B. Blower Belts

Check belts for proper tension and wear. Adjust belt tension as needed. Replace worn belts.

Proper belt tension is important to the long life of the belt and motor. A loose belt will cause wear and slippage. Too much tension will cause excessive motor and blower bearing wear. If adjustment is required, adjust belt tension by means of the adjusting screw on the motor base until the belt can be depressed 1/2" to 3/4" (FIGURE 1). Tighten the lock nut on the adjusting screw. Be sure the belt is aligned in the pulleys.


If the system includes filters, check the filters quarterly. Filters could be either in an optional filter cabinet (DV/RDF/ADF) or in the optional inlet base (DV). To access filters in a filter cabinet, remove the filter cabinet door panels. Clean or replace as needed. If removed, be sure to put blockoff plates in filter rack. If the filters are in the perimeter of the inlet base of a Model DV; they are two-inch permanent filters. Remove and clean the filters as needed.

Type	Disposable		Permanent		Pleated Disposable	
	1"	2"	1"	2"	1"	2"
Model RDF with Optional Filter Cabinet						
1	-	-	(3)12x35	(4)12x35	-	-
2	-	-	(4)12x35	(4)12x35	-	-
3	-	-	(4)12x24	(4)12x24	-	-
	-	-	(12)12x35	(10)12x35	-	-
Model ADF/ADFH with Optional Filter Cabinet						
300	(5)12x30-5/8	(5)12x30-5/8	(10)10x16	(10)10x16	(5)12x32	(5)12x32
500	(5)12x20	(5)12x20	(5)12x20	(5)12x20	(5)12x20	(5)12x20
	(5)12x25	(5)12x25	(5)12x25	(5)12x25	(5)12x26	(5)12x26
700, 1200	(5)12x25	(5)12x25	(5)12x25	(5)12x25	(5)12x25	(5)12x25
	(5)12x30-5/8	(5)12x30-5/8	(5)12x32	(5)12x32	(5)12x32	(5)12x32
Model DV with Optional Filter Section						
109, 112	-	(4)16x16	(4)16x16	(4)16x16	(4)16x16	(4)16x16
	-	(4)16x20	(4)16x20	(4)16x20	(4)16x20	(4)16x20
115, 118	-	(6)16x20	(6)16x20	(6)16x20	(6)16x20	(6)16x20
	-	(6)16x25	(6)16x25	(6)16x25	(6)16x25	(6)16x25
122, 125	-	(16)16x16	(16)16x16	(16)16x16	(16)16x16	(16)16x16
	-	(6)16x25	(6)16x25	(6)16x25	(6)16x25	(6)16x25
Model DV with Inlet Base with Filters						
109, 112	-	-	-	(8) 10x12	-	-
115, 118	-	-	-	(8)15x20	-	-
122, 125	-	-	-	(16)20x20	-	-

S 3. Manifold Gas Pressure

FIGURE 2 - Gas Pressure Tap Locations

Semiannually, check the gas pressure to the burner and to the pilot. Measure both manifold pressure and pilot supply pressure with the blower in operation. Verify against pressures listed on the rating plate.



MAINTENANCE SECTION (cont'd)

S 4. Air Pressure


Profile plate sensing tubes should be checked quarterly and cleaned no less than semiannually. If the sensing tubes become even partially blocked, false pressure readings may be relayed. To clean, remove the screened end caps. Clean the screens and the tubes, if necessary. Replace the cleaned end caps. Check the pressure differential across the profile plate using a slope gauge. Air pressure differential should be between $-.25''$ and $-.75''$ w.c.

To attach the slope gauge, open the control compartment door panel. Just below the junction box, locate the tubing connections. Remove the cap at each connection and attach the slope gauge using two field-supplied $1/4''$ x $1/8''$ female NPT barbed tubing connections. For instructions on measuring air pressure, see Service Section, Paragraph 9.

R 5. Circuit Indicator Board (check lights)

The circuit indicator board is located in the control compartment electrical box (See **FIGURE 7**). Check operation of all indicator lights by switching lights that are not lit with one that is currently lit. Replace any burned out indicator bulbs (P/N 125189).

FIGURE 3 - Circuit Indicator Board, P/N 151263



S 6. Main Burner and Pilot Assembly

CAUTION: Wear eye protection while pressure cleaning and drilling.

WARNING: Do not enlarge burner ports or performance may be drastically affected.

For the most part, the burner and pilot are self cleaning. However, if the application is extremely dirty or dusty, cleaning of the burner and pilot may be necessary. Inspect the burner annually. Follow these instructions. If it is necessary to replace any parts, use only factory-authorized replacements.

- 1) Turn off the gas and power supply to the system.
- 2) Remove the door panels in the burner/control cabinet. Locate the pilot.
- 3) Disconnect the two ignition wires (male and female quick connections) and disconnect the flame sensor lead at the burner. Remove the setscrew located in the ignitor tube (setscrew holds the brass bushing in place). Carefully remove the brass bushing and the ignitor. Check the hot surface ignitor for cracks or unusual deterioration. Check the flame rod for integrity. Replace the flame rod (P/N 131188) and/or the hot surface ignitor (P/N 121865) if not in good condition.
- 4) Clean the burner and pilot by back-flushing, using high pressure air (40-80 lbs). Continue until dust particles are completely expelled from both the upstream and downstream sides of the burner.


If air pressure does not unplug burner orifices or pilot tube, drill burner orifices with a Size #50 drill and/or pilot tube with a Size #55 drill.

Inspect the upstream and downstream sides of the mixing plates. Remove any accumulation of scale or foreign material with a wire brush. If any mixing plate fasteners are loose or missing, tighten or replace. Always use zinc plated or stainless fasteners.

If any cracks are present, replace that mixing plate. Because of the effect of flame temperature on the metal, fasteners may be difficult to remove. Be careful not to damage the gaskets that go between the mixing plates and the

FIGURE 4 - Burner End Plate showing Hot Surface Ignitor


NOTE: Model RDF units manufactured prior to 3/96 have a spark ignition system. Clean ultraviolet sensor and spark plug. Replace as needed.



burner body. The gaskets are designed to overlap approximately 1/16" for airtight seal.
5) Follow Steps in reverse order to re-install the pilot assembly. Close all panels and check for proper operation.

FIGURE 5 - Direct Fired Burner

WARNING: Burner profile plates are factory set to match CFM requirements. Do not adjust profile plates without contacting your Sales Representative for technical assistance.



R E

7. Optional Evaporative Cooling Module (ADF/ADFH only)

Media - Over time, excessive amounts of mineral deposits will begin to buildup on the media. Annually, scale and dirt should be washed off the entering surface of the media. Remove the pad retainers and screen. (See Steps 1-3 and 6-8 of Media Replacement Instructions.) Clean the media using a garden hose, mild soap, and a soft bristled brush. When the media becomes too clogged with mineral deposits and dirt that it cannot be cleaned, the pads should be replaced. The average pad life is approximately three cooling seasons.

Select the correct replacement part numbers and order media pads from your Distributor. Follow the instructions below and remove and replace pads as shown in **FIGURE 6**.

ADF/ADFH	Media Pad Sizes (inches)	Qty	Replacement Part No. (each)			
			Cellulose Fiber		Glass Fiber	
			6"	12"	6"	12"
300	24 x 12	2	105985	106021	106037	106029
	24 x 7-7/8	1	105986	106022	106038	106030
500	24 x 12	3	105985	106021	106037	106029
	24 x 9-5/8	1	105989	106025	106041	106033
700/1200	48 x 12	4	107190	107194	107199	107201
	48 x 8-5/8	1	107191	107195	107200	107202

Instructions for Replacing Evaporative Cooling Media

1. Remove the three sheetmetal screws that hold the top pad retainer in place. Release the top pad retainer from the cooling module.
2. Remove the three sheetmetal screws that hold the bottom pad retainer in place. Release bottom pad retainer from the cooling module.
3. Disengage the screen retainers from the sides of the media.
4. Disengage inlet screen from media pads and remove.
5. Slide all media pads horizontally away from the cooling module until clear of bottom reservoir pan. Dispose of properly.

MAINTENANCE SECTION (cont'd)

7. Optional Evaporative Cooling Module (ADF/ADFH only) (cont'd)

Instructions for Replacing Evaporative Cooling Media (cont'd)

6. Replace media by sliding media pads over both support rails until back stop is encountered. Media *must* be placed as shown in **FIGURE 7**.
7. Center screen on the incoming air side of the media.
8. Replace the two side screen retainers by fitting them between the side of the media pad and the side of the cooling module. The retainers should fit snugly, pinching the screen against the media pads.
9. Replace the bottom pad retainer by securing the retainer between the pad and the reservoir pan. Fasten with the three sheet metal screws removed in Step 2.
10. Replace the top pad retainer by securing the retainer between the pad and top of the cooling module. Fasten with the three sheet metal screws removed in Step 1.

FIGURE 6 - Removal and Replacement of Evaporative Cooling Module Media





FIGURE 7 - Media must be installed with 45° angle sloping downward toward the incoming outside air.

IMPORTANT: The media is made up of two different sheets of cooling material. Each sheet has its own unique angle. When replacing the cooling media, BE CERTAIN that the 45° angle slopes downward toward the incoming outside air (as illustrated above). If the media is not installed properly, water blowoff from the media pads will occur.



Other Evaporative Cooling Module Maintenance

Water Feed Line and PVC Distribution Piping - Annually, the water supply line and PVC water distribution pipe should be flushed of debris and contaminants.

1. Remove the media pads following the media replacement instructions.
2. Remove the water feed line from the downstream side of the ball valve and unscrew the water bleed line barbed hose fitting.
3. Force a fresh water supply through the water inlet hose and thoroughly flush the distribution pipe.
4. Reassemble being careful to install media with air flow direction as shown in **FIGURE 7**.


Water Pump and Inlet Basket Screen (applies to system with float and pump control) -- Annually, the pump and inlet basket screen should be removed, disassembled, and cleaned.

WARNING: Do not expose pump motor or any part of the electrical box to water. Evaporative cooling pump is NOT submersible.

1. Disconnect the power supply to the unit.

2. Remove the service panel and the junction box door. Disconnect the two-line voltage power supply wires from the terminal block inside the junction box.
3. Disconnect the water feed line hose from the upstream side of the ball valve.
4. Unscrew the four sheet metal screws holding the junction box to the cooling module. Remove the junction box-pump-float switch assembly (See Figure 8).
5. Dislodge the inlet basket screen from the pump and clean any buildup of debris and dirt. Carefully remove the base cover plate from the bottom of the pump. Using a mild soap solution, wash all deposits from the inside of the pump and remove all debris from the impeller.
6. Reassemble the pump. Replace the parts in exact reverse order, being careful that everything is returned to its proper position.

FIGURE 8 - Remove Junction Box, Pump, and Float Switch as an Assembly
(Actual assembly may not appear exactly as in the photo. Applies to evaporative cooling module with float and pump control system only.)



REFERENCE: Evaporative Cooling Module Troubleshooting Guide, Paragraph 20, page 23.


OPERATION/ SERVICE SECTION

Controls - Location, Operation, and Service

To service this system, it is necessary to understand the normal operation of the controls and the function of the diagnostic circuit board. Refer to the electrical box drawing in **FIGURE 9** and to the individual illustrations to identify and locate each of the controls. The wiring diagrams for this unit are located in the main electrical box.

WARNING: Service work on this system should only be done by a qualified gas service person. The service information and the troubleshooting guides are intended as an aid to a qualified service person.

FIGURE 9 - Control Identification and Typical Locations (Model DV is shown as an example)




NOTE: Wiring diagrams for the unit are located on the inside of the electrical box door.

8. Electronic Circuit Board with Lights

Location: Control Compartment Electrical Box (See **FIGURE 9**)

Function: The diagnostic lights on the circuit board are designed to assist in troubleshooting. When the system is operating properly, the lights on the circuit board are lit. If the system fails to operate properly, all lights on the circuit board up to that one that represents the component or system that has failed will be lit. For more detailed information, refer to the Troubleshooting Guide in Paragraph 19.

FIGURE 10 - Diagnostic Circuit Board, P/N 151263



Column of 13 indicator bulbs; always replace burned out bulbs, P/N 125189.

Control Switch Energized	●	Manual and Auto Limits Normal	●
Firestat Normal	●	Outside Air Cutoff Normal	●
Freezestat Normal	●	Low Gas Pressure Normal	●
Starter Energized	●	High Gas Pressure Normal	●
Blower ON - High Air Pressure Normal	●	Pilot Valve Energized	●
Blower ON - Low Air Pressure Normal	●	Gas Safety Valve Energized	●

Service: Replacing burned out bulbs is the only service required. If a bulb is not lit, check the bulb by switching it with a bulb that is lit.

9. Limit Safety Controls


Each unit has an automatic temperature activated limit control, a manual reset temperature activated limit control, and an electrical activated energy cutoff device.

• Automatic Reset Limit Control

Function: If the temperature of the discharge air reaches the setpoint, the limit will open the circuit to the burner system and close all burner and pilot valves. The limit control will be activated if total airflow is reduced or if gas pressure surges at the burner causing excessive discharge air temperature. The system will restart when the discharge air temperature decreases below the setpoint.

Service: Failure of this limit requires replacement of the control.

FIGURE 11 - Automatic Reset Limit Controls

	Model	P/N	Setting
	RDF	86979	135°F
	ADF	122856	130°F
	ADFH	57953	170°F
	DV	None	

• Manual Reset Limit Control

Function: The manual reset limit has a higher setting than the automatic limit and requires manual resetting to restart the system. If for any reason the automatic limit should fail to protect against overheating, the manual limit will shutdown the system. Should the manual reset limit activate, check the entire system to determine the cause. Make any necessary changes or adjustments before restarting the burner system. Restart of the unit can be done only after the limit has been cooled and the reset button depressed

CAUTION: If the manual reset limit activates, find and correct the cause before restarting the system.

Service: Failure of this limit requires replacement of the control.

FIGURE 12 - Manual Reset Limit Controls




<p>Model DV - Manual Reset Limit with Capillary, Size 109-122 Setting 190°F, P/N 161437; Size 125, 205°F, P/N 161433</p> 	<p>Model RDF - Setting 150°F, P/N 82610</p> <p>Reset Button</p> 	<p>Model ADF - Setting 135°F, P/N 122858; Model ADFH - Setting 170°F, P/N 57953</p> 
---	--	--

FIGURE 13 - ECO Limit Control



• Emergency Cut Off Limit Control

Function: The emergency cut off is a fusible link high temperature limit which provides onetime redundant protection against overheating. If the temperature sensitive limit controls malfunction, the electrically activated emergency cut-off will shutdown the system.

Service: If this limit activates, the manual limit control has failed and must be replaced. The cause for activating the emergency cut off limit control must be found and corrected before re-starting the system.

OPERATION/SERVICE SECTION (cont'd)

10. Air Pressure Switches

FIGURE 14 - Air Pressure Switch



Location: Control Compartment Electrical Box (See **FIGURE 7.**)

• Low Airflow Switch

Function: The low airflow switch is a velocity pressure switch that monitors airflow across the burner. Until the airflow attains adequate volume for combustion, the switch remains open. When the switch recognizes adequate air volume, it closes, permitting both the pilot and burner to operate. Low pressure switch is normally open; it closes on pressure rise at .25" w.c. Do not alter or adjust setting.

• High Airflow Switch

Function: The high airflow switch is a velocity pressure switch that monitors airflow across the burner. If the high airflow switch senses air velocity above the prescribed limit, it will shutdown gas flow to the burner. High pressure switch is normally closed; it opens when pressure rises above .75" w.c. Do not alter or adjust setting.

Low and High Airflow Sensing Pressure Check: (requires slope gauge, several feet of 1/4" OD tubing and two 1/4" OD barbed tees.)

Attach a slope gauge (0 to 1.0" scale) to the tubing connections in the control compartment. The two connections are located below the electrical control box. Remove the caps on the 1/8" NPT test connections and attach the slope gauge. (The recommended method for attaching the slope gauge is to use field-supplied 1/8" female NPT x 1/4" O.D. barbed hose connections.)

- A) If the system includes an optional discharge damper, before measuring burner differential air pressure, check to be sure that the damper is fully open.
- B) With the blower operating, the pressure differential on the slope gauge should read between -.25" and -.75" w.c. If the slope gauge reading is within those limits, no adjustments are necessary.
- C) When air pressure is within the proper range, turn the disconnect switch OFF. Disconnect the manometer and the slope gauge. Replace the caps removed to connect the slope gauge.


Pressure Switches and Bypass Damper Airflow (Applies to Model DV or Model RDF systems with Air Control Options AR19, AR20, AR22, AR23, AR32, AR33, AR34, AR36, or AR37)

Adjustment of the bypass damper is controlled by the same low and high pressure switches described above. With a bypass damper, the volume of outside air supplied to the building is controlled by a manually set potentiometer (Option AR19 and AR22) or automatically by a pressure null switch (Option AR20 or AR23), a photohelic pressure switch (Option AR36 or AR37), or a field-supplied computer signal (Option AR33 or AR34). With Options AR19, AR20, AR33, and AR36 the supply air is varied by adjusting the position of a damper at the blower discharge. With Options AR22, AR23, AR34, and AR37, a return air damper is adjusted to vary the volume of return air. The unit is arranged so that a fixed amount (20%) of the rated volume flows over the burner at a constant velocity. The remainder (80%) of the rated air volume flows either through a balancing bypass damper or a combination of bypass and return air dampers. As the supply air volume is varied by the return air or discharge damper, the balancing damper is adjusted to maintain the required air velocity over the burner. See Paragraph 14 for inlet air control options.

Service: If the pressure check determines that an airflow switch is not functioning properly, the switch cannot be serviced and must be replaced with an identical replacement. Low air pressure switch is P/N [203932](#); high air pressure switch is P/N [203933](#).


11. Ignition System

FIGURE 15 - Ignition Control Module in the Electrical Compartment, P/N 157953



Location: Ignition Controller Module in the Control Compartment Electrical Box (See FIGURES 9 and 15.); Ignitor and Flame Sensor on the Burner (See FIGURE 16.)

FIGURE 16 - Ignitor, P/N 121865, and Flame Sensor, P/N 134706, on the Burner



Hot Surface Ignition System with Prepurge Time Delay and Flame Sensor with 100% Lockout

Function: The ignition system including the controller, the hot surface ignitor, and the flame sensor function to ignite and prove the pilot flame. When there is a call for heat, the modular ignition controller is energized. When the controller reads 1.4 amps going to the hot surface ignitor, it opens the pilot valve for a 15-second trial for ignition. After the pilot flame rod senses pilot flame, the main gas valve is energized.

If the pilot flame rod does not sense a pilot flame, the controller shuts down the pilot valve for a 10-second interpurge and then opens it again for a second ignition trial. If pilot flame is not proven on the second trial, the ignition controller locks out and must be manually reset by an interruption of the main circuit (disconnect switch).

If the burner ordered is over three feet long (Model RDF with burner Option BL7, BL8, BL9, BL10, BL11, or BL13), a second flame rod is located at the end of the burner. After the main gas valve(s) is energized, a 15-second trial to prove the second flame is initiated. Failure to recognize and prove flame travel to the opposite end of the burner will result in a pre-purge and re-try for ignition.

Service: The modular ignition controller does an internal self-check each time that it is energized and will lockout if not found to be functioning properly. If the ignition controller locks out and there is no other cause, the controller module must be replaced.

12. Gas Train Including Direct-Fired Burner, Gas Control Systems, Manifold Arrangements, & Gas Pressure Switches

FIGURE 17 - Single-Stage Gas Valve and Discharge Air Controller in Makeup Air Gas Control System, Option AG1



Direct-Fired Burner

Function: The design of the direct-fired burner and the controlled velocity of air at the burner ensure complete combustion through the full range of burner sizes and gas inputs as determined by the gas control system. The velocity of air is controlled by the profile plates and monitored by a standard low and high air pressure switch.

Service: Refer to Paragraph 6 in the Maintenance Section for instructions on burner maintenance.

WARNING: Burner profile plates are factory set to match CFM requirements. Do not adjust profile plates without contacting your Sales Representative for technical assistance.

Makeup Air (100% Outside Air) Gas Control Systems

• Single-Stage Gas Valve for Makeup Air (Option AG1) (750MBH maximum)

The standard 24-volt, single state gas valve has an integral automatic electric on-off valve, a pressure regulator, a safety pilot valve, and a manual shutoff. The valve operates in response to a call for heat from a unit-mounted air con-

OPERATION/SERVICE SECTION (cont'd)

12. Gas Train (cont'd)

Makeup Air (100% Outside Air) Gas Control Systems (cont'd)

FIGURE 18 - Two-Stage
Gas Valve and Discharge
Ductstat in Makeup Air Gas
Control System, Option
AG3



troller that monitors discharge air temperature. The controller has a built-in setpoint selector from 0° - 100°F.

Due to different CFM settings and outside temperatures, the average downstream outlet temperature may not match the control setting exactly. After the installation is complete, adjust the setpoint to achieve the desired average outlet air temperature. See the valve manufacturer's literature provided in the owner's envelope for specifications, wiring, and operating information.

• Two-Stage Gas Valve for Makeup Air (Option AG3) (750 MBH maximum)

The single-stage valve is replaced by a two-stage valve having low fire and high fire operation. The two-stage valve is controlled by a unit-mounted ductstat that monitors discharge air temperature. The ductstat has a built-in setpoint selector from 60°-110°F. Available for use with natural gas only.

Due to different CFM settings and outside air temperatures, the average downstream outlet temperature may not match the ductstat setting exactly. After the installation is complete, adjust the setpoint of the ductstat to achieve the desired average outlet air temperature. See the valve manufacturer's literature provided in the owner's envelope for specifications, wiring, and operating information.

• Mechanical Modulation for Makeup Air (Option AG49, 40-160°F, or AG50, 40-120°F) (750 MBH maximum)

The mechanical modulation valve regulates the flow of gas based on the demands of the sensing bulb which is located in the discharge airstream.

See the valve manufacturer's literature provided in the owner's envelope for specifications and operating information. Available for use with natural gas only.

FIGURE 19 - Mechanical
Modulation Gas Valve in
Makeup Air Gas Control
System, Option AG49 and
Option AG50




FIGURE 20 - Modulating
Gas Valve



• Electronic Modulation Gas Control for Makeup Air (100% Outside Air), Options AG30, AG31, AG32, AG33, AG35, AG36

Refer to the wiring diagrams in the main electrical box to determine which controls are on the system being serviced. **NOTE:** All field-supplied control wiring for Maxitrol controls must *not* be run inside conduit with line voltage wiring. To avoid any potential electrical interference, all field-supplied wiring for Maxitrol controls should be shielded wiring and must be grounded at the unit only.

Function: These gas control systems provide heated makeup air at a temperature controlled by a discharge air sensor. Makeup air gas controls apply only to systems with 100% outside air. Each system is equipped with electronic modulation controls that modulate burner flame from 1/25th of full fire input to full fire.

The electronic modulating-type gas controls act in response to discharge and/or room air temperature sensors to change the gas flow rate to the burner, thus

lengthening or shortening the flame. The BTU output is varied (modulated) to maintain the required discharge air temperature.


These modulating gas control options are electronic because in all cases the gas valve acts to adjust the flow of the gas to the main burner in response to DC volts emanating from an amplifier. When the DC voltage is between 0 and 5 volts, the main valve seat is closed. Low fire flow is accomplished through a mechanical bypass. The low fire flow rate is set at the factory and should not need adjustment. However, if adjustment is necessary, refer to the Maxitrol literature that is included in the heater owner's envelope.

All of the electronic makeup air modulating gas control burner systems include low fire start. On an initial call for heat, the main burner ignites at its lowest input. During mild weather, the burner may then cycle off. Such full shutdown can be dictated by the outdoor ambient cutoff control. As the outside air temperature climbs above the setpoint of the outdoor ambient control, the burner control circuit is de-energized. When moderately cold outside air temperatures exist, the burner will modulate between low flame and high flame. Low fire start and the outdoor ambient control prevent the makeup air system from heating already warm air and providing "too much" heat to the building.

For troubleshooting guides and further explanation of Maxitrol Series 14 and 44 electronic modulation gas control systems, refer to the Maxitrol literature in the owner's envelope.


The Option AG30, AG31, AG32, and AG35 electronic modulation systems are comprised of Maxitrol Series 14 controls for makeup air. Options AG30 and AG31 systems electronically maintain a constant discharge air temperature in the range of 55-90°F. Option AG31 includes an overriding thermostat. Option AG32 system will maintain a constant discharge air temperature in the range of 80-130°F. Option AG35 maintains a discharge temperature range of 120-160°F.

FIGURE 21 - Maxitrol Series 14 Components used in Makeup Air Gas Control Options AG30, AG31, AG32, AG35



Option AG33 electronic modulation system is comprised of Maxitrol Series 44 controls for makeup air. The low limit (20-60°F) and the high limit (60-140°F) for control of discharge air temperature are set at the amplifier located in the control compartment. The space temperature is set at the remote selectrstat (55-90°F range) located in the space. When the temperature is below the space temperature setpoint, the control system operates the burner to automatically adjust the discharge air temperature within the maximum and minimum limits set on the amplifier.

FIGURE 22 - Maxitrol Series 44 Components used in Makeup Air Gas Control Option AG33



OPERATION/SERVICE SECTION (cont'd)

12. Gas Train (cont'd) • Electronic Modulation Gas Controls (cont'd)

FIGURE 23 - Components of the Gas Control System used in Option AG36 designed specifically for paint booths - controls are mounted on a remote console

Option AG36 is a special application gas train that is designed for controlling the environment of a paint booth operation. The system includes a Maxitrol A1494 amplifier, discharge air temperature sensor, dual remote discharge air temperature selector (drying selector 80-140°F and a spray selector 60-90°F), and two switches to control the operation of the modulating gas valve.




FIGURE 24 - Maxitrol Signal Conditioner for Computer Control

• Electronic Modulation Makeup Air Gas Control Option AG37



Function: Control Option AG37 does not have a duct sensor or amplifier. Instead, a Maxitrol A200 signal conditioner is activated by a customer-supplied input signal (either 4-20 milliamps or 0-10 volt) to control the modulation of the gas valve.

FIGURE 25 - Modulating Gas Valve



Makeup Air with Recirculation Air Gas Control Systems

• Electronic Modulation Makeup Air with Recirculation Gas Control Options AG47, AG48, AG51

Refer to the wiring diagrams in the main electrical box to determine which controls are on the system being serviced. **NOTE:** All field-supplied control wiring for Maxitrol controls must *not* be run inside conduit with line voltage wiring. To avoid any potential electrical interference, all field-supplied wiring for Maxitrol controls should be shielded wiring and must be grounded at the unit only.


Function: These **makeup air with recirculation** gas control systems provide a mix of outside and recirculated air heated to a temperature controlled by a discharge air sensor. Each system is equipped with electronic modulation controls that modulate burner flame from 1/25th of full fire input to full fire and adjust the outside air damper in response to outside and return air sensors.

Both the flow of the gas to the main burner and the outside (bypass) air damper position are adjusted in response to DC volts emanating from an amplifier. When the DC voltage is between 0 and 5 volts, the main valve seat is closed. Low fire gas flow is accomplished through a mechanical bypass. Minimum outside air is 25%. Carbon dioxide (CO₂) in the discharge air of the unit is maintained to a level in compliance with ANSI Z83.18 requirements.

For troubleshooting guides and further explanation of Maxitrol Series 14 and 44 electronic modulation gas control recirculation systems, refer to the Maxitrol literature in the owner's envelope.

Option AG47 electronic modulation system is comprised of Maxitrol Series 14 controls for makeup air with recirculation. The system electronically operates the burner and/or the outside air damper to maintain a constant discharge air temperature in the range of 40-95°F.

FIGURE 26 - Maxitrol Series 14 Components used in Recirculation Air Gas Control Option AG47



Option AG48 electronic modulation system is comprised of Maxitrol Series 44 controls for makeup air with recirculation. The low limit (20-60°F) and the high limit (60-140°F) for control of discharge air temperature are set at the amplifier. The space temperature is set at the remote selectostat (55-90°F range) located in the space. When the temperature is below the space temperature setpoint, the control system operates the burner and/or the outside air damper to automatically adjust the discharge air temperature within the maximum and minimum limits set on the amplifier.

FIGURE 27 - Maxitrol Series 44 Components used in Recirculation Air Gas Control Option AG48




FIGURE 28 - Option AG51 includes Maxitrol Series 44 Components used in AG48 plus a Remote Sensor

Option AG51 electronic modulation system is comprised of the same Maxitrol Series 44 controls as Option AG48 plus a remote sensor/selector.



Service - ALL Gas Controls: Check all electrical connections. A qualified service person should refer to the control manufacturer's literature for assistance in identifying problems and determining the correct solution. None of the controls have field replaceable parts. All components must be replaced with identical replacement parts.

OPERATION/SERVICE SECTION (cont'd)

12. Gas Train (cont'd)

Manifold Arrangements

Description: The manifold is the gas train from the gas supply connection to the burner. The manifold selection ordered determines the manifold arrangement including all of the gas train components except the main control valve. Manifold arrangements are available for varying BTUH ranges and gas controls and meet ANSI, CSA, FM or GAP (former IRI) requirements.

All manifold arrangements include two 5psi rated manual shutoffs.

These systems are designed to operate on a natural gas supply differential pressure range of a minimum of 4.3-5.0" w.c. plus the manifold pressure drop. Maximum supply pressure depends on manifold selection; see below. If the gas supply pressure is above the maximum allowed, it is necessary to install a field-supplied step-down gas regulator in the supply line. Order and install the appropriate Gas Regulator Kit, Option CZ1 (1") or CZ2 (1-1/2"). Follow the instructions provided with the kit. Measure the gas pressure between the step-down regulator and the unit.

Maximum Supply Pressure by Manifold

(Refer to the wiring diagram or rating plate to identify the manifold on the system being serviced.)

Manifold Option BM75, BM76, BM77 - 1/2 psi

Manifold Option BM78, BM79 - 2 psi

Manifold Option BM80, BM81 - 5 psi

The table below lists the minimum supply pressure required for manifold and gas control combinations. Refer to the wiring diagram to be sure which combination of options applies to the system being serviced. (NOTE: Not all options are applicable on all models.)

Minimum Supply Gas Pressure ("w.c.) for Full Fire

Manifold Option with Gas Control Option	BM75		BM76		BM77	BM78	BM79	BM80	BM81									
	AG1	AG3	AG 30, 31, 32, 33, 35, 36, 37, 47, 48, or 51		AG 49, 50	AG 30, 31, 32, 33, 35, 36, 37, 47, 48, or 51												
Manifold Size	1"		1"		1"		1"		1"		1-1/4"		1-1/4"		2"			
MBH	Nat	Pro	Nat	Pro	Nat	Pro	Nat	Pro	Nat	Pro	Nat	Pro	Nat	Pro	Nat	Pro		
250	4.0	1.4	4.0	N/A	4.1	1.6	4.3	1.5	4.4	1.6	4.6	1.6	4.5	1.6	5.1	1.8		
500	5.3	1.9	5.0	N/A	5.8	2.3	6.2	2.2	6.0	2.3	5.2	1.9	5.0	1.7	5.3	1.9		
750	7.5	2.7	6.8	N/A	8.5	3.3	9.5	3.3	8.4	3.3	6.1	2.3	5.7	2.0	5.5	1.9		
1000					12.4	4.7					11.7	4.6	7.4	2.8	6.7	2.4	5.8	2.1
1250													9.1	3.5	8.0	2.9	6.2	2.2
1500													11.2	4.3	9.6	3.5	6.6	2.4
1750													13.6	5.3	11.5	4.2	7.2	2.6
2000													16.5	6.3	13.7	5.0	7.8	2.8
2500													23.3	8.9	18.9	7.0	9.4	3.4
3000																	11.3	4.1

If the gas train includes either or both high and low gas pressure switches, the switches monitor gas pressure downstream from the safety valves.

If the gas pressure in a system equipped with a high gas pressure switch (standard with manifold Options BM 78, 79, 80 and 81; Option BP2 with other manifolds) exceeds the setpoint, the switch will open the electrical circuit to the burner, stopping all gas flow. The high gas pressure switch is a manually reset device.

A low gas pressure switch (Option BP3) will shutoff the gas flow if the gas pressure drops below the setpoint of the low pressure switch. The low gas

pressure switch will automatically reset when the gas pressure rises above the setpoint.

(NOTE: Both high and low gas pressure switches incorporate a vent limiting device and do not require venting to the outdoors when used in an application indoor installation.)

FIGURE 29 - Gas Pressure Switches

Low Gas Pressure Switch, P/N 204375 (automatic)



High Gas Pressure Switch, P/N 204297 (manual reset)



13. Outside Air Cutoff Control (Option BN2)

FIGURE 30 - Outside Air Cutoff Control, P/N 126170



Location: The control is in the electrical box (See Figure 7.); the sensor is in the air inlet.

Function: After sensing pilot flame, the burner ignites at its lowest input rate. The "amount of heat" required to reach the desired discharge temperature also depends on the temperature of the incoming outside air. The outside air control is factory set at 60°F (adjustable 25-250°F). The burner reacts differently depending on the entering air temperature and the setting on the outside air control. The burner --

- may not ignite (pilot valve will not open);
If the actual temperature of the outside air is above the setpoint on the outside air control, the burner will not ignite.
- may modulate to satisfy discharge setting;
- would shutdown completely only on Option BN2 control, once burner has been fired; or
Modulating operation will depend on the temperature rise between the outside air and the discharge air setting.
- may remain on continuous low fire.
If the outside air control is set too high, the burner will continuously burn on low fire as long as the control switch is set to "winter".

When the outside air control is set properly for the climate, the system blower will continue to provide the required makeup air (ventilation) at the ambient outdoor temperature (burner not operating) even when the control switch is set to "winter".

Service: If the control does not function properly, replace it with an identical switch.

14. Door Switch (Option BX1)

FIGURE 31 - Door Switch, P/N 124253



Location: The control is installed on an overhead door opening to control the operation of the heater to coincide with the opening and closing of the door.

Function: The function of the switch is to energize and interlock the heating unit when an outside overhead door reaches approximately 80% of full open travel. The switch will de-energize the furnace when the overhead door closes approximately 20%. The complete switch includes a limit switch electrically wired to the heater and a roller yoke for mechanical activation by a field-supplied trigger on the overhead door.

15. Inlet Air Controls

Description: The system is equipped with one of the 11 types of inlet air control arrangements listed below. All systems provide a constant flow of outside air across the burner at the required air volume (CFM). Refer to the wiring diagrams in the main electrical box to determine which controls are on the system being serviced.

OPERATION/SERVICE SECTION (cont'd)

15. Inlet Air Controls (cont'd)

WARNING: Burner profile plates are factory set to match CFM requirements. Do not adjust profile plates without contacting your Sales Representative for technical assistance.

- **Option AR1** - a constant supply of **100% makeup air**
- **Option AR19** - **100% outside makeup air** with variable supply air volume (CFM). The discharge damper controlling the variable air supply is controlled by a manually set remote potentiometer and can be varied from 100% to 20-25% of total rated airflow (CFM). In response to changes in the discharge damper setting, the bypass damper balances the volume of air so that the required fixed amount of air volume flows over the burner.
- **Option AR20** - **100% outside makeup air** with variable supply air volume (CFM). The discharge damper controlling the variable air supply is automatically controlled by a building pressure sensor and can be varied from 100% to 20-25% of total rated airflow (CFM). In response to changes in the discharge damper setting, the bypass damper balances the volume of air so that the required fixed amount of air volume flows over the burner.
- **Option AR22** - a combination of **outside makeup air and bypass return air** including modulating return air and bypass air dampers. The volume of outside air is regulated by a remotely located, manually set potentiometer.
- **Option AR23** - a combination of **outside makeup air and bypass return air** including modulating return air and bypass air dampers. The volume of outside air is regulated automatically by a remotely located building pressure sensor.
- **Option AR32** - a combination of **outside makeup air and bypass return air** including a two-position actuator. The two position actuator changes the position of the damper to provide either 100% outside air or 20% outside/80% return air. Control is from a SPDT toggle switch mounted on a 4x4 box (or if ordered, the switch is mounted on a remote console).
- **Option AR33** - **100% outside makeup air** with variable supply air volume (CFM). The discharge damper controlling the variable air supply is automatically controlled by a 0-10 VCD or 4-20 milliamp signal. In response to changes in the discharge damper setting, the bypass damper balances the volume of air so that the required fixed amount of air volume flows over the burner.
- **Option AR34** - a combination of **outside makeup air and bypass return air** including modulating return air and bypass air dampers. The volume of outside air is regulated by a 0-10 VCD or 4-20 milliamp signal.
- **Option AR35** - a constant supply of **100% makeup air** to the unit but including a two-position inlet shutoff damper that closes the dampers when the system is not operating. The damper attaches to the duct flange of the optional inlet base (used only with the optional inlet base that has three closed sides and a duct connection for outside air).
- **Option AR36** - **100% outside makeup air** with variable supply air volume (CFM). The discharge damper controlling the variable air supply is automatically controlled by a remotely located photohelic pressure sensor. In response to changes in the discharge damper setting, the bypass damper balances the volume of air so that the required fixed amount of air volume flows over the burner.
- **Option AR37** - a combination of **outside makeup air and bypass return air** including modulating return air and bypass air dampers. The volume of outside air is regulated by a remotely located photohelic pressure sensor.

Airflow Dampers

Function: Dampers operate in response to controls to provide the rated flow of makeup air to the building. Minimum outside air is 20-25%.

Service: Clean all dampers of dust or dirt.

Damper Motor

FIGURE 32 -
Damper Motor



Function: The damper motor automatically actuates the return air, bypass, and/or discharge dampers in response to an electrical control device. The damper motor is direct-coupled to the dampers so there is no damper linkage to adjust. **Service:** There is no service required on these motors other than external cleaning. If the motors need replaced, replace with an identical damper motor.

Potentiometer

FIGURE 33 -
Potentiometer,
P/N 16110



Function: The potentiometer is a manually set switch that operates either the discharge damper (Option AR19) or the return air damper (Option AR22) providing a mixture of return and outside air. It is a remotely located switch that requires manual adjustment.

Service: If the potentiometer does not function properly, replace it with an identical switch.

Pressure Null Switch (automatic building pressure sensor)



FIGURE 34 -
Pressure Null
Switch, P/N 88052

Description/Function: The pressure null switch is a diaphragm operated differential pressure switch used in makeup air applications to automatically control building pressure. It maintains a selected positive or negative pressure setpoint by changing the amount of outside air being introduced to the building through modulating outside air damper. As more pressure is required in the building, the pressure null switch activates the damper motor driving the outside air damper towards the full open position (causing the bypass return air damper to go toward the closed position). Conversely, as less pressure is required, the switch drives the outside air damper in the opposite direction.

Service: Clean the tubing and the screened ends of the pressure tap vents. Be sure that the switch is installed with the diaphragm in a vertical plane and that the pressure taps are sheltered from the wind. For further service, follow the manufacturer's instructions included with the switch.

Photohelic Pressure Switch (automatic building pressure sensor)

FIGURE 35 -
Photohelic
Pressure
Sensor,
P/N 159893



Description/Function: The photohelic pressure switch is a phototransistor relay operated positive pressure switch used in makeup air applications to automatically control building pressure. It maintains a selected positive pressure setpoint by changing the amount of outside air being introduced to the building through a modulating outside air damper. As more pressure is required in the building, the switch activates the damper motor driving the outside air damper towards the full open position (causing the bypass return air damper to go toward the closed position). Conversely, as less pressure is required, the switch drives the outside air damper in the opposite direction.

Service: Clean the tubing and the screened ends of the pressure tap vents.

If the interior of the switch is protected from dust, dirt, corrosive gases and fluids, years of trouble-free service may be expected. Zero adjustment should be checked and reset occasionally to maintain accuracy; follow the manufacturer's instructions included with the switch.

There are no field-repairable parts in this switch. If the switch should require repair, contact either the system or the switch manufacturer concerning switch replacement or repair.

16. Dirty Filter Switch

FIGURE 36
- Dirty Filter
Pressure
Switch,
P/N 105507



Location: Switch is located in the main electrical box (See FIGURE 9); sensor tubes run to either side of the filter rack; indicator light is on the remote console.

Function: The dirty filter switch is a pressure switch that activates an indicator light on the remote console when the filters need cleaned or replaced (See Service Section, Paragraph 2). This switch is only on systems with an optional console that includes a dirty filter light. The pressure switch is set during in-

OPERATION/SERVICE SECTION (cont'd)

16. Dirty Filter Switch (cont'd)

stallation so that the light will be activated at approximately 50% filter blockage. Contacts should close at .17 to 5.0" w.c. \pm .05" w.c.

Service: Clean the sensor tubes. If the dirty filter indicator system still does not function properly, check the setting of the switch. With clean filters in place, blower doors closed, and blower in operation, decrease the pressure setting by adjusting the setscrew on the switch clockwise until the filter light is energized or screw is bottomed out. At that point, adjust the setscrew three full turns counterclockwise or until the screw is top ended.

If it is determined that the switch needs replacing, use an identical switch. When a new switch is installed, it must be manually set; follow the instructions above.

17. Photoelectric Smoke Detector (Option SA1)



FIGURE 37 - Photoelectric Smoke Detector (cover removed), P/N 159553, used with sampling tube, P/N 159714

Location: Field-mounted in the discharge ductwork.

Function: The detector will shut down the system if smoke is detected in the discharge ductwork.

Service: Clean the external surface. Check the wiring and connections.

18. Firestat (Option BD5)

FIGURE 38 - Firestat, P/N 42782



Location: Field-mounted on the discharge ductwork so that the sensor extends into the duct. This control requires manual reset so it should be mounted in an accessible location.

Function: The firestat will shut down the system if the temperature in the ductwork reaches 200°F. The switch must be manually reset.

Service: Clean the external surface. Check the wiring and connections.

19. Low Temperature Limit (Freezestat), Option BE2

FIGURE 39 - P/N 126170



Location: The control is in the blower section electrical box; the sensing bulb is field-mounted in the discharge duct.

Function: The freezestat will shut down the system if the discharge temperature falls below the setpoint. The switch is automatic and will startup the heater when the temperature reaches the setpoint.

Service: Clean the external surface. Check the wiring and connections. Freezestat Controller is P/N 126170.

20. Troubleshooting

Chart 1 - System Troubleshooting (Check the diagnostic lights.)

Symptom or Problem	Cause and Remedy
1. Disconnect switch is closed, but "control power" light is <i>not</i> lit.	<ol style="list-style-type: none"> 1. Fuses are missing or blown in disconnect switch - replace fuses. 2. Transformer not wired according to diagram - check wiring. 3. Secondary 8A fuse (on transformer) is missing or blown - replace fuse. 4. Indicator light is burned out - replace bulb (P/N 125189).
2. Disconnect switch is closed, but "firestat normal" light is <i>not</i> lit.	<ol style="list-style-type: none"> 1. See causes and remedies for Problem 1 above. 2. Optional control relay or door switch contacts are open - to test, jump terminals 3 to 4 or 1 to 2. 3. Firestat option not ordered - verify order/wiring diagram. 4. Firestat manual reset tripped - reset firestat control.
3. Disconnect closed, blower switch in test position, "firestat" light is lit, but "freezestat" light is not lit	<ol style="list-style-type: none"> 1. Freezestat option not ordered - verify order/wiring diagram. 2. Freezestat relay contacts are open - checking setting on control. 3. Indicator bulb is burned out - replace bulb (P/N 125189).
4. Disconnect closed, blower switch in test position, "firestat" and "freezestat" lights are lit, but "starter energized" light is not lit and the blower motor is not operating.	<ol style="list-style-type: none"> 1. End switch on damper motor not closed. - check end switch wiring. 2. Faulty damper relay - replace relay. 3. Damper motor miswired - rewire damper motor per wiring diagram.
5. Disconnect closed, blower switch in test position, "firestat", "freezestat" and "starter energized" lights are lit, but the blower motor is not operating.	<ol style="list-style-type: none"> 1. Blower motor not wired correctly - check wiring diagram on motor. 2. Faulty motor starter - replace (check coil first). 3. Faulty blower motor relay - replace relay.
6. Disconnect closed; blower switch in test position; "firestat", "freezestat" and "starter energized" lights are lit and the blower motor is operating; but the "low air light" is not lit.	<ol style="list-style-type: none"> 1. Low air switch open - verify pressure drop at burner. 2. Indicator light is burned out - replace bulb (P/N 125189). 3. Faulty low air switch - replace pressure switch (P/N 203932).
7. Disconnect closed; blower switch in test position; "firestat", "freezestat", "starter energized" and "low air" lights are lit and the blower motor is operating; but the "high air light" is not lit.	<ol style="list-style-type: none"> 1. High air switch open - verify pressure drop at burner. 2. Indicator light is burned out - replace bulb (P/N 125189). 3. High air switch option not ordered - verify order/wiring diagram. 4. Faulty high air switch - replace pressure switch (P/N 203933).
8. Disconnect closed; blower switch in test position; "firestat", "freezestat", "starter energized", "low air" and "high air" are lit; but the "limit control normal" light is not lit.	<ol style="list-style-type: none"> 1. Indicator light is burned out - replace bulb (P/N 125189). 2. Tripped manual reset limit control(s) - reset manual control. 3. Faulty manual limit control (s) - replace limit control.
9. Disconnect closed; blower switch in test position; "firestat", "freezestat", "starter energized", "low air", "high air" and "limit control normal" lights are lit; but the "ambient (outside air) cutoff normal" light is not lit.	<ol style="list-style-type: none"> 1. Indicator light is burned out - replace bulb (P/N 125189). 2. High ambient control option not ordered - verify order/wiring diagram. 3. High ambient control contacts open - check setting on control.
10. Disconnect closed; blower switch in test position; "firestat", "freezestat", "starter energized", "low air", "high air", "limit control normal" and "ambient (outside air) cutoff normal" lights are lit; but the "low gas pressure normal" light is not lit.	<ol style="list-style-type: none"> 1. Indicator light is burned out - replace bulb (P/N 125189). 2. Low gas pressure switch option not ordered - verify order/wiring diagram. 3. Low gas pressure switch contacts open - check setting on control. 4. Low gas pressure switch contacts open - check gas pressure. 5. Faulty gas pressure switch - replace gas pressure switch.
11. Disconnect closed; blower switch in test position; "firestat", "freezestat", "starter energized", "low air", "high air", "limit controls normal", "ambient (outside air) cutoff normal" and "low gas pressure normal" lights are lit; but the "high gas pressure normal" light is not lit.	<ol style="list-style-type: none"> 1. Indicator light is burned out - replace bulb (P/N 125189). 2. High gas pressure switch option not ordered - verify order/wiring diagram. 3. High gas pressure switch contacts open - check setting on control. 4. High gas pressure switch contacts open - check gas pressure. 5. Manual reset on switch tripped - reset pressure switch manual reset. 6. Faulty gas pressure switch - replace gas pressure switch.
12. Disconnect closed; blower and burner switches in run position; control switch is in "winter" position; "control power", "high gas normal"; "low gas normal"; "firestat normal"; "system switch energized"; "starter energized" and "freezestat normal" lights are lit; but igniter is not becoming energized or beginning to glow.	<ol style="list-style-type: none"> 1. Lack of power at L1 on ignition module - ECO blown, find cause then replace ECO. 2. Faulty burner enable relay - replace relay. 3. Low stage relay contacts are not closed - check air controller or thermostat setting. 4. Faulty low stage relay - replace relay. 5. Faulty hot surface ignitor - check continuity at the ignition module and circuit board. If reading is greater than 5-6 ohms, replace ignitor. 6. Faulty ignition module - replace entire module.
13. Disconnect closed; blower and burner switches in run position; control switch is in "winter" position; "control power", high gas normal; "low gas normal"; "firestat normal"; "system switch energized"; "starter energized" and "freezestat normal" lights are lit; ignitor glowing but "pilot valve normal" light (thus the pilot valve)	<ol style="list-style-type: none"> 1. Ignitor not reaching 1.4A threshold - check voltage and current to ignitor. 2. Faulty hot surface ignitor - check continuity, replace ignitor. 3. Faulty ignition module - replace entire module.

OPERATION/SERVICE SECTION (cont'd)

20. Troubleshooting (cont'd)

Chart 1 - System Troubleshooting (Check the diagnostic lights.) (cont'd)

Symptom or Problem (cont'd)	Cause and Remedy (cont'd)
<p>14. Disconnect closed; blower and burner switches in run position; control switch is in "winter" position; "control power", high gas normal; "low gas normal"; "firestat normal"; "system switch energized"; "starter energized" and "freezestat normal" lights are lit; ignitor has reached 1.4A and has opened the pilot valve bringing on the "pilot valve normal" light; but the pilot flame is not present. (After two trials the unit will go into safety lockout requiring cycling of the main disconnect switch.)</p>	<ol style="list-style-type: none"> 1. Air in pilot gas line - bleed pilot line. 2. Inadequate pilot gas pressure - verify pilot gas pressure (3.5" w.c.) 3. Faulty pilot valve - replace pilot solenoid valve. 4. Faulty ignition module - replace entire module.
<p>15. Disconnect closed; blower and burner switches in run position; control switch is in "winter" position; all status lights are lit except "main valve normal" light. The pilot flame is present and stable, but the (low stage portion or) main gas valve will not open, or rapid cycling of the main valve is occurring.</p>	<ol style="list-style-type: none"> 1. Microamp signal on flame rod is inadequate - check position and condition of flame rod and signal (minimum 0.5 microamps required.) 2. Grounding for unit or flame rod inadequate - check ground path. 3. Faulty main gas valve - replace main gas valve. 4. Faulty ignition module - replace ignition module. 5. Inadequate main gas pressure - verify main burner pressure.
<p>16. Disconnect closed; blower and burner switches in run position; control switch is in "winter" position; all status lights are lit; the pilot flame and low fire on the main burner are present and stable, but the unit will not progress to a high fire condition.</p>	<ol style="list-style-type: none"> 1. Faulty main gas valve - replace main gas valve. 2. Inadequate timing on high fire time delay relay - adjust setting. 3. Faulty high fire time delay relay - replace time delay relay. 4. High stage relay contacts are not closed - check control setting. 5. Inadequate main gas pressure - verify main burner gas pressure. 6. Faulty high stage relay - replace relay. 7. Faulty ignition module - replace entire module.

REFERENCE: For service and troubleshooting information on the electrical controls, refer to the manufacturer's literature covering that component. Component literature is included in the literature envelope.

Chart 2 - Troubleshooting Optional Evaporative Cooling Module (Models ADF/ADFH)

WARNING: Disconnect the power before servicing the cooling module. Failure to do so can cause electrical shock, personal injury or death.

Problem	Probable Cause	Remedy
Float & Pump Control System - Pump does not run. Unit is calling for cooling (i.e. console control switch is in cooling position) and reservoir is full.	<ol style="list-style-type: none"> 1. Electrical connections 2. Electric float switch on pump 3. Dirty pump 4. Defective pump 	<ol style="list-style-type: none"> 1. Verify all electrical connections. See Wiring Diagram. 2. Check position of the actuators on the electric float switch. 3. Clean pump. 4. Replace pump.
Float & Pump Control System - Required water level (3") not maintained	<ol style="list-style-type: none"> 1. Float valve 2. Optional drain and fill valves 3. Incorrect overflow pipe nipple - should be 3-1/2" 4. Drain leaking 	<ol style="list-style-type: none"> 1. Adjust float valve. See Filling and Adjusting Water Level. 2. Check valve for proper operation. 3. Replace pipe nipple. 4. Tighten drain plug.
Water running off of media pads	<ol style="list-style-type: none"> 1. Excessive water flow 2. Media pads need cleaned or replaced. 	<ol style="list-style-type: none"> 1. Adjust ball valve in distribution line. See Maintenance Section, Paragraph 7. 2. Clean or replace media pads. See Maintenance Section, Paragraph 7.
Water not distributing evenly	<ol style="list-style-type: none"> 1. Distribution line clogged 2. Holes in distribution line turned 3. Incorrect voltage to pump (Float & Pump control system) 	<ol style="list-style-type: none"> 1. Flush distribution line. See Maintenance Section, Paragraph 7. 2. Check position of distribution line. Holes should be spraying upward. If not positioned with holes toward top, adjust position of PVC line. 3. Check voltage at pump terminal in cooling module junction box.
Media pads becoming clogged and discolored quickly (scale/salt deposits) and/or rapid deterioration of the float switch (Float and Pump Control System)	<ol style="list-style-type: none"> 1. Bleed off line clogged 2. Excessive water flow 3. Inadequate bleed off 	<ol style="list-style-type: none"> 1. Clean bleed line. 2. Reduce flow by adjusting ball valve in distribution line. See Maintenance Section, Paragraph 7. 3. A uniform build-up of minerals on the entering air face of the media indicates insufficient bleed off. Increase the rate until the mineral deposits dissipate.
Water blowoff from media pads or water being pulled from reservoir	<ol style="list-style-type: none"> 1. Media pads installed incorrectly 2. Requires moisture elimination pad (over 600 FPM) 3. Water level not 3 inches (float & pump control system) 	<ol style="list-style-type: none"> 1. Install media pads correctly. See Maintenance Section , Paragraph 7. 2. Install moisture elimination pad. Consult factory. 3. See second problem listed above (Required water level not being maintained.)

FOR SERVICE OR REPAIR, FOLLOW THESE STEPS IN ORDER:

FIRST: Contact the Installer

Name _____

Address _____

Phone _____

SECOND: Contact the nearest distributor (See Yellow Pages). If no listing, contact Authorized Factory Representative, 1-800-695-1901 (Press 1).

THIRD: Contact REZNOR®/Thomas & Betts Corporation
150 McKinley Avenue
Mercer, PA 16137
Phone: (724) 662-4400

Model No. _____

Unit Serial No. _____

Date of Installation _____