


SHARP SERVICE MANUAL

SA209AYXPC5PU/T

SPLIT TYPE AIR CONDITIONER (INDOOR UNIT)



MODEL AY-XPC15PU AY-XPC18PU AY-XP24PU

In the interests of user-safety (Required by safety regulations in some countries) the set should be restored to its original condition and only parts identical to those specified should be used.

CONTENTS

CHAPTER 1. PRODUCT SPECIFICATIONS

- [1] SPECIFICATION..... 1-1
- [2] EXTERNAL DIMENSIONS..... 1-2
- [3] ELECTRICAL PARTS 1-3
- [4] WIRING DIAGRAMS..... 1-3

CHAPTER 2. EXPLANATION OF CIRCUIT AND OPERATION

- [1] BLOCK DIAGRAMS..... 2-1
- [2] MICROCOMPUTER CONTROL SYSTEM 2-2
- [3] FUNCTION..... 2-3
- [4] OPERATION MANUAL 2-6

CHAPTER 3. TROUBLE SHOOTING GUIDE

- [1] SELF-DIAGNOSIS FUNCTION..... 3-1
- [2] THERMISTOR TEMPERATURE CHARACTERISTICS 3-8
- [3] AIR CONDITIONER OPERATION IN THERMISTOR ERROR 3-8
- [4] GENERAL TROUBLESHOOTING CHART.... 3-9

CHAPTER 4. DISASSEMBLING PROCEDURE

- [1] INDOOR UNIT 4-1
- [2] PLASMACLUSTER UNIT 5-4

CHAPTER 5. INSTALLATION INSTRUCTION

- [1] INDOOR UNIT 5-1

Parts Guide

Parts marked with "⚠" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

CHAPTER 1. SPECIFICATION

[1] SPECIFICATION

| ITEMS | INDOOR MODEL | AY-XPC15PU | AY-XPC18PU | AY-XP24PU |
|--------------------------------|--------------|----------------------------------|----------------------------------|----------------------------------|
| Electrical data | | | | |
| Phase | | Single | Single | Single |
| Rated frequency | V | 208/230 | 208/230 | 208/230 |
| Rated voltage | Hz | 60 | 60 | 60 |
| Refrigerant system | Evaporator | Louver fin and Grooved tube type | Louver fin and Grooved tube type | Louver fin and Grooved tube type |
| | Refrigerant | R410A | R410A | R410A |
| Sound Pressure Level (Cooling) | High | dB(A) | 44 | 45 |
| | Low | dB(A) | 32 | 33 |
| | Silent | dB(A) | 27 | 28 |
| Sound Pressure Level (Heating) | High | dB(A) | 44 | 46 |
| | Low | dB(A) | 34 | 35 |
| | Silent | dB(A) | 29 | 30 |
| Net dimensions | Width | inch (mm) | 38.0 (965) | 38.0 (965) |
| | Height | inch (mm) | 12.3 (313) | 12.3 (313) |
| | Depth | inch (mm) | 9.8 (250) | 9.8 (250) |
| Net weight | lb (kg) | 28.7 (13) | 29.8 (13.5) | 29.8 (13.5) |

Fan system

| Fan motor | | | CMOT-A561JBKZ | CMOT-A561JBKZ | CMOT-A561JBKZ |
|-----------------------------|--------|--------------|---------------------|---------------------|---------------------|
| | | | 8poles,40W | 8poles, 40W | 8poles, 40W |
| Air flow quantity (Cooling) | High | CFM (m3/min) | 467 (13.2) | 476 (13.5) | 511 (14.5) |
| | Low | CFM (m3/min) | 306 (8.7) | 310 (8.8) | 444 (12.6) |
| | Silent | CFM (m3/min) | 239 (6.8) | 243 (6.9) | 286 (8.1) |
| Air flow quantity (Heating) | High | CFM (m3/min) | 503 (14.3) | 501 (14.2) | 525 (14.9) |
| | Low | CFM (m3/min) | 332 (9.4) | 338 (9.6) | 469 (13.3) |
| | Silent | CFM (m3/min) | 254 (7.2) | 261 (7.4) | 314 (8.9) |
| Fan speed (Cooling) | High | rpm | 1060 | 1150 | 1220 |
| | Low | rpm | 750 | 800 | 1080 |
| | Silent | rpm | 620 | 660 | 750 |
| Fan speed (Heating) | High | rpm | 1130 | 1200 | 1250 |
| | Low | rpm | 800 | 850 | 1130 |
| | Silent | rpm | 650 | 700 | 810 |
| Fan | | | Cross-flow fan Φ118 | Cross-flow fan Φ118 | Cross-flow fan Φ118 |

Connections

| Refrigerant coupling | | Flare type |
|--|-----------|--|
| Refrigerant tube size (A:Gas line,B:Liquid line) | inch (mm) | A: 1/2" (Flared connection 1/2") (12.7) |
| | inch (mm) | B: 1/4" (Flared connection 1/4") (6.35) |
| Drain hose | inch (mm) | Insulation O.D. Φ1.14 (29), Connected part O.D. Φ0.63 (16) |


Others

| | |
|--------------------|---------------|
| Air filters | PFILMA282JBEA |
| Cluster generator | CKITTA113AKKZ |
| Rremote controller | CRMC-A868JBEZ |

The data of 18PU/24PU models is currently under revision.
Will be released after approval.

[2] EXTERNAL DIMENSION


Indoor unit



[3] ELECTRICAL PARTS

| Part Name | Model | Remarks |
|--------------|------------------|----------------------------|
| Fan motor | SHA-37CVJ-F440-1 | DC motor (CMOT-A561JBKZ) |
| Louver motor | 24BYJ48-1373 | DC12V (RMOT-A223JBZZ) |
| Fu 1 | - | QFS-GA078JBZZ (3.15A 250V) |


[4] WIRING DIAGRM



[3] ELECTRICAL PARTS


| Part Name | Model | Remarks |
|--------------|------------------|----------------------------|
| Fan motor | SHA-37CVJ-F440-1 | DC motor (CMOT-A561JBKZ) |
| Louver motor | 24BYJ48-1373 | DC12V (RMOT-A223JBZZ) |
| Fu 1 | - | QFS-GA078JBZZ (3.15A 250V) |

[4] WIRING DIAGRM




CHAPTER 2. EXPLAMATION OF CIRCUIT AND OPERATION

[1] BLOCK DIAGRAMS




[2] MICROCOMPUTER CONTROL SYSTEM

1. Electronic control circuit diagram



2. Printed wiring board




[3] FUNCTION

1. Restart control

Once the compressor stops operating, it will not restart for 180 seconds to protect the compressor.

Therefore, if the operating compressor is shut down from the remote control and then turned back on immediately after, the compressor will restart after a preset delay time.

(The indoor unit will restart operation immediately after the ON switch is operated on the remote control.)



2. Startup control

When the air conditioner starts in the cooling mode, if the room temperature is 2°C higher than the set temperature the air conditioner operates with the operating frequency at maximum. Then, when the set temperature is reached, the air conditioner operates at the operating frequency determined by fuzzy logic calculation, then enters the normal control mode after a while.

3. ON timer


The ON timer can be activated by pressing the ON timer button. When the ON timer is activated, the operation start time is adjusted based on fuzzy logic calculations 1 hour before the set time so that the room temperature reaches the set temperature at the set time.

4. OFF Timer (Sleep Operation)


The OFF timer can be activated by pressing the OFF timer button. When the OFF timer is set, the operation stops after the set time.

When this timer is set, the compressor operating frequency lowers for quieter operation, and the room temperature is gradually varied after one hour (reduced 1°C three times (max. 3°C) in heating, or increased 0.3°C three times (max. 1°C) in cooling or dehumidifying operation) so that the room temperature remains suitable for comfortable sleeping.

Heating operation



Cooling/dehumidifying operation



5. Power ON start

If the connecting wire "POWER ON" (POJP) is put on the PWB assembly, when the power is supplied by turning on a circuit breaker, the air conditioner automatically starts of operation in "AUTO".

(Refer to Printed Wiring Board.).

6. Self-diagnostic malfunction code display

1) When a malfunction is confirmed, all relays turn off and a flashing operation LED, timer LED, Plasmacluster LED is displayed to indicate the type of malfunction.

When the air conditioner is in non-operating condition, holding down AUX button for more than 5 seconds activates the malfunction code display function.

The operation continues only in the case of a serial open-circuit, and the main relay turns off after 30 seconds if the open-circuit condition remains.

In the case of a serial short-circuit, the air conditioner continues operating without a malfunction code display, and the main relay turns off after 30 seconds if the short-circuit condition remains.

The malfunction information is stored in memory, and can be recalled later and shown on display.

2) The self-diagnostic memory can be recalled and shown on the display by stopping the operation and holding down AUX button for more than 5 seconds.


(For details, refer to the troubleshooting section.)

7. AUTOMATIC AIR CONDITIONING

In the AUTO mode, the unit will automatically select COOL or HEAT mode by comparing the room temperature and your desired temperature.

The unit will automatically switch between HEAT and COOL mode to keep the desired temperature.

COANDA and MULTI SPACE button will be inactivated during AUTO mode.



During operation, if the outdoor temperature changes, the temperature settings will automatically slide as shown in the chart.

8. Airflow control

8.1. VERTICAL AIR FLOW DIRECTION

- Press the SWING button on the remote control once.
 - The vertical adjustment louvre will swing continuously.
- Press the SWING button again when the vertical adjustment louvre is at the desired position.
 - The louvre will stop moving within the range shown in the diagram.
 - The adjusted position will be memoried and will be automatically set to the same position when operated the next time.

CAUTION: Never attempt to adjust the louvres manually.

- Manual adjustment on the louvres can cause the unit to malfunction.

Position in the COOL or DRY mode for an extended period of time,

- When the vertical adjustment louvre is positioned at the lowest condensation may result.

8.2. HORIZONTAL AIR FLOW DIRECTION

Hold the horizontal airflow louver link and adjust the air flow direction.

9. Difference of operation in Auto and Manual modes


In the Auto mode, the temperature setting is automatically determined based on the outside air temperature. In addition, the air conditioner operation differs from the operation in the Manual mode as explained below.

9.1. Difference relating to set temperature

| | | Temperature setting method |
|-------------|---------------|---|
| Auto mode | Heating | Automatic temperature setting based on outside air temperature. Can be changed within $\pm 2^\circ\text{C}$ using remote control. |
| | Cooling | |
| | Dehumidifying | |
| Manual mode | Heating | Can be changed between 18 and 32 °C using remote control. |
| | Cooling | Can be changed between 16 and 30°C using remote control. |
| | Dehumidifying | Automatic setting. Can be changed within $\pm 2^\circ\text{C}$ using. |

10. Dehumidifying operation control

In the Dehumidifying mode, the temperature setting is automatically determined based on the outside air temperature. In addition, the air conditioner operation differs from the operation in the Manual mode as explained below.



11. Full Power Operation

In this operation, the air/air heat pump works at the maximum power and optimum louvre direction to make the room cool or warm rapidly.

During operation, press the FULL POWER button.

- The remote control will display "☀"
- The temperature display will go off.
- The green FULL POWER lamp on.
- The unit will light up.

TO CANCEL

Press the FULL POWER button again.

- The FULL POWER operation will also be cancelled when the operation mode is changed, or when the unit is turned off.

- The green FULL POWER lamp on the unit will turn off

NOTE:

- The air/air heat pump will operate at "Extra HIGH" fan speed for 5 minutes, and then shift to "HIGH" fan speed. The vertical adjustment louvre will be set obliquely downward.

- You can not set the temperature or fan speed during the FULL POWER operation.

- To turn off the FULL POWER lamp, press the DISPLAY button.

12. Self Clean operation

Heating or Fan operation and Cluster operation are performed simultaneously.


The judgment of whether Heating or Fan operation is used is based on the outside air temperature at 3 minutes after the start of internal cleaning.

The operation stops after 40 minutes.

- During this operation the horizontal louver moves and stays two positions.

It turns to the lower direction and stays for 30 minutes.

Next moves upward and stays for 10 minutes.



13. Plasmacluster Ion function

Operating the Plasmacluster Ion button while the air conditioner is in operation or in non-operation allows the switching of the operation mode in the following sequence: "Air Clean operation" → "Stop".

- "Self Clean operation" generates about equal amounts of (+)ions and (-)ions from the cluster unit to provide clean air.

If the Plasmacluster Ion generation function is operated together with the air conditioner operation, the indoor unit fan speed and louver direction are in accordance with the air conditioner settings.

If the Plasmacluster Ion generation function is used without operating the air conditioning function, the indoor unit fan operates at a very low speed and the upper louver is angled upward and the lower louver remains horizontal. (The airflow volume and direction can be changed by using the remote control.)

14. Auto restart

When power failure occurs, after power is recovered, the unit will automatically restart in the same setting which were active before the power failure.

14.1. Operating mode (Heat, Cool, Dry)

- Temperature adjustment (within 2°C range) automatic operation
- Temperature setting
- Fan setting
- Air flow direction
- Power ON/OFF
- Automatic operation mode setting
- Swing louvre
- Plasmacluster mode

14.2. Setting not memorized

- Timer setting
- Powerful Jet setting
- Internal cleaning


14.3. Disabling auto restart function

By removing (cutting) jumper ○ (JP ○) on the printed circuit board (PCB), the auto restart function can be disabled.


15. Explanation of cluster circuit

The cluster unit generates cluster ions, which are circulated throughout the room by the air flow created by the blower fan (indoor unit fan motor) in the air conditioner unit.


1) When microcomputer output turns "H," the Q11 output changes to "Lo," turning ON the SSR2 and applying 100 V to the cluster unit for the generation of cluster ions (positive and negative ions).



BASIC OPERATION



1 Press the HEAT, COOL, AUTO or DRY button.



• The green OPERATION lamp (☐) will light up.

TO TURN OFF

Press the STOP button.

• The green OPERATION lamp (☐) will turn off.

2 Press the TEMPERATURE button to set the desired temperature.

(HEAT/COOL/AUTO mode)
The temperature setting range:
61-86 °F (16-30 °C).

(DRY mode)

The temperature can be adjusted up to an additional ±3 °F (±2 °C) from the desired temperature automatically by pressing the TEMPERATURE button.

(Example: 1 °F / 1 °C higher)



(Example: 3 °F / 2 °C lower)



3 Press the FAN button to set the desired fan speed.



• In the DRY mode, the fan speed is preset to AUTO and cannot be changed.

NOTE:

TIPS ABOUT AUTO MODE


- In the AUTO mode, the unit will automatically select COOL or HEAT mode by comparing the room temperature and your desired temperature.
- The unit will automatically switch between HEAT and COOL mode to keep the desired temperature.
- COANDA and MULTI SPACE button will be inactivated during AUTO mode.

ADJUSTING THE AIR FLOW DIRECTION

VERTICAL AIR FLOW DIRECTION

1 Press the SWING button (↕).
• The vertical airflow louver will swing.

2 Press the SWING button (↕) again to stop at the desired position.



CAUTION:

Never attempt to adjust the louvers manually.


- Manual adjustment of the louvers can cause the unit to malfunction.
- When the vertical adjustment louver is positioned at the lowest position in the COOL or DRY mode for an extended period of time, condensation may result.

NOTE:

- The adjustment range is narrower than the SWING range in order to prevent condensation from dripping.

HORIZONTAL AIR FLOW DIRECTION


Hold the horizontal airflow louver link and adjust the air flow direction.



PLASMACLUSTER OPERATION

The Plasmacluster ion generator inside the air conditioner will release positive and negative Plasmacluster ions into the room to reduce airborne mold.


1 During operation, press the PLASMACLUSTER button.

- The remote control will display “”.
- The blue PLASMACLUSTER lamp will light up.

TO CANCEL

Press the PLASMACLUSTER button again.

- The blue PLASMACLUSTER lamp will turn off.




NOTE:


- Use of the PLASMACLUSTER operation will be memorized, and it will be activated the next time you turn on the unit.
- To perform Plasmacluster operation in FAN only mode, press the PLASMACLUSTER button when the unit is not operating. The mode symbol of the remote control will go off and the fan speed cannot be set to AUTO.
- Plasmacluster is Sharp's original technology. For more information, please visit: <http://www.sharp-pci.com/en/>

COANDA (GENTLE COOL / HEAT) AIRFLOW

By using this function, the louver will be automatically adjusted to deliver comfortable air gently and quickly across the ceiling or floor without cold/warm air blows directly on you as much as possible. In heat mode, vertical airflow louver is set downward to deliver the warm air down to the floor. In cool or dry mode, vertical airflow louver is set obliquely upward to deliver cool air to the ceiling in order to avoid direct airflow.


1 During operation, press the COANDA AIRFLOW button.

- (HEAT mode)
- The remote control will display “”.

- (COOL / DRY mode)
- The remote control will display “”.

TO CANCEL

Press the COANDA AIRFLOW button again.





NOTE:

- If you want COANDA AIRFLOW operation in FULL POWER mode, press COANDA AIRFLOW button during FULL POWER operation.
- The COANDA AIRFLOW setting and the MULTI SPACE setting can not be used together.


MULTI SPACE

The unit will operate to cool or warm multiple rooms in well insulated house by pressing this button.

1 During cooling or heating operation, press MULTI SPACE button.


The remote controller will display “” and fan speed icon will be changed to “”. Louver angle will be changed to the position for long distance delivery of cool or warm air.

- (HEAT mode)
- The remote control will display “”.

- (COOL / DRY mode)
- The remote control will display “”.

TO CANCEL

Press MULTI SPACE button again.



NOTE:

- The unit will operate at “Extra HIGH” fan speed for 15 minutes for long distance delivery of conditioned air, and then shift to “HIGH” fan speed after 15 minutes.
- SILENT, COANDA, and FAN SPEED button will be disabled during this operation.
- Effectiveness of this function may differ depending on the room layout, installation position of the unit, and insulation level of the space concerned.

SILENT OPERATION


The unit will operate at “Extra LOW” fan speed for comfort and in need of quieter operation.

1 During COOL, HEAT, and AUTO operation, press the SILENT button.

- The speed icon on the remote control will display “SILENT”.

TO CANCEL

Press the SILENT button again.



FULL POWER OPERATION

The air conditioner works at the maximum power to makes the room cool or warm quicker.


1 During operation, press the FULL POWER button.

- The remote control will display “” and AIR FLOW symbol will get longer.
- The temperature display will go off.
- The green FULL POWER lamp () will light up.

TO CANCEL

Press the FULL POWER button again.

- The green FULL POWER lamp () will turn off.




NOTE:

- The air conditioner will operate at “Extra HIGH” fan speed for 15 minutes, and then shift to “HIGH” fan speed.
- You can not set the temperature or fan speed during the FULL POWER operation.

1-2-3-5h OFF TIMER

When the 1-2-3-5h OFF TIMER is set, the unit will automatically turn off after the setting hours.

1 Press the 1-2-3-5h OFF TIMER button to set the desired time.




- The orange TIMER lamp () will light up.
- The remaining time will be indicated on the remote control in 1-hour increments.

TO CANCEL

Press the SET/C button.

Alternatively, press the 1-2-3-5h OFF TIMER button.

- The orange TIMER lamp () will turn off.




NOTE:

- The 1-2-3-5h OFF TIMER has priority over TIMER ON and TIMER OFF.
- If the 1-2-3-5h OFF TIMER is set while the unit is not operating, the unit will operate at the formerly set condition.
- If TIMER ON and/or TIMER OFF are set, TIMER CANCEL button cancels every setting.

TIMER OPERATION

TIMER OFF

- 1** Press the **TIMER OFF** button.
 - The **TIMER OFF** indicator will blink.
- 2** Press the **TIME ADVANCE** or **REVERSE** button to set the desired time.
 - The time can be set in 10-minute increments.
- 3** Press the **SET/C** button.
 - The orange **TIMER** lamp (Ⓜ) will light up.



NOTE:

- When the **TIMER OFF** is set, the temperature setting is automatically adjusted to prevent the room from becoming excessively cold or warm, for example while you sleep. (Auto Sleep function)
HEAT mode: One hour after the timer is set, the temperature setting drops by 5 °F (3 °C).
COOL mode: One hour after the timer is set, the temperature setting rises by 2 °F (1 °C).

TIMER ON

- 1** Press the **TIMER ON** button.
 - The **TIMER ON** indicator will blink.
- 2** Press the **TIME ADVANCE** or **REVERSE** button to set the desired time.
 - The time can be set in 10-minute increments.
- 3** Press the **SET/C** button.
 - The orange **TIMER** lamp (Ⓜ) will light up.
- 4** Select the mode, temperature, and fan speed as desired.
 - Press below buttons to select mode;

| | |
|--------|--------|
| : HEAT | : COOL |
| : AUTO | : DRY |
 - Press the **TEMPERATURE** button (▲ or ▼) to set the desired temperature.
 - Press the **FAN** button to set the desired fan speed.




NOTE:

- The unit will turn on prior to the set time to allow the room to reach the desired temperature. (Awaking function)

TO CANCEL


Press the **SET/C** button.

- The orange **TIMER** lamp (Ⓜ) will turn off.
- The current time will be displayed on the remote control.



TO CHANGE TIME SETTING

Cancel the **TIMER** setting, then set it again



TO COMBINE TIMER ON AND TIMER OFF

Timer on and timer off can be set up at the same time

Set the **TIMER OFF** and **TIMER ON**. The settings will be automatically combined.

Example
 (Current time: 9:00 p.m.)
OFF **TIMER** at 11:00 p.m.
ON **TIMER** at 7:00 a.m.



- The arrow (◀ or ▶) between the **TIMER ON** indicator and the **TIMER OFF** indicator shows which timer will activate first.

NOTE:

- You cannot program the **ON-TIMER** and **OFF-TIMER** to operate the unit at different temperatures or other settings.
- Either timer can be programmed to activate prior to the other.

SELF CLEAN OPERATION

SELF CLEAN operation will reduce the growth of mold fungus with Plasmacluster ions and dry inside of the unit. Utilize the operation at seasonal change over terms.


1 Press the SELF CLEAN button when the unit is not operating.

- The remote control will display “C”. (The “C” will disappear automatically in 1 minute.)
- The blue PLASMACLUSTER lamp (☼) will light up.
- The unit will stop operation after 40 minutes.

TO CANCEL

Press the SELF CLEAN button.

- The blue PLASMACLUSTER lamp will turn off.



NOTE:

- You cannot set the temperature, fan speed, air flow direction or timer setting during the SELF CLEAN operation.
- Mold fungus already grown can not be eliminated by this operation.

DISPLAY BUTTON


Press the DISPLAY button when the lamps on the unit are too bright. (The green OPERATION lamp and the orange TIMER lamp cannot be turned off.)

1 During operation, press the DISPLAY button.

- The blue PLASMACLUSTER lamp (☼), 5°F/-15°C AUTO OFF lamp and/or the green FULL POWER lamp (☼) will turn off.

TO LIGHT UP

Press the DISPLAY button again.



AUXILIARY MODE

Use this mode when the remote control is not available.

TO TURN ON


Press the AUX button.

- The green OPERATION lamp (☼) will light up.
- The mode and the temperature setting are automatically selected according to the room temperature and the outdoor temperature when the unit is turned on. The fan speed is set to AUTO.

TO TURN OFF

Press the AUX button again.

- The green OPERATION lamp (☼) will turn off.



2.CHART FOR READING SELF-DIAGNOSIS RESULT

<INDOOR UNIT> ○:1-second ON / 1-second OFF

| Problem symptom | Outdoor unit indication (LED1) | Indoor unit | | | | | Malfunction No.* | | Content of diagnosis | | Check point | Action | |
|--|--------------------------------|-------------|------|-----------|----------------------|-----|----------------------|---|---|--|--|--|----------------------|
| | | → | Lamp | | | | Main | Sub | Main | Sub | | | |
| Indoor and outdoor units do not operate. | 2-time | ○ ○ ○ ○ ○ | ○ | ○ | ○ | ○ | 2 | 0 | Cycle temperature | Compressor high temperature error | 1) Check the outdoor unit air outlet for blockage. 2) Check if the power supply voltage is AC 230V at full power. 3) Check the pipe connections for refrigerant leaks. 4) Measure resistance of the outdoor unit compressor thermistor. 5) Check the expansion valve for proper operation. | 1) Ensure unobstructed air flow from the outdoor unit air outlet. 2) Connect power supply of proper voltage. 3) Charge the specified amount of refrigerant. 4) Replace the outdoor unit compressor thermistor assembly. 5) Replace the expansion valve coil, expansion valve or outdoor unit control PCB assembly. | |
| | | | | | | ○ | | | | | | | Operation (Green) |
| | | | | | | | | | | | | | |
| Indoor unit operates. Outdoor unit does not operate temporarily | 2-time | ○ ○ ○ ○ ○ | ○ | ○ | ○ | ○ | 1 | | Compressor discharge overheat. | (Temporary stop for cycle protection) | - | | |
| | | | | | | ○ | | | | | | Operation (Green) | |
| | | | | | | ○ | | | | | | Plasmacluster (Blue) | |
| | | | | ○ ○ ○ ○ ○ | ○ | ○ | ○ | 2 | | Outdoor unit heat exchanger overheat. | (Temporary stop for cycle protection) | - | |
| | | | | | | ○ | Operation (Green) | | | | | | |
| | | | | | | ○ | Plasmacluster (Blue) | | | | | | |
| | | | | ○ ○ ○ ○ ○ | ○ | ○ | ○ | 3 | | Indoor unit heat exchanger overheat. | (Temporary stop for cycle protection) | - | |
| | | | | | | ○ | Operation (Green) | | | | | | |
| | | | | | | ○ ○ | Plasmacluster (Blue) | | | | | | |
| | | | | ○ ○ ○ ○ ○ | ○ | ○ | ○ | 4 | | IPM high temperature error | Measure resistance of the heat-sink thermistor. | - | |
| | | | | | | ○ | Operation (Green) | | | | | | |
| | | | | | | ○ | Plasmacluster (Blue) | | | | | | |
| Indoor and outdoor units do not operate. | 2-time | ○ ○ ○ ○ ○ | ○ | ○ | ○ | 5 | | | IPM high temperature error | Replace the outdoor unit control PCB assembly. | - | | |
| | | | | | | | | | | | | ○ | Operation (Green) |
| | | | | | | | | | | | | ○ | Plasmacluster (Blue) |
| Indoor unit operates. Outdoor unit does not operate temporarily. | 3-time | ○ ○ ○ ○ ○ | ○ | ○ | ○ | 3 | 0 | Dry operation | Temporary stop due to dehumidifying operation | (Temporary stop for cycle protection) | - | | |
| | | | | | | | | | | | | ○ ○ | Operation (Green) |
| | | | | | | | | | | | | | Plasmacluster (Blue) |
| Indoor and outdoor units do not operate. | 5-time | ○ ○ ○ ○ ○ | ○ | ○ | ○ | 5 | 0 | Outdoor unit thermistor open-circuit | Heat exchanger thermistor open circuit error | 1) Check connector of outdoor unit thermistor for secure installation. | 1) Correct the installation | | |
| | | | | | | | | | | | | ○ | Operation (Green) |
| | | | | | | | | | | | | | Plasmacluster (Blue) |
| | | | | ○ ○ ○ ○ ○ | ○ | ○ | ○ | 1 | | Outdoor temperature thermistor open circuit error | 2) Measure resistance of outdoor thermistors | 2) Replace the outdoor unit thermistor assembly. | |
| | | | | | | ○ | Operation (Green) | | | | | | |
| | | | | | | ○ | Plasmacluster (Blue) | | | | | | |
| | | | | ○ ○ ○ ○ ○ | ○ | ○ | ○ | 2 | | Suction thermistor open circuit error | 3) Check the lead wires of thermistors on the outdoor unit control PCB for open-circuit. | 3) Replace the outdoor unit thermistor assembly. | |
| | | | | | | ○ | Operation (Green) | | | | | | |
| | | | | | | ○ | Plasmacluster (Blue) | | | | | | |
| | | | | ○ ○ ○ ○ ○ | ○ | ○ | ○ | 3 | | Suction thermistor open circuit error | 4) 1) 2) 3):Normal | 4) Replace the outdoor unit control PWB assembly. | |
| | | | | | | ○ | Operation (Green) | | | | | | |
| | | | | | | ○ ○ | Plasmacluster (Blue) | | | | | | |
| | | | | ○ ○ ○ ○ ○ | ○ | ○ | ○ | 4 | | Discharge thermistor open circuit error | | | |
| | | | | | | ○ | Operation (Green) | | | | | | |
| | | | | | | ○ | Plasmacluster (Blue) | | | | | | |
| | | ○ ○ ○ ○ ○ | ○ | ○ | ○ | 5 | | Heat sink thermistor open circuit error | | | | | |
| | | | | ○ | Operation (Green) | | | | | | | | |
| | | | | ○ | Plasmacluster (Blue) | | | | | | | | |

| Problem symptom | Outdoor unit indication (LED1) | Indoor unit | | | | Malfunction No.* | | Content of diagnosis | | Check point | Action | | | | | | | | | |
|--|--------------------------------|--|---------|---|---|----------------------|-----|----------------------|-------------------------|---|---|--|---|-------------------|----|---|--------------|-----------------------------|---|--|
| | | → | Lamp | | | Main | Sub | Main | Sub | | | | | | | | | | | |
| Indoor and outdoor units do not operate. | 6-time | O | O | O | O | Timer (Orange) | 6 | 0 | Outdoor unit DC Current | DC over current error | Go to "DC Over Current Error (6-0 error)". | | | | | | | | | |
| | | | | O | O | Operation (Green) | | | | | | | | | | | | | | |
| | | | | | | Plasmacluster (Blue) | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | 1 | | | | | | | | |
| | | | | O | O | Operation (Green) | | | | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | | | | |
| Indoor and outdoor units do not operate. | 7-time | O | O | O | O | Timer (Orange) | 7 | 0 | Outdoor unit AC Current | AC over current error | 1) Ensure unobstructed air flow from the outdoor unit air outlet. 2) Check the outdoor unit fan motor. | 1) Ensure unobstructed air flow from the outdoor unit air outlet. 2) Check the outdoor unit fan motor. | | | | | | | | |
| | | | | O | O | Operation (Green) | | | | | | | | | | | | | | |
| | | | | | | Plasmacluster (Blue) | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | | 1 | | | | | | | |
| | | | | O | O | Operation (Green) | | | | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | | 2 | | | | | | | |
| | | | | O | O | Operation (Green) | | | | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | | 3 | | | | | | | |
| | | | | O | O | Operation (Green) | | | | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| Indoor and outdoor units do not operate. | 8-time | O | O | O | O | Timer (Orange) | 8 | 0 | Abnormal wire check | Abnormal wire check error | 1) Check the expansion valve. 2) Are four expansion valves connected by mistake. 3) Check the wiring between units. | 1) Replace the outdoor control board assembly. 2) Reattach 3) Check the wiring between units. | | | | | | | | |
| | | | O | | | Operation (Green) | | | | | | | | | | | | | | |
| | | | | | | Plasmacluster (Blue) | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| Indoor and outdoor units do not operate. | 9-time | O | O | O | O | Timer (Orange) | 9 | 0 | Cycle temperature | Thermistor installation error or 4-way valve error. | 1)Check the thermistor (heat exchanger) and (2-way valve) are installed in correct positions. 2)Check resistance of thermistors (heat exchanger and 2-way valve). 3)Check the 4-way valve for proper operation. 4)No abnormality found in above inspections (1), (2), (3). | 1)Correct the installation. 2)Change the specified amount of refrigerant. 3)Replace the 4-way valve. 4)Replace the outdoor unit control PWB assembly. | | | | | | | | |
| | | | O | | | Operation (Green) | | | | | | | | | | | | | | |
| | | | | | | Plasmacluster (Blue) | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | | 4 | | | | | | | |
| | | | | O | | Operation (Green) | | | | | | | | | | | | | | |
| | | | | O | | Plasmacluster (Blue) | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | Indoor and outdoor units do not operate. | 10-time | O | O | O | | | | | | | O | Timer (Orange) | 10 | 0 | EEPROM error | EEPROM (outdoor) data error | - | Replace the outdoor unit control PWB assembly. |
| | | | | | O | | | | | | | | | Operation (Green) | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | | | | |
| O | O | | | O | O | Timer (Orange) | 1 | | | | | | | | | | | | | |
| | O | | | | | Operation (Green) | | | | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | | | | |

| Problem symptom | Outdoor unit indication (LED1) | Indoor unit | | | | Malfunction No.* | | Content of diagnosis | | Check point | Action | | | | | | |
|--|--------------------------------|-------------|---|----------------------|---|----------------------|-----|----------------------|--------------------------------|---|---|---|---|---|---|--|--|
| | | → | | | | Main | Sub | Main | Sub | | | | | | | | |
| Indoor and outdoor units do not operate. | 10-time | O | O | O | O | Timer (Orange) | 10 | 2 | EEPROM error | EEPROM (outdoor) data error | - | Replace the outdoor unit control PWB assembly. | | | | | |
| | | | O | | O | Operation (Green) | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | |
| Indoor and outdoor units do not operate. | 11-time | O | O | O | O | Timer (Orange) | 11 | 0 | Outdoor unit DC fan | Outdoor unit DC fan rotation error | 1) Check connector CN3 of the outdoor unit DC fan motor for secure installation. 2) Check the outdoor unit fan motor for proper rotation. 3) Check fuse FUSE5. 4) Outdoor unit control PWB | 1) Correct the installation. 2) Replace the outdoor unit fan motor. 3) Replace the outdoor unit control PWB assembly. 4) Replace the outdoor unit control PWB assembly. | | | | | |
| | | | O | | O | Operation (Green) | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | | 1 | 1 | Outdoor unit DC fan driver IC error | 1) Check if the fan IPM terminal resistance values are uniform. 2) Outdoor unit fan motor continuity check. | 1) Replace the outdoor unit control PWB assembly. 2) Replace the outdoor unit fan. |
| | | | O | | O | Operation (Green) | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | | 2 | 2 | Outdoor unit DC fan lock error | 1) Check the outdoor unit fan motor for proper rotation. 2) 1): Normal | 1) Replace the outdoor unit control PWB assembly. 2) Replace the outdoor unit fan. |
| | | | O | | O | Operation (Green) | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | | 3 | 3 | Detection error of DC fan negative rotation before compressor is driven | (Temporary stop for DC fan circuit protection) | - |
| | | | O | | O | Operation (Green) | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | | 4 | 4 | Detection error of inverter current for DC fan | - | Replace the outdoor unit control PWB assembly. |
| | | | O | | O | Operation (Green) | | | | | | | | | | | |
| | | | | O | | Plasmacluster (Blue) | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | | 5 | 5 | Outdoor unit DC fan open connector error | 1) Check connector CN3 of the outdoor unit DC fan motor for secure installation. 2) No abnormality found in above inspection 1). | 1) Correct the installation. 2) Replace the outdoor unit control PWB assembly. |
| | O | | O | Operation (Green) | | | | | | | | | | | | | |
| | | O | | Plasmacluster (Blue) | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| Indoor and outdoor units do not operate. | 12-time | O | O | O | O | Timer (Orange) | 12 | 0 | Thermal fuse in terminal board | Thermal fuse error in terminal board (for power supply) | 1) Check the thermal fuse in terminal board (for Power supply) 2) Check connector CN5 of the outdoor unit. 3) 1) 2): Normal | 1) Replace terminal board for Power supply. 2) Correct the installation. 3) Replace the outdoor unit control PCB assembly. | | | | | |
| | | | O | | O | Operation (Green) | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| Indoor and outdoor units do not operate. | 13-time | O | O | O | O | Timer (Orange) | 13 | 0 | DC compressor | Compressor startup error | 1) Check the colors (red, white, orange) of the compressor cords for proper connection. (PWB side, compressor side) 2) Check if the IPM terminal resistance values are uniform. 3) Check if outdoor main relay (MRY1) turns on and voltage of both end of the condenser (C10) has become DC290-330V. 4) 1) 2) 3) : Normal | 1) Correct the installation. (U: Red, V: White, W: Orange) 2) Replace the outdoor unit control PWB assembly. 3) Replace the outdoor unit control PWB assembly. 4) Replace the compressor. | | | | | |
| | | | O | | O | Operation (Green) | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | | 1 | 1 | Compressor rotation error. (at 120° energizing) | 2) Check if the IPM terminal resistance values are uniform. | 3) Check if outdoor main relay (MRY1) turns on and voltage of both end of the condenser (C10) has become DC290-330V. 4) 1) 2) 3) : Normal |
| | | | O | | O | Operation (Green) | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| | | O | O | O | O | Timer (Orange) | | | | | | | 2 | 2 | Compressor rotation error (at 180° energizing) | 3) Check if outdoor main relay (MRY1) turns on and voltage of both end of the condenser (C10) has become DC290-330V. 4) 1) 2) 3) : Normal | 3) Replace the outdoor unit control PWB assembly. 4) Replace the compressor. |
| | | | O | | O | Operation (Green) | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| Indoor and outdoor units operate. | | O | O | O | O | Timer (Orange) | | | | Detection error of inverter current | Check the circuit of detection of inverter current. | Replace the outdoor unit control PWB assembly. | | | | | |
| | | | O | | O | Operation (Green) | | | | | | | | | | | |
| | | | | | O | Plasmacluster (Blue) | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |

| Problem symptom | Outdoor unit indication (LED1) | Indoor unit | | | | | Malfunction No.* | | Content of diagnosis | | Check point | Action | |
|--|--------------------------------|-------------|---|------|----------------------|---|----------------------|-----|----------------------|-------------------------|---------------------------------|--|--|
| | | → | | Lamp | | | Main | Sub | Main | Sub | | | |
| Indoor and outdoor units do not operate. | 14-time | O | O | O | O | O | Timer (Orange) | 14 | 0 | Outdoor unit PAM | PAM over voltage error | 1) Check the AC power supply voltage for fluctuation. 2) No abnormality found in above inspection. | 1) Correct the installation. 2) Replace the PWB assembly. |
| | | | O | O | O | | Operation (Green) | | | | | | |
| | | | | | | | Plasmacluster (Blue) | | | | | | |
| | | | | | | | | | | | | | |
| | | O | O | O | O | O | Timer (Orange) | 1 | | | PAM clock error | Check the PAM clock for proper input. | Replace the outdoor unit control PWB assembly. |
| | | | O | O | O | | Operation (Green) | | | | | | |
| | | | | | | O | Plasmacluster (Blue) | | | | | | |
| | | O | O | O | O | O | Timer (Orange) | 2 | | | PAM under voltage error | 1) Check the AC power supply voltage for fluctuation. 2) No abnormality found in above inspection. | 1) Correct the installation. 2) Replace the PWB assembly. |
| | O | O | O | | Operation (Green) | | | | | | | | |
| | | | | O | Plasmacluster (Blue) | | | | | | | | |
| Indoor unit operates. Outdoor unit does not operate. | Lighting or OFF | O | O | O | O | O | Timer (Orange) | 17 | 0 | Wiring between units | Serial opencircuit | 1) Check the wires between units. 2) Check voltage between N and 1 the indoor/outdoor unit terminal boards. 3) Check the outdoor unit fuse. 4) Check 15-V,13-V and 5-V voltages on the PCB. Check resistance between IPM terminals. 5) Check pins No.5 and 8 of connector CN3 of the outdoor unit fan motor for shortcircuit. 6) Outdoor unit control PCB. | 1) Connect stable power supply. Correct the wiring. 2) Replace the outdoor unit control PWB assembly. 3) Replace the fuse/outdoor unit control PWB assembly. 4) Replace the outdoor unit control PWB assembly. 5) Replace the outdoor unit fan motor. 6) Replace the outdoor unit control PWB. |
| | | O | | | | O | Operation (Green) | | | | | | |
| | | | | | | | Plasmacluster (Blue) | | | | | | |
| Indoor unit operates. Outdoor unit does not operate. | Lighting or OFF | O | O | O | O | O | Timer (Orange) | 18 | 0 | Wiring between units | Serial opencircuit | Check the wiring between units. | Correct the wiring. |
| | | O | | | | O | Operation (Green) | | | | | | |
| | | | | | | | Plasmacluster (Blue) | | | | | | |
| Indoor and outdoor units do not operate. | Lighting or OFF | O | O | O | O | O | Timer (Orange) | 1 | | | Check the wiring between units. | Correct the wiring. | |
| | | O | | | | O | Operation (Green) | | | | | | |
| | | | | | | O | Plasmacluster (Blue) | | | | | | |
| Indoor and outdoor units do not operate. | Normal blinking or OFF | O | O | O | O | O | Timer (Orange) | 19 | 0 | Indoor unit fan | Indoor unit fan error | 1) Check the indoor fan motor for proper rotating operation. (Check fan lock.) 2) Check the lead wire of the indoor fan motor for open-circuit. 3) Check connector of the indoor unit fan motor for secure installation. 4) 1) 2) 3): Normal | 1) Replace the indoor fan motor. 2) Replace the indoor fan motor. 3) Correct the installation of the indoor fan motor connector. 4) Replace the indoor unit control PCB. |
| | | O | | | | O | Operation (Green) | | | | | | |
| | | | | | | | Plasmacluster (Blue) | | | | | | |
| Indoor and outdoor units do not operate. | Normal blinking or OFF | O | O | O | O | O | Timer (Orange) | 20 | 0 | Indoor unit control PCB | EEPROM data error | (EEPROM read data error) | Replace the indoor unit control PWB. |
| | | O | | | | O | Operation (Green) | | | | | | |
| | | | | | | | Plasmacluster (Blue) | | | | | | |

| Problem symptom | Outdoor unit indication (LED1) | Indoor unit | | | | Malfunction No. | | Content of diagnosis | | Check point | Action |
|-----------------------------------|--------------------------------|-------------|------|---|---|-----------------|-----|--|--|--|-----------------------------|
| | | → | Lamp | | | Main | Sub | Main | Sub | | |
| Indoor and outdoor units operate. | Normal blinking or OFF | ○ | ○ | ○ | ○ | 26 | 1 | Indoor unit room temperature thermistor | Indoor unit room temperature thermistor | (1) Check connector of thermistor for secure installation. | (1) Replace the thermistor. |
| | | ○ | ○ | ○ | ○ | | | | | (2) Check the temperature properties of the thermistor. | (2) Replace the thermistor. |
| | | ○ | ○ | ○ | ○ | | | | | | |
| | | ○ | ○ | ○ | ○ | 2 | 2 | Indoor unit pipe temperature thermistor | Indoor unit pipe temperature thermistor | (1) Check connector of thermistor for secure installation. | (1) Replace the thermistor. |
| | | ○ | ○ | ○ | ○ | | | | | (2) Check the temperature properties of the thermistor. | (2) Replace the thermistor. |
| | | ○ | ○ | ○ | ○ | | | | | | |
| | | ○ | ○ | ○ | ○ | 3 | 3 | Indoor unit valve temperature thermistor | Indoor unit valve temperature thermistor | (1) Check connector of thermistor for secure installation. | (1) Replace the thermistor. |
| | | ○ | ○ | ○ | ○ | | | | | (2) Check the temperature properties of the thermistor. | (2) Replace the thermistor. |
| | | ○ | ○ | ○ | ○ | | | | | | |

***Remark**

The malfunction No. is calculated using the following way.

Example)

| Indoor unit lamp | →Lamp | | | | | Calculation | Main | Sub |
|----------------------|-------|---|---|---|---|-------------|------|-----|
| | 16 | 8 | 4 | 2 | 1 | | | |
| Timer (orange) | ○ | ○ | ○ | ○ | ○ | | | |
| Operation (Green) | | | ○ | | ○ | 4+1=5 | 5 | |
| Plasmacluster (blue) | | | | ○ | | 2 | | 2 |


IPM CHECK METHOD

1. Turn off the power.
2. Make sure that the electrolytic capacitor voltage is approx. 0 V.
3. Remove all connectors of the IPM PWB.
4. Measure the resistance between terminals using a tester.

Measuring points of terminals are shown in the figure below.


| Analog tester | | Normal Resistance | Analog tester | | Normal Resistance |
|---------------|----|-------------------|---------------|----|-------------------|
| - | + | | - | - | |
| TP | TN | ∞ *(Few MΩ) | TU | TN | ∞ (Few MΩ) |
| | TU | | | | |
| | TV | | | | |
| | TW | | | | |

*() value: by Digital tester



DC Over Current Error (6-0 error)

6-0 error memory is recorded.




- * 1 Check the connection of compressor lead wire on IPM PWB.
TU : RED
TV : WHITE
TW : ORANGE
- * 2 Check the connection of compressor terminal marking.
- * 3 Refer to "DISASSEMBLING PROCEDURE OUTDOOR UNIT".
Check to make sure thermistors are installed in correct portions.
Refer to "THERMISTOR TEMPERATURE CHARACTERISTICS".
- * 4

[2] THERMISTOR TEMPERATURE CHARACTERISTICS.

| Thermistor | Signal | Color |
|----------------------------|--------|--------|
| Room temperature | TH1 | Yellow |
| Heat exchanger temperature | TH2 | Orange |
| Valve temperature | TH3 | Black |


Room temperature thermistor TH1 (CN2 ③ - ④)
 Heat exchanger temperature thermistor TH2 (CN2 ① - ②)
 Valve temperature thermistor TH3 (CN2 ⑤ - ⑥)



To measure the resistance, first remove the soldering as shown at right.

Heat exchanger/Valve thermistor TH2 (Orange), TH3 (Black)
 25°C resistance 4.431 kΩ

Room temperature thermistor TH1 (Yellow)
 25°C resistance 10 kΩ



[3] AIR CONDITIONER OPERATION IN THERMISTOR ERROR

* These models have following thermistors.

| INDOOR UNIT | |
|-----------------------------------|---------------|
| AY-XPC15PU, AY-XPC18PU, AY-XP24PU | TH1, TH2, TH3 |

The errors for the thermistors that are not mentioned above are irrelevant.
 These indoor units don't have power relay.

| Item | Mode | Control operation | When resistance is low (temperature judged higher than actual) | Short-circuit | When resistance is high (temperature judged lower than actual) | Open-circuit |
|-----------------------------------|--------------------------|--|---|--|--|---|
| Room temperature thermistor (TH1) | Auto | Operation mode judgment | Cooling mode is activated even if room temperature is low. | Cooling mode is activated in most cases. | Heating mode is activated even if room temperature is high. | Heating mode is always activated. |
| | Cooling | Frequency control | Room becomes too cold. | Air conditioner operates in full power even when set temperature is reached. | Room does not become cool. | Compressor does not operate. |
| | Dehumidifying | Room temperature memory Frequency control | Normal operation. | Room temperature is stored in memory as 31.0 °C, and compressor does not stop. | Normal operation. | Room temperature is stored in memory as 18.5 °C, and compressor does not operate. |
| | Heating | Frequency control | Room does not become warm. | Hot keep status results immediately after operation starts. Frequency does not increase above 30 Hz (40 Hz). | Room becomes too warm. | Air conditioner operates in full power even when set temperature is reached. |
| Heat exchanger thermistor (TH2) | Cooling Dehumidifying | Freeze prevention | Indoor unit evaporation may freeze. | Indoor unit evaporation may freeze. | Compressor stops occasionally. | Compressor does not operate. |
| | Heating | Cold air prevention | Cold air prevention deactivates too soon and cold air discharges. | Compressor operates at low speed or stop, and frequency does not increase. | Cold air prevention deactivates too slow. | Cold air prevention does not deactivate, and indoor unit fan does not rotate. |

[4] GENERAL TROUBLESHOOTING CHART

* These models have following thermistors.

| INDOOR UNIT | |
|-----------------------------------|---------------|
| AY-XPC15PU, AY-XPC18PU, AY-XP24PU | TH1, TH2, TH3 |

The errors for the thermistors that are not mentioned above are irrelevant.

These indoor units don't have power relay.

1. Indoor unit does not turn on

| Main cause | Inspection method | Normal value/condition | Remedy |
|--------------------------------------|-----------------------|--|--------------|
| Cracked PWB. (Cracked pattern) | Check visually. | There should be no cracking in PWB or pattern. | Replace PWB. |
| Open-circuit in FU1 (250 V, 3.15 A). | Check melting of FU1. | There should be no open-circuit. | Replace PWB. |

2. Indoor unit fan does not operate

| Main cause | Inspection method | Normal value/condition | Remedy |
|--|--|--|---------------------|
| Open-circuit in heat exchanger thermistor (TH2) (in heating operation) | Measure thermistor resistance (dis-mount for check) | Refer to THERMISTOR TEPERATURE CHARACTERISTICS-1 | Replace thermistor. |
| | | There should be no open-circuit or faulty contact. | Replace thermistor. |
| Disconnected heat exchanger thermistor (TH2) (in heating operation) | Inspect connector on PWB. Check thermistor installation condition. | Thermistor should not be disconnected. | Install correctly. |

3. Indoor unit fan speed does not change

| Main cause | Inspection method | Normal value/condition | Remedy |
|--|-----------------------|--|------------------|
| Remote control not designed to allow fan speed change. | Check operation mode. | Fan speed should change except during dehumidifying operation, ventilation, light dehumidifying operation, internally normal operation | Explain to user. |

4. Remote control signal is not received

| Main cause | Inspection method | Normal value/condition | Remedy |
|---|--|---|--|
| Batteries at end of service life. | Measure battery voltage. | 2.5 V or higher (two batteries in series connection) | Install new batteries. |
| Batteries installed incorrectly. | Check battery direction. | As indicated on battery compartment. | Install batteries in indicated direction. |
| Lighting fixture is too close, or fluorescent lamp is burning out. | Turn off light and check. | Signal should be received when light is turned off. | Change light position or install new fluorescent lamp. |
| Use Sevick light (Hitachi). | Check if Sevick light (Hitachi) is used. | Signal may not be received sometimes due to effect of Sevick light. | Replace light or change position. |
| Operating position/angle is inappropriate. | Operate within range specified in manual. | Signal should be received within range specified in manual. | Explain appropriate handling to user. |
| Open-circuit or short-circuit in wiring of light receiving section. | Check if wires of light receiving section are caught. | Wires of light receiving section should not have any damage caused by pinching. | Replace wires of light receiving section. |
| Defective light receiving unit. | Check signal receiving circuit (measure voltage between terminals 8 and 9 of connector CN7). | Tester indicator should move when signal is received. | Replace PWB. |
| Dew condensation on light receiving unit. | Check for water and rust. | Signal should be received within range specified in manual. | Take moisture-proof measure for lead wire outlet of light receiving section. |

5. Louvers do not move

| Main cause | Inspection method | Normal value/condition | Remedy |
|---|--|--|-------------------------------------|
| Caught in sliding section. | Operate to see if louvers are caught in place. | Louvers should operate smoothly. | Remove or correct catching section. |
| Disconnected connector | Inspect connectors. | Connectors or pins should not be disconnected. | Install correctly. |
| Contact of solder on PWB (connector section on PWB) | Check visually. | There should not be solder contact. | Correct contacting section. |

6. There is noise in TV/radio

| Main cause | Inspection method | Normal value/condition | Remedy |
|---|---|---|---------------------------------------|
| Grounding wires not connected properly. | Check grounding wire connections. | Grounding wires should be connected properly. | Connect grounding wires properly. |
| TV/radio is placed too close to outdoor unit. | Check distance between TV/radio and outdoor unit. | If TV/radio is placed too close, it may become affected by noise. | Move TV/radio away from outdoor unit. |
| Other than above. | Check for radio wave interference. | | |

7. Malfunction occurs

| Main cause | Inspection method | Normal value/condition | Remedy |
|------------------------------|------------------------------------|------------------------|--------|
| Malfunction caused by noise. | Check for radio wave interference. | | |

CHAPTER 4. DISASSEMBLY PROCEDURE

Be sure to disconnect the power cord from the AC power outlet before starting the disassembly procedure.

Be sure to install screws to their original positions after repairing

After the air conditioner is repaired or parts are replaced, measure insulation resistance of the equipment using an insulation resistance meter. If the measured resistance is lower than 1 MΩ, inspect parts and repair or replace defective parts.

[1] INDOOR UNIT


1. Open the open panel to the horizontal position and remove with pulling it forward.
5. Remove the connecting cable and power supply cable from terminal board.





2. Remove the 2 air filters.




3. Unscrew the screw fixing cable cover and remove it.




4. Unscrew the 2 screws and remove the cable holder.





6. Remove the grille by releasing the 3 hooks.





7. Release the 2 hooks and remove the filter guide.



8. Unscrew the screw fixing the front panel L and remove it.




9. Unscrew the screw fixing the front panel R and remove it.




10. Unscrew the 2 screws and remove the front cover.



11. Unscrew the screw fixing earth wire.




12. Cut the fixing bands.




13. Release the 2 hooks of the control box side cover and remove it.




14. Release the hook of the control box top cover and slide it up to remove.



15. Cut the 2 fixing bands and disconnect the connectors from the control board unit.




11. Remove the control box by releasing the upper hook and pulling out.




12. Unscrew the 2 screws fixing drain pan and remove it.



13. Unscrew the 2 screws and remove the motor bracket.




14. Slide the vertical louvre and remove it



15. Unscrew the 3 screws fixing side cover L and side cover R.




16. Release the hook of the motor cover from cabinet.



17. Take out the motor and cross flow fan.



18. Unscrew the screw of the cross flow fan and remove it.




19. Remove the pipe holder.

- Push the hook of the pipe holder and remove it by pulling lower part.




Front side




Back side

[2] PLASMACLUSTER UNIT


1. Open the open panel.



2. Remove the vertical louvre.



3. Pull wire guard from drain pan hook.




4. Slide the wire guard to the right and remove it.




5. Remove the 2 screw covers.


Insert a flat tip screw driver to hole of screw cover.



6. Unscrew 2 screws.




7. Slide Plasmacluster cover to the back.



8. Replace the Plasmacluster unit.

Disconnect the connector and replace Plasmacluster unit.











CHAPTER 5. INSTALLATION INSTRUCTION

[1].SAFETY PRECAUTIONS

- **Installation must be made in accordance with the installation manual by qualified service personnel.**
Incorrect work can cause electric shock, water leak, fire.
- **Be sure to use the attached accessories parts and specified parts for installation.**
Use of other parts can cause electric shock, water leak, fire, the unit falling.
- **The appliance shall be installed and wired in accordance with national electrical code and by qualified personnel only.**
Wrong connection can cause overheating or fire.
- **After installation has complete, check that there is no leakage of refrigerant gas.**
If the refrigerant gas contact with fire, it will generate toxic gas.
- **Ventilate the room if refrigerant gas leaks during installation.**
If the refrigerant gas contact with fire, it will generate toxic gas.
- **Use the specified electrical cable.**
Make sure the cable is secured in place and that the terminals are free of any excess force from the cable. Otherwise overheating or fire may result.
- **Form the cable so that the control box cover, the cord holder and cable holder are not loose.**
Otherwise overheating, fire or electric shock may result.
- **Tighten the flare nut with a torque wrench according to the specified method.**
If the flare nut is tightened too hard, the flare nut may crack or break after a long time and cause refrigerant gas leakage.
- **When installing the unit, take care not to enter air substance other than the specified refrigerant(R410A) in the refrigerant cycle.**
Otherwise, it can cause burst and injury as a result of abnormal high pressure in the refrigerant cycle.
- **Be sure to connect the refrigerant pipe before running the compressor.**
Otherwise, it can cause burst and injury as a result of abnormal high pressure in the refrigerant cycle.
- **Earth the unit.**
Incomplete earth may cause electrical shock.
- **Install an earth leakage breaker to avoid electric shock in case of leak.**
Use the current-activated, high-sensitivity, high-speed type breaker with a rated sensitivity current of below 30 mA and an operating time of below 0.1 second.
- **Arrange the drain hose to ensure smooth drainage.**
Insufficient drainage may cause water damage to the room, furniture etc.
- **This room air conditioner uses refrigerant R410A.**
Use refrigerant pipes, flare nuts and tools exclusively for R410A.


[2].ACCESSORIES

| ITEMS | Q'ty | APPLICATION | ITEMS | Q'ty | APPLICATION | ITEMS | Q'ty | APPLICATION |
|---|------|---------------------------------------|--|------|--|--|------|---------------------|
| 1 Mounting plate  | 1 | To mount the indoor unit on the wall. | 4 Dry battery  | 2 | For the remote control. AAA batteries. | 7 Manuals  | 1 | Operation manual |
| 2 Long screw 5/32" x 39/32" L (M4.5x30)  | 7 | To fix the mounting plate. | 5 Short screw 3/16" x 13/16" L (M4x20)  | 3 | To fix the remote control holder. (1) To fix the cable cover. (2) | 8 Cable cover  | 1 | To secure the cable |
| 3 Remote control  | 1 | To control remotely. | 6 Remote control holder  | 1 | To mount the remote control on the wall. | | | |

[3].NOTES ON LOCATIONS

1. Keep the air outlet clear of any obstacle so that outgoing air flows smoothly in the entire room.
2. Make a drain hose hole that will allow easy condensate water drainage.
3. Provide sufficient space on both sides and above the unit.
4. The unit must be installed with enough space allowance so that the air filters can be removed and replaced easily
5. Keep TV set, radio and other similar appliances at least 1 m or more away from the unit and the remote control.
6. Keep the air inlet clear of obstacles that could block incoming air, and clean the air filter regularly.
7. The remote control may not function properly in a room equipped with an electronic simultaneous-start or rapid-start fluorescent lighting.
8. Select a location that does not cause loud operation noise and extreme vibrations.

[4].INSTALLATION DIAGRAM




Provide as much installation space as possible for efficient air-conditioning.

Use the refrigerant pipes shown in the table below.

| | Pipe size | Pipe thickness | Thermal insulation |
|-------------|------------------|------------------|--|
| Liquid Side | 1/4" (ø 6.35 mm) | 0.03 in (0.8 mm) | Thickness: 0.2 inch (6 mm) or thicker Material: Polyethylene foam |
| Gas Side | 1/2" (ø 12.7 mm) | | |

- The thermal insulation should cover both the gas and liquid pipes.

[5].INSTALLATION DIMENSION OF INDOOR UNIT




[6].INSTALLATION PROCEDURE

1 PLACING THE MOUNTING PLATE AND MAKING A PIPING HOLE


Installing the mounting plate

- The mounting plate should be installed on a wall which can support the weight of the indoor unit.
- Referring to the following illustration, mark the location for the fixing holes and the piping hole.
 - Recommended fixing holes are marked in circle around the hole. (7 points)
 - Make sure that the mounting plate is horizontally.
 - Secure the mounting plate to the wall with the long screws and check the stiffness.



Making a piping hole

- Drill a piping hole with concrete drill or a hole saw with a 0.2inch (5mm) down ward slant to the outside. the diameter is 2.8inch (70mm).
- Set the sleeve and caps.



2 CONNECTING THE CABLE TO THE INDOOR UNIT




Connecting wires and the ground wire

- Use solid conductor AWG14 or stranded conductor AWG14. (14 AWG or larger if required by local electrical code)
- Use double insulated copper wire with 600 V insulation.
- Use copper conductors only.
- Follow local electrical codes.
- Use a cable which is not lighter than polychloroprene sheathed flexible cord.

- Process the end of the connecting cable for the indoor side.
- Take off the Cable Holder from the backside of the indoor unit.
- Take off the Connection Holder from the Wire Conduit and attach the Connection holder to Cable Holder with Lock Nut. (Fig.2)
- Make the connecting cable get through the Cable holder.
- Attach the Cable Holder and Connection Holder to Cabinet with screw. Refer to "ATTACH THE CABLE HOLDER AND CONNECTION HOLDER". (Fig.3 and Fig.4)
- Insert the connecting cable into the unit from backside.
- Open the Open Panel.
- Connect the Connecting Cable to Terminal Board. (Fig.1)
- Fix the Cacle cover with the screw.
- Tighten the Connection Holder to Wire Conduit.
- Close the Open Panel.


Cautions:

- Be sure to put the cable leads deep into the terminal board and tighten up the screws. Poor contact can cause overheating or fire, or malfunction.
- Be very careful not to confuse the terminal connections. Wrong cabling may damage the internal control circuit.
- Be sure to connect the cable to match the markings on the indoor unit's terminal board and those of the outdoor unit.
- Firmly tighten the lock nut of wire conduit. After tightening, pull the wire conduit lightly to confirm that they do not move.



ATTACH THE CABLE HOLDER AND CONNECTION HOLDER

- Attach Wire conduit to Cable Holder with Lock Nut.
The thread of the installed Wire Conduit should be less than 3/8 in. (10 mm)
- Fix the Cable Holder with screw firmly.



3 SETTING UP THE INDOOR UNIT

Mounting the indoor unit

For right side piping


- (1) Pass the pipes and the drain hose through the piping hole.
- (2) Hook the unit onto the mounting plate.
- (3) Pull the connecting cable into the indoor unit.
- (4) Push the unit and apply the bottom hooks to the mounting plate's support.
- (5) Pull the bottom of the unit to check that the unit is fixed in place.

For left side piping

- (1) Reverse the positions of the drain hose and drain cap. Refer to "Exchange the drain hose".
- (2) Connect the pipes and wrap tape around the insulation of the piping joints tightly not to become thick.
- (3) Pass the pipes, connecting cable and the drain hose through the piping hole.
- (4) Hook the unit onto the mounting plate.
- (5) Push the unit and apply the bottom hooks to the mounting plate's support.
- (6) Pull the bottom of the unit to check that the unit is fixed in place.


Notes:

- Bend the pipes carefully as not to damage them.
- Lay the drain hose below the pipes.




Piping route

For directions 1, 2, 4 and 5, cut out the specific zone without leaving any sharp edge.



Exchange the drain hose

- (1) Remove the screw and pull out the drain hose.
- (2) Pull out the drain cap.
- (3) Reconnect the drain hose to the right and insert the drain cap to the left.
 - Fully insert the drain hose until it stops and fix the screw removed in (1).
 - Insert a hexagon wrench (4 mm diagonal) into the drain cap, and press it fully.




Caution:

After replacing, make sure that both the drain hose and drain cap are firmly inserted.

4 CONNECTING THE DRAIN HOSE


Connecting the drain hose

- (1) Glue and Connect a drain hose.
- (2) Tape over the connecting part.




Checking drainage

- (1) Open the open panel.
- (2) Remove the air filters.
- (3) Pour some water into the drain pan.
- (4) Check the water drains smoothly.



Notes:

- Be sure to lay the drain hose downward for smooth drain flow.
- Be careful not to allow the drain hose to rise, form a trap or leave its end in water, as shown below.
- Coil thermal insulation around a drain hose extension, if running in the room.



5 CONNECTING THE REFRIGERANT PIPES

Flaring the pipe end

(1) Cutting with a pipe cutter
Cut at a right angle.



(2) Deburring
Allow no cuttings in the pipe.

(3) Putting in the flare nut

Connecting the pipes

Connect the pipes for the indoor unit first and then for the outdoor unit.

(1) Tighten the flare nuts by hand for the first 3-4 turns.


(2) Use a wrench and torque wrench to tighten up the pipes.

• Do not over tighten the pipes. It may be deformed or damaged.

(3) Wind coating tape around refrigerant pipes together with drain hose and cable for general.

• Lay the drain hose below the pipes.

• The thermal insulation should cover both the gas and liquid pipe. As insulation, use polyethylene foam 6 mm or thicker.



(4) Flaring


Flare processing dimensions(A)

| Tool | A |
|-------------------|-----------------------------|
| R410A tool | 0-0.02 in (0 - 0.5 mm) |
| Conventional tool | 0.04-0.06 in (1.0 - 1.5 mm) |



(5) Checking

To be flared perfectly circular.
Flare nut not missing.




Flare nut tightening torque

| Pipe size | | Torque |
|-------------|------------------|--------------------------|
| Liquid side | 1/4" (ø 6.35 mm) | 16±2 N·m (1.6±0.2 kgf·m) |
| Gas side | 1/2" (ø 12.7 mm) | 55±5 N·m (5.5±0.5 kgf·m) |


6 HANGING THE REMOTE CONTROL

Fix the remote control holder to the wall with the short screws.



Loading the batteries

- Slide and open the cover.
- Insert the batteries.
- Replace the cover.
- Press the RESET button using a thin stick.




7 TEST RUN


(1) Start the operation with the remote control.

(2) To start test run in cooling, hold down the AUX button on the unit for over 5 seconds until a beep sound is heard and an operation lamp flashes.

(3) Make sure the system runs well.
To stop the operation, press the AUX button again.



(AY-XPC07PU, AYXPC09PU, AY-XPC12PU)



(AY-XPC15PU, AYXPC18PU, AY-XP24PU)

8 ITEMS TO CHECK

- Is the specified power supply voltage used?
- Is the connecting cable fixed to terminal board firmly?
- Is the earth wire connected properly arranged?
- Is the drainage properly?
- Is the indoor unit hooked to the mounting plate firmly?
- Is there any gas leakage at the pipe connection?
- Confirm with the customers whether the 5°F/-15°C AUTO OFF function will be used or not.

EXPLANATION TO CUSTOMER

- Explain to the customer how to use and maintain the system, referring to the operation manual.
- Ask the customer to carefully read the operation manual.
- When the system has been set up, hand the installation manual to the customer.


[7].DETACHING THE UNIT FROM THE MOUNTING PLATE

Push the "△" marks at the bottom of the indoor unit to release the hooks from the mounting plate, and pull the unit toward you.



"△" mark

SHARP PARTS LIST



**SPLIT TYPE
ROOM AIR CONDITIONER
MODELS **AY-XPC15PU**
AY-XPC18PU
AY-XP24PU**

CONTENTS

- [1] INDOOR UNIT PARTS
- [2] ACCESSORY PARTS
- [3] INDOOR PACKING PARTS

*Parts of AY-XPC18PU and AY-XP24PU are still under revision, may change for reliability improvement. New edition of this manual will be issued after revision is completed.


HOW TO ORDER REPLACEMENT PARTS

To have your order filled promptly and correctly, please furnish the following information.

1. MODEL NUMBER
2. REF. NO.
3. PART NO.
4. DESCRIPTION


Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

[1] INDOOR UNIT PARTS




| NO. | PARTS CODE | PRICE RANK | NEW MARK | PART RANK | DESCRIPTION |
|---------------------------------|---------------|------------|----------|-----------|-----------------------------------|
| [1] INDOOR UNIT PARTS | | | | | |
| CYCLE PARTS | | | | | |
| 3 | CCYC-E038JBKZ | CA | N | | CYCLE ASS'Y(AI-XPC15PU) |
| 3 | CCYC-E039JBKZ | CG | N | | CYCLE ASS'Y(AI-XPC18PU,AY-XP24PU) |
| 3-1 | DCOV-A389JBKZ | AL | N | | COVER-L ASS'Y |
| 3-2 | PCOV-B987JBFZ | AH | N | | SIDE COVER R |
| 3-3 | PGID-A200JBFA | AG | N | | EVA COVE L |
| 3-4 | PGID-A201JBFA | AG | N | | EVA COVE R |
| 3-5 | PPFPPE436JBEZ | AK | | | INSULATOR |
| 3-6 | PSEN-A086JBKZ | AP | | | FLARE NUT ASS'Y |
| 3-7 | LHLD-B207JBFZ | AE | N | | THERMISTOR HOLDER |
| 3-8 | PSEN-A080JBKZ | AH | | | FLARE NUT ASS'Y |
| CONTROL BOX | | | | | |
| 4-1 | DBOX-A136JBKZ | BR | N | | CONTROL BOX ASS'Y(AI-XPC15PU) |
| 4-1 | DBOX-A137JBKZ | BL | N | | CONTROL BOX ASS'Y(AI-XPC18PU) |
| 4-1 | DBOX-A149JBKZ | BQ | N | | CONTROL BOX ASS'Y(AI-XP24PU) |
| 4-1-1 | DSGY-F028JBKZ | BL | N | | CONTROL BOARD UNIT(AI-XPC15PU) |
| 4-1-1 | DSGY-F032JBKZ | BL | N | | CONTROL BOARD UNIT(AI-XPC18PU) |
| 4-1-1 | DSGY-F121JBKZ | BL | N | | CONTROL BOARD UNIT(AI-XP24PU) |
| 4-1-2 | GBTN-A015JBFA | AC | N | | BUTTON |
| 4-1-3 | LHLD-A539JBFA | AE | | | CORD HOLDER |
| 4-1-4 | LHLD-B210JBFA | AE | N | | DISPLAY HOLDER |
| 4-1-5 | PCOV-B854JBWZ | AV | | | CONT.BOX COVER A |
| 4-1-6 | PCOV-C099JBWZ | AH | N | | CONT.BOX COVER B |
| 4-1-7 | PCOV-B858JBWZ | AY | | | TERMINAL COVER |
| 4-1-8 | QTANZA090JBZZ | AR | N | | TERMINAL BOARD |
| 4-1-9 | RH-HXA165JBZZ | AS | | | THERMISTOR |
| 4-1-10 | PBOX-A587JBFA | AX | N | | CONTROL BOX |
| 4-3 | PCOV-B988JBFA | AE | N | | DISPLAY COVER |
| 4-4 | PCOV-B989JBFZ | AC | N | | LED COVER |
| 4-5 | LHLD-B233JBFA | AC | N | | CORD HOLDER |
| DRAIN PAN PARTS | | | | | |
| 5-1 | LPLT-A058JBPZ | AC | | | HOSE HOLDER |
| 5-2 | PHOS-A052JBEZ | AM | | | DRAIN HOSE |
| 5-3 | CKITTA087JBKZ | BN | N | | CLUSTER ASS'Y |
| 5-3-1 | CKITTA133AKKZ | BM | | | PLASMA CLUSTER UNIT |
| 5-3-2 | PCOV-B990JBFA | AC | N | | SCREW COVER |
| 5-3-3 | QW-VZG595JBZZ | AK | | | LEAD WIRE |
| 5-3-4 | LHLD-B211JBFA | AG | N | | HOLDER |
| 5-3-5 | LHLD-B212JBFA | AG | N | | COVER |
| 5-4 | DCOV-A390JBKZ | AV | N | | FRONT PANEL ASS'Y |
| 5-5 | DSRA-A403JBKZ | BC | N | | DRAIN PAN SUB ASS'Y |
| 5-6 | GGAD-A076JBTA | AT | N | | WIRE GUARD |
| 5-7 | MARMPA078JBFA | AD | N | | ARM |
| 5-8 | MJNTPA191JBFA | AE | N | | LOUVER LINK |
| 5-9 | MLOV-A574JBFA | AQ | N | | HORIZONTAL LOUVER |
| 5-10 | MLOV-A562JBFA | AE | | | VERTICAL LOUVER |
| 5-11 | NBRG-A026JBFA | AB | | | LOUVER BUSHING |
| 5-12 | NBRG-A038JBFA | AC | | | BEARING C |
| 5-13 | PDAI-A291JBFA | AD | N | | MOTOR BRACKET |
| 5-14 | PGUMMA381JBEZ | AF | | | DRAIN PLUG |
| 5-15 | RMOT-A223JBZZ | AS | | | LOUVER MOTOR |
| FRONT PANEL PARTS | | | | | |
| 6-1 | CWAK-E203JBKZ | AX | N | | FRONT PANEL L ASS'Y |
| 6-1-1 | HDEC-B226JBFA | AL | N | | DECORATION PANEL L |
| 6-2 | CWAK-E202JBKZ | BA | N | | FRONT PANEL R ASS'Y |
| 6-2-1 | HDEC-B227JBFA | AL | N | | DECORATION PANEL R |
| 6-2-2 | TCAUSA002JBRZ | AD | | | UL WARNING LABEL -2 |
| 6-2-3 | TLABCE002JBRZ | AD | N | | WIRING DIAGRAM |
| CABINET & UNIT PARTS | | | | | |
| 7-1 | CMOT-A561JBKZ | BM | N | | FAN MOTOR SUB ASS'Y |
| 7-2 | CHLD-A122JBKZ | AG | | | BEARING ASS'Y |
| 7-3 | DCHS-A833JBKZ | BD | N | | CABINET SUB ASS'Y |
| 7-4 | PCOV-B996JBFZ | AE | N | | MOTOR COVER |
| 7-5 | DPNL-A123JBKZ | BD | N | | OPEN PANEL ASS'Y |
| 7-6 | LHLD-B213JBFA | AD | N | | STOPPER |
| 7-8 | NFANCA149JBEZ | BD | N | | CROSS FLOW FAN |
| 7-9 | PCOV-B994JBFA | AF | N | | PIPE HOLDER |
| 7-10 | PCOV-B851JBWZ | AV | | | BOX COVER |
| 7-11 | PCOV-B995JBFA | AP | N | | GRILL |
| 7-12 | PCOV-B983JBWZ | AE | N | | CABLE HOLDER |
| 7-13 | PFILMA282JBEA | AL | N | | AIR FILTER |
| 7-14 | PGID-A202JBFA | AH | N | | FILTER GUIDE |
| 7-15 | PPLTNA134JBWZ | AX | | | MOUNTING ANGLE |
| 7-16 | TSPC-H648JBRA | AF | N | | NAME LABEL(AI-XPC15PU) |
| 7-16 | TSPC-H655JBRA | AF | N | | NAME LABEL(AI-XPC18PU) |
| 7-16 | TSPC-H815JBRA | AF | N | | NAME LABEL(AI-XP24PU) |
| 7-17 | TCAUSA003JBRZ | AF | N | | UL WARNING LABEL-3 |
| 7-18 | PGID-A127JBFZ | AG | | | GUIDE |

[2] ACCESSORY PARTS



| NO. | PARTS CODE | PRICE RANK | NEW MARK | PART RANK | DESCRIPTION |
|---------------------------|----------------|------------|----------|-----------|---------------------|
| [2]ACCESSORY PARTS | | | | | |
| 1-1 | CRMC-A868JBEZ | BE | N | | REMOTE CONTROL |
| 1-2 | LHLD-A484JBFA | AE | | | HOLDER |
| 1-3 | DHLD-A071JBKZ | AK | N | | CORD HOLDER ASS'Y |
| 1-4 | FFZK-A256JBKZ | AF | | | SCREWS KIT |
| 1-5 | TINS-B404JBRZ | AE | N | | INSTALLATION MANUAL |
| 1-6 | TINSE A760JBRZ | AF | N | | OPERATION MANUAL |
| 1-7 | UBATUA027JBE0 | AE | | | BATTERY PACK |

[3] INDOOR PACKING PARTS



| NO. | PARTS CODE | PRICE RANK | NEW MARK | PART RANK | DESCRIPTION |
|--------------------------------------|---------------|------------|----------|-----------|----------------------------|
| [3] INDOOR UNIT PACKING PARTS | | | | | |
| 2-1 | SPADBA579JBEZ | AP | | | PACKING PAD L |
| 2-2 | SPADBA580JBEZ | AP | | | PACKING PAD R |
| 2-3 | SPAKCE212JBEZ | AS | | | PACKING CASE |
| 2-4 | TLABMB224JBRZ | AE | N | | PRODUCT LABEL (AY-XPC15PU) |
| 2-4 | TLABMB225JBRZ | AE | N | | PRODUCT LABEL (AY-XPC18PU) |
| 2-4 | TLABMB301JBRZ | AE | N | | PRODUCT LABEL (AY-XP24PU) |
| 2-5 | TLAB-F722JBRZ | AE | | | NO CLAMP LABEL |