


G-SERIES INSTALLATION & OPERATING MANUAL

20-01693


G-SERIES HIGH-VOLUME SELF-SERVICE REFRIGERATED DISPLAY CASES

PLEASE NOTE THE FOLLOWING:


1. YOUR MODEL NUMBER IS LOCATED ON THE SERIAL LABEL (USUALLY AT CASE REAR). HOWEVER, LABEL LOCATIONS MAY VARY DEPENDING UPON MODEL.
2. SEE *SERIAL LABEL LOCATION & INFORMATION* SECTION IN THIS MANUAL FOR SAMPLE LABELS.
3. CASES SHOWN IN THIS MANUAL REFLECT FULL & OPEN END PANELS / STRAIGHT OR ANGLED BASES. YOURS MAY DIFFER.
4. SEE "MODELS (AND THEIR RESPECTIVE CASE DIMENSIONS) LISTED IN THIS MANUAL" SECTION FOR ADDITIONAL INFORMATION REGARDING SPECIFIC CASE DIMENSIONS OF STANDARD MODELS AND CDRs.




GHSS656R / Optional Night Air Curtain / Locking Security Cover / Rear Doors With Perforated Acrylic Plenum




GHBS5R.4986A (Remote)




GHSS456R / Optional Night Air Curtain & Locking Security Cover




GHBS5R.4986A (Remote)




GHSEH656RLB (Remote)




GHSS1075RLB.5422




GHSS660R w/Optional Perforated Plexiglas® Sliding Doors




GHSS652RLB Without End Panel




GHSS660R Shown With Optional Night Air Curtain



GHSSAC652R



GHSSACS857R Includes Scale Stand With Isolated Ground Receptacle



GHSS850R



TABLE OF CONTENTS

TABLE OF CONTENTS	2
MODELS LISTED IN MANUAL (AND DETERMINING THEIR RESPECTIVE CASE DIMENSIONS) ...	3
OVERVIEW / TYPE 1 vs. 2 / COMPLIANCE / WARNINGS / PRECAUTIONS / WIRING / PLUGS	4-5
INSTALLATION: REMOVAL FROM SKID, REMOVING LOWER FRONT PANELS	6
INSTALLATION: ADJUSTING FRONT PANELS / ADJOINING UNITS / GLASS SHELVING	7
INSTALLATION: ELECTRICAL CONNECTIONS / BALLAST BOX / LED DRIVER (REMOTE UNITS).	8
INSTALLATION: ELECTRICAL CONNECTIONS / BALLAST BOX / LED DRIVER (SELF-CONTAINED UNITS)	9
INSTALLATION: UNDERSIDE FIELD ACCESS COMPONENTS (REMOTE MODEL GHSSEH456RLB DISPLAYED)	10
INSTALLATION: TOPSIDE FIELD ACCESS COMPONENTS AND TOPSIDE REFRIGERATION LINE ROUTE (REMOTE MODEL GHSS675RLB.5422A DISPLAYED)	11
INSTALLATION: ELECTRICAL CONNECTIONS / OPTIONAL SCALE STAND	12
INSTALLATION: FRAME SUPPORT RAILS / SEALING TO FLOOR / LOCKING CASTERS	13
INSTALLATION: REFRIG. LINES / STUB-UPS / DRAINS / WIRING DIAGRAMS / VENTILATION	14
INSTALLATION: DISPLAY CASE START-UP (CASE / LIGHTS / TEMPERATURE CONTROLLER / SATURATED SUCTION TEMPERTURE)	15
MAINTENANCE: STANDARD LIGHT FIXTURES	16
MAINTENANCE: LED LIGHTS/BRACKETS/SHELVES/DRAIN/TXV	17
MAINTENANCE: REFRIGERATION PACKAGE ILLUSTRATION (FROM SELF-CONTAINED MODEL GHDSS850R)	18
MAINTENANCE: REFRIGERATION PACKAGE ILLUSTRATION (FROM SELF-CONTAINED MODEL GHSS660R)	19
MAINTENANCE: OPTIONAL SLIDING REAR DOORS / PERFORATED ACRYLIC PLENUM	20
MAINTENANCE: OPTIONAL NIGHT AIR CURTAIN ATTACHMENT & OPERATING INSTRUCTIONS .	21
GENERAL CLEANING (TO BE PERFORMED BY STORE PERSONNEL)	22
TROUBLESHOOTING (TO BE PERFORMED BY STORE PERSONNEL)	23
GENERAL CLEANING (BY TRAINED SERVICE PROVIDERS ONLY)	24
TROUBLESHOOTING (BE PERFORMED BY TRAINED SERVICE PROVIDERS ONLY)	25-27
TROUBLESHOOTING - CONDENSING SYSTEM (BY TRAINED SERVICE PROVIDERS ONLY)	28
TROUBLESHOOTING - EVAPORATOR SYSTEM (BY TRAINED SERVICE PROVIDERS ONLY)	29
PREVENTIVE MAINTENANCE (TO BE PERFORMED BY TRAINED SERVICE PROVIDER ONLY)...	30
HONEYCOMB AIR DIFFUSER REMOVAL/INSTALLATION (TO BE PERFORMED BY TRAINED SERVICE PROVIDER ONLY)	31
SERIAL LABEL INFORMATION & LOCATION	32
CAREL® CONTROLLER - PROGRAMMING THE INSTRUMENT.....	33
CAREL® CONTROLLER - USER INTERFACE, SUMMARY TABLES OF ALARMS & SIGNALS	34
CAREL® CONTROLLER - Summary Table of Operating Parameters (After Programming Key)	35
TECHNICAL SERVICE CONTACT INFORMATION & WARRANTY INFORMATION	36

MODELS LISTED IN THIS MANUAL (AND DETERMINING THEIR RESPECTIVE CASE DIMENSIONS)

DETERMINING YOUR MODEL AND ITS CASE DIMENSIONS:

Note 1. Your model number can be found on serial label (usually at case rear). However, serial label placement can sometimes vary depending upon model. See *SERIAL LABEL INFORMATION & LOCATION* section in this manual for serial label samples.

Note 2. Dimensions of most models can be found at www.structuralconcepts.com. Simply enter the case model number into the Product Number Search box. Click the **product specification** link for complete dimensions.

Note 3. If your specific model is not found, contact technical service (phone number is listed at Technical Service section in this manual) for dimensions.

Note 4. CDRs (Customer Design Requests) are listed with a 4-digit suffix. Dimensions are very similar to standard model (pre-suffix) dimensions.

THIS OPERATING MANUAL ENCOMPASSES THE FOLLOWING MODELS (AND/OR THEIR RESPECTIVE CDRs):

G-Series GHSS850R

G-Series GHBSS5R.4986A

G-Series GHSS436R
G-Series GHSS460R.5976
G-Series GHSS636R
G-Series GHSS656R
G-Series GHSS660R
G-Series GHSS852R
G-Series GHSS652RLB
G-Series GHSS656RLB
G-Series GHSS675RLB.5422A
G-Series GHSS852RLB
G-Series GHSS856RLB
G-Series GHSS875RLB.5422
G-Series GHSS1075RLB.5422
G-Series GHSSAC452R
G-Series GHSSAC457R
G-Series GHSSAC652R
G-Series GHSSAC852R
G-Series GHSSAC1252R
G-Series GHSSACS657R
G-Series GHSSACS857R
G-Series GHSSACS1257R

G-Series GHSSEH456RLB
G-Series GHSSEH556RLB
G-Series GHSSEH652RLB
G-Series GHSSEH656RLB
G-Series GHSSEH856RLB
G-Series GHSSEH1056RLB
G-Series GHSSEH1256RLB

OVERVIEW

- These Structural Concepts G-Series® Self-Service merchandisers are designed to merchandise packaged products at 41 °F (5 °C) or less product temperatures (unless custom cases with wire rack shelving).
- Product must be pre-chilled at 41 °F (5 °C) or less prior to being placed in merchandiser.
- Cases should be installed and operated according to this operating manual's instructions to ensure proper performance.
- Improper use will void warranty.

- For Type 2 Conditions: ambient conditions are to be at 60% maximum humidity and maximum temperatures of 80 °F (27 °C).
- If unsure if unit is designed for Type 1 or Type 2 conditions, see identifying label on your case. Location varies depending upon model.

TYPE 1 vs. TYPE 2 UNITS

This unit is designed for the display of products in ambient store conditions where temperatures and humidity are maintained within a specific range.

- For Type 1 Conditions (most cases): ambient conditions are to be at 55% maximum humidity and maximum temperatures of 75 °F (24 °C).

COMPLIANCE

- Performance issues when in violation of applicable NEC, federal, state and local electrical and plumbing codes are not covered by warranty.
- See below compliance guideline.

WARNINGS

- This page contains important warnings to prevent injury or death.
- Please read carefully!

PRECAUTIONS and WIRING DIAGRAMS

- See next page for **PRECAUTIONS** and **WIRING DIAGRAM** information.



COMPLIANCE
 This equipment **MUST** be installed in compliance with all applicable NEC, federal, state and local electrical and plumbing codes.



WARNING
 Risk of electric shock. Disconnect power before servicing unit. **CAUTION!** More than one source of electrical supply is employed with units that have separate circuits. *Disconnect ALL ELECTRICAL SOURCES before servicing.*



WARNING
 Hazardous moving parts. Do not operate unit with covers removed. Fan blades may be exposed when deck panel is removed. Disconnect power before removing deck panel.




WARNING
 Condensate Pan and/or Overflow Condensate Pan is Hot! Disconnect and allow to cool before cleaning or removing from case.

PRECAUTIONS


- Following are important precautions to prevent damage to unit or merchandise.
- Please read carefully!
- See previous page for specifics on **OVERVIEW**, **TYPE**, **COMPLIANCE** and **WARNINGS**.

WIRING DIAGRAM

- Each case has its own wiring diagram folded and in its own packet.
- Wiring diagram placement may vary; it may be placed near ballast box, field wiring box, raceway cover, or other related location.




CAUTION! LAMP REPLACEMENT GUIDELINES
 LED lamps reflect specific size, shape and overall design. Any replacements must meet factory specifications. Fluorescent lamps have been treated to resist breakage and must be replaced with similarly treated lamps.



CAUTION! GFCI BREAKER USE REQUIREMENT
 If N.E.C. (National Electric Code) or your local code requires GFCI (Ground Fault Circuit Interrupter) protection, you **MUST** use a GFCI breaker in lieu of a GFCI receptacle.




CAUTION! POWER CORD AND PLUG MAINTENANCE
 Risk of electric shock. If cord or plug becomes damaged, replace only with cord and plug of same type.



CAUTION! ADVERSE CONDITIONS / SPACING ISSUES

- Performance issues caused by adverse conditions are **NOT** warranted.
- End panels must be tightly joined or kept at least **6-inches** away from any structure to prevent condensation.
- Unit must be kept at least **15-feet** from exterior doors, overhead HVAC vents or any air curtain disruption to maintain proper temperatures.
- Unit must not be exposed to direct sunlight or any heat source (ovens, fryers, etc.).
- Tile floors, low ceilings or small rooms increase noise level. Whisper Cool compressor blankets or remote units resolve noise level issues.
- Keep at least **8-inch** clearance above unit for air discharge (self-contained units only).




CAUTION! CHECK CONDENSATE PAN POSITION AND PLUG
 Water on flooring can cause extensive damage!
 Before powering up unit, check the following:

- Condensate pan **MUST BE** positioned directly under condensate drain.
- Condensate pan plug **MUST BE** securely plugged into receptacle.
- Check that overflow pan is fully functional.

INSTALLATION: REMOVAL FROM SKID, REMOVING VERTICAL LOWER FRONT PANELS

1. Remove From Skid (Rails or Levelers)

- Remove shipping brace that may be securing case to skid.
- Support case to prevent tipping.
- **Caution! Frame Support Rails (or levelers) can be damaged if case hits floor with heavy force!**
- Carefully slide unit to rear of skid and tip backward off skid.
- Illustration may not reflect every feature or option of your particular case.




Note: Case can be repositioned with pallet truck when front lower panel is removed. Blocking may be necessary to obtain adequate height.

2. Remove Case From Skid (Casters)

Remove shipping brackets that may be securing casters to skid


- Place ramp up against skid (to allow case to smoothly slide off from skid).
- Maintain support of case at all times or center of gravity may cause case to fall.
- Unlock Casters. Roll unit to rear of skid. Roll down ramp and off from skid.

Note: Illustrations shown reflect a general outline of sample cases and do not reflect features or options of your particular model.



3. Removing Vertical Lower Front Panels

Note: No screw removal required: Simply lift lower front panel up (off hooks) and out (away from case).




Hooks For Lower Front Panel

Note
Lower Front Panel
Removed & Reversed
For Illustrative
Purposes Only

Slots For Lower Front Panel

Note: Illustration below reflects case unit with front flat glass. Your case may not reflect every feature or option of this particular case. However lower front panel removal illustration will apply.





View of Front Panel
(Removed & Reversed)

4. Bolting and Caulking Units Together

Follow these steps to assure a secure, level lineup.

- A. Begin all lineups leveling from highest point of floor.
- B. After the 'first' case is level, apply industrial grade butyl caulk on non-visible areas (at case end). Use industrial grade silicone sealant on visible areas (at case end).
- C. **Form Two (2) Caulk/Sealant Lines:** (Sanitation and Refrigeration). See illustration at mid-right for outline of caulk/sealant lines.
- D. Line up 'second' case bolt-hole to bolt-hole to 'first' case.
- E. Using SCC-supplied bolts (found in hole locations **OR** in installation packet), insert bolts in bolt hole locations (shown at top-right). You may need to remove decking to access lower bolt holes.
- F. Caution! Front of cases **MUST** be flush with each other! After leveling, all cases to be same height.
- G. Using SCC-supplied nuts & bolts, **lightly tighten** each of the 5 to 8 bolts in a cross-wise pattern. Work your way around the pattern, tightening more firmly at each pass. **Do not** firmly tighten one bolt and then start on the next!
- H. After the cases are bolted together, level the 'second' case. Repeat this process for each case to be adjoined.
- I. After all lined-up cases are level, seal all seams with industrial grade silicone sealant.
 - See illustration at top-right.



Note: Illustration above reflects dual case unit with glass in end panels. Your case may not reflect every feature or option of this particular case.

5. Glass Shelving

If your unit has glass shelving, it will be packed separately.

Caution! Carefully remove from packaging.

- Grasp firmly and carefully install.
- **Caution! Check that plastic edging is intact before placing glass shelving onto brackets!**
- Plastic edging must NOT be removed from glass shelves. Contact Structural Concepts for replacement edging (see **TECHNICAL SERVICE CONTACT INFORMATION** section).
- Check that glass shelving is in proper position before placing product in case.
- See illustrations at mid and lower-right showing both curved and flat front glass (optional).

6. Electrical Connections (Remote Units)


Ballast / LED Driver

Remove front panel. See **INSTALLATION: REMOVAL FROM SKID, REMOVING VERTICAL LOWER FRONT PANELS** section in this manual for instructions.

- Stub-up connections are in ballast box.
- Remove ballast box / LED driver box cover.

- Knockouts are on the underside of ballast box / LED driver box making electrical connections.
- Voltage rating is on serial label at case rear.
- Remote case illustration shown below reflects flat front glass. Your case may differ (but electrical layout will be accurate).
- Note: Wiring process must be performed by certified electrician only.

Note: Illustration reflects remote Model GHBSS5R.4986A with front panel removed for illustrative purposes only. See next page for self-contained model GHDSS850R.



INSTALLATION: ELECTRICAL CONNECTIONS / BALLAST BOX / LED DRIVER (SELF-CONTAINED)

7. Electrical Connections (Self-Contained Units)


Front Ballast / LED Drivers

Remove front panel. See **INSTALLATION: REMOVAL FROM SKID, REMOVING VERTICAL LOWER FRONT PANELS** section in this manual for instructions.

- Stub-up connections are in ballast box.

- Remove electrical raceway cover.
- Knockouts are on the underside of electrical race way for making electrical connections.
- Voltage rating is on serial label at case rear.
- Self-contained case illustration shown below reflects curved front glass. Your case may slightly differ (but electrical layout is accurately portrayed).
- Wiring process must be performed by certified electrician only.

Note: Illustration reflects self-contained Model GHBSS5R.4986A with lower-front panel and electrical raceway cover removed for illustrative purposes only. See previous page for remote model GHDSS850R.




INSTALLATION: UNDERSIDE FIELD ACCESS COMPONENTS (MODEL GHSSEH456RLB DISPLAYED)

8. Underside Field Access Box Components and Underside Refrigeration Line Route

- On certain models, field access components (a variety of which is shown below) are at underside.
- Model GHSSEH456RLB is illustrated below; your underside component layout may vary.

- Caution! Only certified electricians are to perform electrical connectivity duties.
- To access large field access box, two screws (at case front) must be removed and box slid out.

Note: Illustration Reflects Remote Model GHSSEH456RLB With Underside Electrical Components. Your Case May Vary.



INSTALLATION: TOPSIDE FIELD ACCESS COMPONENTS (MODEL GHSS675RLB.5422A DISPLAYED)




9. Topside Field Access Box Components and Topside Refrigeration Line Route

- On certain models, field access components (a variety of which is shown below) are topside.
- Model GHSS675RLB.5422A is illustrated below; your topside component layout may vary.
- **Caution!** Only certified electricians are to perform electrical connectivity duties.

- To access large field access box, two screws (at case rear) must be removed and cover lifted up and off.
- ***Note:** See **MAINTENANCE: OPTIONAL NIGHT AIR CURTAIN ATTACHMENT...** section in this manual for night curtain operating instructions.

Note: Illustration Reflects Remote Model GHSS675RLB.5422A With Topside Electrical Components. Your Case May Vary.


4" x 4" Field Access Box




INSTALLATION: ELECTRICAL CONNECTIONS / OPTIONAL SCALE STAND

10. Optional Scale Stand

- Scale stand is on model GHSSACS857R (and may be on additional models).
- Scale stand is provided with isolated ground receptacle.
- Depending upon options chosen, scale stand may be at either left or right of case.




Model GHSSACS857R Shown Below
With Scale Stand and Receptacle.
Your Model May Vary.



11. Cases With Levelers: Adjust Levelers

- After case is in position, adjust case so it is level and plumb (see illustration at right).
- You may need to remove front and/or rear Toe-Kick to access levelers.
- Use adjustable wrench (and possibly a pry bar) to adjust leveler.
- Do not use pry bar on toe-kick (it may buckle).
- Do not use pry bar on end panel (it may chip).
- Use pry bar ONLY on base frame to avoid damaging case.
- Use a block to reach base frames with pry bar.
- Caution! After leveling, both front and top of case lineups must be flush with each other!
- See illustrations directly below.





12. Cases With Frame Support Rails: Shim

- Illustration below shows case with frame support rails. End panel has been removed for illustrative purposes only.
- Shims will be provided with all cases that have frame support rails.
- Use shims to level case.
- See illustration below-right.
- **Note:** After case is in position, it must be sealed to floor to prevent entry or leakage of liquid or moisture.

13. Cases With Casters: Lock and Unlock

- To lock casters, press down on lever.
- To unlock casters, pull lever up.
- See illustration below-left.



14. Refrigeration Line Stub-Up Connections (Remote Units)

- Remove front panel.
- Refrigerant stub-up access opening is at the front on the left hand side of the base (see illustration at top-right).
- Stub-up connections are accessed from inside the case.
 - Remove interior decks.
 - Remove fan shroud assembly.
- Line connections are in the tub front, on the left hand side
- Remove foam material from the entry hole provided in the tub drain trough.
- Route refrigerant lines through access hole.
 - Run case-to-case connections through cutouts in base.
 - Sweat the high and low pressure connections.
- Fill access hole with suitable filler to insure watertight integrity of tub.
- Illustration at top-right may not reflect every feature or option of your particular case.


15. Refrigeration Drain Connection (Remote Units)

- Depending upon drain access needs, either front or rear panel may be removed to gain access to drain stub-up.
- 1.5" male PVC stub-up connection is under the case on the right hand side.
- Drain stub-up may be at case center in extended length cases.
- Connect tub drain to floor drain. Maintain 1/4"-fall per foot to provide proper drainage.
- Illustration at top-right may not reflect every feature or option of your particular case.

16. Condensate Pan / Drain Position (Self-Contained Units)

- Remove the front panel by lifting up & out.
- Slide the condenser unit out from case.
- Condenser unit access is now available.
- Insure that the condensate pan is installed under the PVC condensate drain trap.
- Insure that the condensate pan is plugged into the receptacle inside base.
- Lower rear panel back into place.

Note: Illustration Below May Not Reflect Every Feature or Option of Your Particular Case




- See ***Drain, Hose and Bracket Placement*** section in Operating Manual for details.

17. Electrical Wiring Diagram

- Each case has its own wiring diagram folded and in its own packet.
- Wiring diagram placement may vary; it may be placed near condenser fan cover, ballast box, raceway cover, or other related location.

18. Ventilation and Clearance

- **Self-Contained** refrigerated cases must maintain airflow clearance of 6" (minimum) to 12" (recommended) at front and rear.
- Restriction of air can void warranty.
- Illustration below may not reflect every feature or option of your particular case.



Check air grilles for obstructions. Maintain airflow clearance of 6" (min.) to 12" (recommended) at front & rear.

19. Display Case Start-Up

A. Case



- Remote: Case will power-up when properly field wired (or plugged in).
- Self-Contained: Turn main power on.
- After case is powered up, lift curved or flat front glass by grasping lift handle and raising (see illustration at right).
- Note: Illustration at right reflects flat front glass. Yours may have curved front glass.
- Lift deck to check that coil fans are running.
- Coil fans (and in self-contained units, compressor motor) should turn on.

B. Lights

- Turn lights on.
 - > Switch is either at case front, attached to rear plenum, above top shelf (as shown at right) or at case rear (as shown at top-right).
 - > In cases with NO SWITCH, lights will come on when case powers up.
- All lights should come on at the same time. If bulbs are fluorescent, first time lighting may require a short warm-up period. LEDs have no warm-up period.
- Slightly dim / flickering of new bulbs is normal. If lights do not turn on, check raceway plugs.
- Lighting is wired in series so **all lights must be plugged in or receptacles capped** for case lights to be on. See illustration at right.
- LED Lights: If lights do not come on, check that plug is properly inserted into socket.

C. Temperature Controller (All Self-Contained Units and some Remote Units)

- Check that compressor symbol light is on.
- Compressor will likely be identified with:
 - ⊗ Compressor symbol (common in Carel® temperature controllers).
 - After case has run for a few minutes, check that temperature starts to drop.
 - If temperature controller does not begin cooling (in a few minutes) see temperature controller section in this operating manual for instructions.
 - Remote units (without temperature controller on case): Verify that refrigeration requirements listed on serial label (found on the case) are being met.



D. Saturated Suction Temperature (Remote)

- See serial label on case for suction temperature requirements and BTU requirements.
- See serial label on case for defrost schedule and temperature termination parameters.

Note: See *INSTALLATION* section in manual for:

- *Front Panel adjustment and removal*
- *Angled Base adjustment and removal*
- *Vertical Base adjustment and removal*

1. Light Fixtures

Warning! Disconnect power before providing maintenance and service to unit.

Caution: Lamps have been treated to resist breakage and must be replaced with similarly treated lamps.

Note: Warranty will be void if claims arise from negligence, misuse of goods, extreme environmental conditions or improper maintenance. See *Overview And Warnings* section in this operating manual.

Light fixtures are located on underside of shelf assemblies and at the top inside of case. See illustration at top-right for locations.

Removal of lamp:

- Rotate lamp (1/4-turn) either direction to disengage (upper or lower) pins/contacts from lamp-mounting sockets.
- Remove bulb by applying even pressure from back side at the bulb ends and pulling the remaining contact from sockets.
- See illustrations at mid and lower-right.


Installation of lamp:

- Align pins with slot.
- Insert pins into socket by rotating the bulb 1/4-turn to secure either the (upper or lower) pin contacts into the sockets.
- Rotate remaining bulb contacts (1/4-turn) into remaining lamp mounting socket contacts.
- See illustrations at right.



See next page for LED Light Fixture information

2. Thermometers

- Thermometers are located at rear plenum.
- Thermometers reflect internal air temperature only (not actual food temperature).
- Use probe thermometers to determine actual product temperatures.
- See illustration at right for common location of thermometer (your location may slightly vary).




Above illustration has end panel removed for illustrative purposes only.




1. LED Light Removal / Replacement

- LED lights rarely require change-out.
- Contact Structural Concepts' Technical Service Department for replacement parts (see **Technical Service** section of this guide).
- To remove LED light fixture, disconnect existing LED light from its brackets or self-adhesive tape.
- Then, firmly grasp LED light while applying outward pressure to brackets.
- Twist the LED away from the bracket to release.



2. Plug And Cord Positioning

- Plug is to connect to LED light at raceway side of case.
- Before attaching LED light to case, plug must connect to LED properly without cord doubling-back.
- See photos of proper vs. improper connections.




3. Proper Plug Insertion Into LED Light

- Plug must be inserted into LED light properly or the LED will not light up.
- Oval form of plug is to connect to LED light oval form.
- See illustration at right.

See previous page for Standard Light Fixture information.

4. Bracket Retainer Removal

- To remove brackets, it may be necessary to remove the nylon shipping bracket retainers.
- Pliers will be required to accomplish this task.
- See illustration at top-right for location of bracket retainers.




5. Shelf Assembly Removal

- Remove glass shelves
- For lighted shelving, unplug the light cord.
- Remove rear shelf support.
- Remove shelf light cover from brackets.
- Lift brackets up and out.

6. Drain and Thermostatic Expansion Valve (TXV)

Access


- The drain and thermostatic expansion valve are both accessible from the front of the case.
- Unplug the fans (one plug per side) and remove the fastener from the access panel in the front right (or left) corner of the unit.
- The drain and the thermostatic expansion valve (TXV) are directly below the access panel.



MAINTENANCE: REFRIGERATION PACKAGE ILLUSTRATION (FROM S.C. MODEL GHDSS850R)

7. Refrigeration Package Configuration


- Illustration shown is from self-contained model GHDSS850R.
- Your particular refrigeration package may have a slightly different refrigeration package layout.



MAINTENANCE: REFRIGERATION PACKAGE ILLUSTRATION (FROM S.C. MODEL GHSS660R)

8. Refrigeration Package Configuration

- Illustration shown is from self-contained model GHDSS660R.
- Your particular refrigeration package may have a slightly different layout.



9. Rear Sliding Doors/Perforated Acrylic Plenum (Optional) is Illustrated Below


- Rear sliding doors have metal brackets connected to perforated acrylic plenums.
- These perforated acrylic plenums are designed to maintain proper refrigerated temperature.
- When sliding rear doors open, the perforated acrylic plenums also slide open (allowing access to contents inside case).
- Be sure to completely close the rear sliding doors after accessing case contents.

10. Rear Sliding Door Removal

- Rear sliding doors can be removed WITHOUT removing the perforated acrylic plenum.
- Simply slide rear sliding doors to case center, lift upward and out. Replace in reverse order the doors were removed.

11. Perforated Acrylic Plenum Removal


- Access perforated acrylic plenums from front of case.
- Simply lift the pieces up and out of case.
- Replace in reverse order they were removed.



12. Optional Night Air Curtain Attachment & Operating Instructions

1. Use caution when handling night air curtain.
2. Display case may come with night air curtain already attached. If not, a retrofit kit will be provided. If using SCC-supplied retrofit kit, place night air curtain on top of case as shown.
3. Grasp the handle and pull downward to desired location OUTSIDE of the acrylic air deflector (see illustration below).
4. To return night air curtain to its retracted position, grasp handle, lift up and away from its magnetic attachment and carefully wind night air curtain back into roll.
5. **Caution!** Do not allow spring-loaded night air curtain to freely snap back into roll. Doing so can eventually destroy night air curtain's tension and retractability.
6. To entirely detach night air curtain from case, carefully return curtain into its housing. Lift night air curtain straight up and off. Note, due to magnet strength, two people may need to grasp each end of night air curtain and lift upward together.
7. Store in safe place, where night air curtain will not be damaged.

***NOTE: THE
BELOW
ILLUSTRATION
MAY NOT
EXACTLY
REFLECT
EVERY
PARTICULAR
CASE'S
FEATURES OR
OPTIONS.***



GENERAL CLEANING (TO BE PERFORMED BY STORE PERSONNEL)

AREA TO CLEAN	FREQ.	INSTRUCTIONS
Case Exterior	Daily	Acrylic: Clean any acrylic surfaces (including air deflectors and with a mild soap and water solution and a soft cloth. Caution! Never use ammonia-based cleaners on acrylic. Incorrect cleaning agents or abrasive cleaning cloths cause surface to 'cloud' over time.
	Daily	Glass / Mirrors / Shelving: Clean side glass, glass shelves, and mirrors with a household or commercial glass cleaner.
	Daily	Shelves/Decking: Non-glass shelves and decking can be cleaned with a warm soap and water solution and soft cloth.
	Daily	End Panels, Front Panel, Toe-Kick, etc.: Wipe off all surfaces with warm water and mild soap solution and non-abrasive cloth.
	Weekly	Wood, Laminate and Painted Surfaces: Clean with mild soap and water solution and a soft cloth.
	Weekly to Monthly	(Self-Contained Cases Only) Air Filter (With Magnetic Strip) on Rear Grille (Optional): <ul style="list-style-type: none"> • Depending upon environment, it may be necessary to clean filter as often as weekly. Filter MUST be cleaned at least monthly. • Remove from case. Submerge in warm, soapy water. Use soft-bristled brush to remove dust, grease and grime that collects on filter. Rinse thoroughly. After filter has dried, return to case. • See MAINTENANCE FUNDAMENTALS section in this manual for illustrations.
Case Interior	Daily	Shelves/Deck: Shelves/Deck can be cleaned with a warm soap and water solution. For stubborn stains/residue, decks can be removed and cleaned with soap and water solution or submersed in hot, soapy water solution. Rinse thoroughly. Dry. Return to case.
	Weekly	Shelving Brackets / Air Return Grilles / Decking <ul style="list-style-type: none"> • Wipe off shelving brackets, air return grilles and decking with moist cloth. • Shelving brackets can be removed for more thorough cleaning. • Air return grilles can be removed for more thorough cleaning. • Decking is NOT to be removed by store personnel.
	Monthly	Condenser Coil: Vacuum or brush grille condenser coil at case front. Use metal or fiber brush to remove dust and dirt that can collect on condenser coils. Be careful not to damage the fins on the coil. See INSTALLATION section in manual for side panel removal information.

TROUBLESHOOTING (TO BE PERFORMED BY STORE PERSONNEL)

CONDITION	TROUBLESHOOTING
Case Not Lining Up	See INSTALLATION section in manual for instructions on properly aligning case (alongside other cases) and adjusting levelers (or rails).
Water Is On The Floor	Call service provider.
Fan Emits Excessive Noise	Call service provider.
Case Lights Are Not Working	Check that Light switch is in the <i>on</i> position.
	Check that ALL of the light cords and plugs are properly connected. See MAINTENANCE FUNDAMENTALS - STANDARD LIGHT FIXTURES or MAINTENANCE FUNDAMENTALS - LED LIGHTS section in manual.
	If case lights still do not come on, call service provider.
Case is Not Holding Proper Temperature	If a large amount of warm product was added to the case, it will take time for the temperature to adjust. Product must be pre-chilled before placing in case.
	Check that the case is not in the sun or near a heat or air-conditioning vent. See OVERVIEW / TECHNICAL INFORMATION / WARNINGS section in this manual for specifics.
	If case is located near front doors, temperature fluctuation can hinder unit's ability to maintain temperature.
	Check that air filter and condenser coil has been cleaned. See GENERAL CLEANING (TO BE PERFORMED BY STORE PERSONNEL) section in this manual for specifics.
	Check air return grilles (area at front of decking) for obstructions. DO NOT set product on air grilles as this will prevent proper airflow!
	If case still is not holding proper temperature, call service provider.

GENERAL CLEANING (TO BE PERFORMED BY TRAINED SERVICE PROVIDERS ONLY)

AREA TO CLEAN	FREQUENCY	INSTRUCTIONS
Case Interior	Monthly	<p><u>Evaporator Fan Shroud Area (Under Decking):</u> <i>Caution! Due to rotating fans in area, turn off case and disconnect plug from wall outlet before beginning fan shroud (and surrounding tub area) cleaning!</i> 1) Turn off power. 2) Remove decks from case. 3) Clean fan shroud area (and surrounding tub area) with moist cloth.</p>
	Quarterly	<p><u>Tub & Drain:</u> <i>Caution! Due to rotating fans in area, turn off case and disconnect plug from wall outlet before beginning tub & drain cleaning!</i> Vacuum tub under decks. Clean with soap and water solution. Wipe dry with clean cloth. Keep drain free of debris to prevent clogging.</p>

CONDITION	TROUBLESHOOTING
Case Not Lining Up	See INSTALLATION section in manual for instructions on properly aligning case (alongside other cases) and adjusting levelers.
Water Is On The Floor	<p>Caution! Water on flooring can cause much damage! Until cause is determined (and repaired), following these procedures:</p> <ul style="list-style-type: none"> • Use wet-dry vacuum (or mop & bucket) to remove standing water. • Use 'catch pans' for water to drain into. Swap out regularly until case has completely drained. <p>Note: See <i>Drain, Hose and Bracket Placement Illustrations</i> sheet in this manual for views of different condensate systems used in display cases.</p>
	Check that the drain trap is free of debris.
	Check that the drain hose is correctly positioned over condensate pan (or floor drain, for remote units).
	Check store conditions. To prevent condensation in Type 1 environments, maximum conditions are to be 55% humidity / 75 °Fahrenheit. For Type 2, maximum conditions are to be 60% humidity / 80 °Fahrenheit. See serial label (at case rear near main power switch) for case type.
	Check condensate pan float for proper operation (Heat Rod Condensate System only).
	Check that condensate pan is properly plugged in or connected.
	<p>Caution! Condensate pan may be malfunctioning (electrical heat rod condensate system). If so, water will overflow pan and seep onto flooring causing damage! Until condensate pan is functioning (or is replaced), following these procedures:</p> <ul style="list-style-type: none"> • Use wet-dry vacuum (or mop & bucket) to remove standing water. • Use 'catch pans' for water to drain into. Swap out regularly until case has completely drained.
	<p>Caution! Disruption of power can cause water to overflow pan and seep onto flooring causing damage! Check that power to case is constant. Until power is restored, following these procedures:</p> <ul style="list-style-type: none"> • Use wet-dry vacuum (or mop & bucket) to remove standing water. • Use 'catch pans' for water to drainage. Swap out regularly until evaporation of case is complete (or until power is restored). <p>When power to case is restored, condensate pan should function properly and water will no longer overflow onto flooring.</p>
	<p>Caution! Wicking material may be dirty or worn and need replacement (Hot Gas Condensate system only).</p> <ul style="list-style-type: none"> • Slide refrigeration system out from under unit. • After refrigeration system has been carefully slid out from under unit, replace wicking material with new. If wicking material is not available, contact Structural Concepts®. See toll-free number at last page of this operating manual.

CONDITION	TROUBLESHOOTING
Fan Emits Excessive Noise	Check that the case is aligned, level and plumb.
	Check evaporator fan for cleanliness.
	Unplug/power off fan motors. Check motor shaft for bearing wear.
	Check that fan motors are securely mounted in brackets.
	Verify that fan blades are securely mounted to fan motor.
	Check that nothing is preventing blade rotation.
	Check that the fan shroud is properly secured.
Fans Are Not Working	Check that the MAIN power switch is on.
	Check that fans are plugged in at the fan shroud.
	Check for foreign material obstructing fan performance.
	Check that fan blades freely rotate within fan shrouds
	Check that power is going to fans
	Check that fan wiring is connected on terminal blocks.
Digital Control Display Is Blank	Check that the MAIN power switch is on.
	Check the circuit breaker box for tripped circuits.
System Not Operating	Check that the utility power is on.
	Check that the MAIN power switch is on.
	Check the circuit breaker box for tripped circuits.

CONDITION	TROUBLESHOOTING
Case Lights Are Not Working	Check that Light switch is in the <i>on</i> position.
	Check that ALL of the light cords and plugs are properly connected. See <i>MAINTENANCE - LIGHT FIXTURES (LED LIGHT FIXTURES)</i> section.
	Service Technicians Only: Check voltage at LED drivers. If voltage is entering but not exiting, LED driver may be faulty.
Control Display Is Flashing	See your case's serial label for your model's specified settings. See <i>SERIAL LABEL LOCATION & INFORMATION LISTED / TECH INFO & SERVICE</i> for label location, etc.
Case Is Not Holding Temperature	If a large amount of warm product was added to the case, it will take time for the temperature to adjust. Unit needs product to be pre-chilled.
	Temperature changes during defrost mode but will return to normal. Fourth LED will indicate defrost cycle in progress.
	Check that case is not in sun or near a heat or air-conditioning vent. See <i>OVERVIEW AND WARNINGS</i> section in manual for adverse conditions/spacing issue parameters.
	If case is located near front doors, temperature fluctuation can hinder unit's ability to maintain temperature. See <i>OVERVIEW AND WARNINGS</i> section in manual for adverse conditions/spacing issue parameters.
	Check that magnetic air filter (attached to rear grille) has been cleaned. See <i>GENERAL CLEANING (TO BE PERFORMED BY STORE PERSONNEL)</i> section in operating manual for instructions.
	Check that condenser coil has been cleaned.
	Check air return grilles for obstructions.
	Check sight glass for flashing and/or low charge.
	Check Set Point Temperature; it may be adjusted too high.
Condensing Unit Is Not Operating	Check that the power is turned on.
	Determine if temperature controller settings are properly set. See your case's serial label for your model's specified settings. See <i>SERIAL LABEL LOCATION & INFORMATION LISTED / TECH INFO & SERVICE</i> section in manual for label location, etc.

TROUBLESHOOTING - CONDENSING SYSTEM (BY TRAINED SERVICE PROVIDERS ONLY)

CONDITION	TROUBLESHOOTING
Head Pressure Too High	Check that the Condensing Coil is not dirty or covered.
	Check that Condensing Fans are working.
	Check that refrigerant is not overcharged.
	Check to verify that a non-condensable is not in the system.
	Check that Liquid Line Drier is not plugged.
	Check that there are no close-offs around Condensing Coil.
	Check Set Point Temp.; it may be adjusted too high.
	Check System Operating Temperatures.
	Check that Store Ambient Temperature isn't above maximum allowed. See <i>Overview and Warnings</i> Section.
Head Pressure Too Low	Check that Refrigerant Charge isn't too low.
	Check that Suction Pressure isn't too low.
	Check to verify that Compressor Valves aren't bad.

TROUBLESHOOTING - EVAPORATOR SYSTEM (BY TRAINED SERVICE PROVIDERS ONLY)

CONDITION	TROUBLESHOOTING
Low Suction Pressure	Check that the Refrigerant doesn't have a low charge.
	Check that the Thermostatic Expansion Valve (TXV) isn't restricted.
	Check that Liquid Line or Filter isn't restricted.
	Check that Evaporator Motors are working.
	Check that High Superheat doesn't need adjusting.
	Check that the Thermostatic Element charge isn't depleted.
	Check that there is air no seepage of air around Condensing Coil.
	Check that the Coil is not iced up.
High Suction Pressure	Check that Refrigerant Charge isn't too high.
	Check that Compressor Valves aren't bad.
	Check that the Cooling Load isn't high.
	Check that Superheat Adjustment isn't low.
	Check TXV Bulb Installation a. Poor thermal contact. b. Warm location.
	Check Compressor: Low capacity means it is undersized for its application.

PREVENTIVE MAINTENANCE (TO BE PERFORMED BY TRAINED SERVICE PROVIDER)

WARNING! TURN OFF CASE BEFORE PERFORMING PREVENTIVE MAINTENANCE!

PREVENTIVE MAINTENANCE	FREQ.	INSTRUCTIONS
Case Exterior	Quarterly	<p><u>Condensing Coil:</u></p> <ul style="list-style-type: none"> • Remove panel to access area by lifting up and off or by screw removal (depending on case). • Use air pressure or industrial strength vacuum; clean dust and dirt that may collect on the Condenser Coil. • Caution! Airborne dust can contaminating food! Use wet rags to cover area where air pressure is blowing. • Warning! Coil fins are sharp. Handle with care! • Return panel to case.
	Quarterly	<p><u>Refrigeration Package/Compressor Area:</u> <i>Caution! Be certain to disconnect power from case before cleaning Refrigeration Package!</i></p> <ul style="list-style-type: none"> • Warning! Condensate Pan Is HOT! Disconnect power from case and allow to cool before cleaning condensate pan! • Slide/Roll compressor package out from under case. • See REFRIGERATION FUNDAMENTALS section for in-depth instructions on accessing the condensate pan. • Use a scrub-brush and a de-scaling solution such as CLR® (to prevent corrosion, lime and rust). Follow instructions as to proper dilution, safety precautions and scrubbing method. • Electric heater coil condensate pans can be removed and cleaned. • After thoroughly cleaning pan with scrub-brush and solution, rinse thoroughly with clean water (in spray bottle) and wipe dry with sponge or paper towel. • Use moist cloth to wipe off dust & debris that collects on various parts (fans, sight glass, overflow pan, etc.). • Slide refrigeration assembly back under case. • Replace front panel and lower grille via hooks (no screws required).
	Quarterly	<p><u>Under Case Cleaning:</u> Once refrigeration package is clear of unit, vacuum under case to remove dust and dirt that may collect under case.</p>
	Quarterly	<p><u>Honeycomb:</u> Check honeycomb air diffuser to determine whether it is dirty. If dirty, remove from case and clean. See MAINTENANCE FUNDAMENTALS - HONEYCOMB AIR DIFFUSERS (SERVICE TECHNICIANS ONLY) section of this manual (next page) for cleaning specifics.</p>
Case Interior	Quarterly	<p><u>Tub Area (Evaporator Coil, Drain, Fans, Brackets):</u></p> <p>Caution! Disconnect power from the case before cleaning tub, coil, fan, motor and drain area!</p> <ul style="list-style-type: none"> • Use vacuum to clean entire area. • After vacuuming, clean area with warm water, clean cloth, and mild soap solution. • Remove any debris that may clog drain. • Wipe down fan blades, motors and brackets with moist cloth.

Honeycomb Air Diffuser Removal

See **PREVENTIVE MAINTENANCE (TO BE PERFORMED BY TRAINED SERVICE PROVIDER)** section in this manual for cleaning frequency.

A. Wedge a non-metallic device of suitable strength (such as a ballpoint pen) between the honeycomb and the end panel.

Caution! Use care not to dislodge the heating wire (that prevents condensation on the lamp assembly).

B. Apply pressure to collapse the honeycomb to allow it to be pulled out of honeycomb retainer.

C. Carefully pry downward and away from the honeycomb retainer.

Clean honeycomb with warm water and soap solution. Submerge if necessary. Use brush to dislodge stubborn or sticky residue. Dry by using vacuum's blow mode (vs. suction mode).


Honeycomb Air Diffuser Installation

D. Squeeze honeycomb to allow it to fit into the honeycomb retainer.

E. Carefully slide honeycomb into place.





F. Adjust honeycomb so that it fits flat against retainer. It must not be wavy or out of position.

Note: For honeycomb air diffusers in other locations, these same general instructions apply.






Serial Label Location & Information Listed / Technical Information & Service

- Your model number can be found on serial label (usually located at case rear). However, serial label location can sometimes vary depending upon model.
- Serial labels contain electrical, temperature and refrigeration information, as well as regulatory standards to which the case conforms.
- For additional technical information and service, see the *TECHNICAL SERVICE* page in this manual for instructions on contacting Structural Concepts' Technical Service Department.
- See images below for samples of both refrigerated and non-refrigerated serial labels.

 <p>Structural Concepts 888 E. Porter Rd · Muskegon, MI 49441</p>		 <p>ENCORE[®] SERIES</p>		<p>MODEL HV74RSS SCROLL SERIAL NO.</p>	
<p>FOR PARTS AND SERVICE CALL 1-800-433-9489</p>		<p>SAMPLE ONLY</p>			
  <p>3048256</p>		<p>ELECTRICAL RATING</p>		<p>120/1/60 24A</p>	
<p>CONFORMS TO UL STD 471</p>		<p>REFRIGERANT</p>		<p>R404A AMOUNT ?? OZ</p>	
<p>CONFORMS TO NSF STD 7</p>		<p>DESIGN PRESSURE</p>		<p>HIGH 450 LOW 200</p>	
<p>CERTIFIED TO CAN/CSA STD C22.2 NO 120</p>		<p>MINIMUM CIRCUIT</p>		<p>30A</p>	
		<p>MAXIMUM OVERCURRENT</p>		<p>30A</p>	
		<p>SAMPLE ONLY</p>			
<p>Super Heat Temp</p>		<p>8-10°F</p>		<p>SAMPLE ONLY</p>	
<p>BTUH Requirements</p>		<p>9,738 BTUH @ 20° F SST</p>			
<p>Defrost</p>		<p>6 defrosts per day, 45° F termination, 45 min. failsafe</p>			

----- Sample Serial Label For Refrigerated Case -----

 <p>Structural Concepts 888 E. Porter Rd · Muskegon, MI 49441</p>		 <p>Addenda[®]</p>		<p>PC5682 txtRemote</p>	
 <p>3048256</p>		<p>120 VOLTS 60 HZ SINGLE PHASE 1.84AMP</p>			
<p>CONFORMS TO UL STD 65</p>		<p>FOR PARTS OR SERVICE CALL</p>			
<p>CERTIFIED TO CAN/CSA</p>		<p>STRUCTURAL CONCEPTS</p>			
<p>STD C22.2 NO 120</p>		<p>AT</p>			
		<p>1-800-433-9489</p>		<p>SAMPLE ONLY</p>	
		<p><small>N/A</small></p>			

----- Sample Serial Label For Non-Refrigerated Case -----

CAREL

ir33 platform

Integrated Electronic
Microprocessor Controller




Programming The Instrument

To Modify The Setpoint

Set Press and hold the “SET” key for at least 1 second.

▲/aux **def/▼** 2. Use arrow keys ▲ ▼ on temperature controller to increase (or decrease) the setpoint.

Set 3. Quickly press and release the “SET” key again.



To Modify Defrost, Differential, Other Parameters

Prg/mute **Set** 1. Press & hold “Prg” & “SET” keys together for five (5) seconds; display will flash “0”, representing password prompt.

Set 2. Confirm by pressing “SET” key.

▲/aux **def/▼** 3. Press ▲ or ▼ to reach the category to be modified.

Set 4. Press “SET” to modify this selected parameter.

▲/aux **def/▼** 5. Increase or decrease the value using the ▲ or ▼ button respectively.

Set 6. Press the “SET” key to temporarily save the new value and return to the display of the parameter.

Prg/mute 7. Press & hold the “Prg” key for at least 5 seconds to save changes. This action will also mute the audible alarm (buzzer) & deactivate the alarm relay.

How To Change Reading From Fahrenheit (°F) To Celsius (°C)

Prg/mute **Set** 1. Press and hold “Prg” and “SET” keys together for at least 5 seconds; display will show “0” (password prompt).

Set 2. Confirm by pressing “SET” key.

▲/aux **def/▼** 3. Press ▲ or ▼ until reaching the parameter “/ 5”.

Set 4. Press “SET” to modify this selected parameter.

▲/aux **def/▼** 5. Press ▲ or ▼ to change value to desired setting: “0” for Celsius (°C) or “1” for Fahrenheit (°F).

Set 6. Press “SET” key to temporarily save the new value and return to the display of the parameter.

Prg/mute 7. Press & hold “Prg” key for at least 5 seconds to save changes. **Note! All values will automatically convert to new scale. No conversion is required.**

Warning! Save Your Parameter Settings!

1. To store the new parameter values, PRESS and HOLD the “Prg” key for at least 5 seconds.
2. All modifications made to parameters will be lost if you do NOT press a button within 60 seconds. Should this “timeout” occur, normal operational settings (prior to modifications being made) will resume.
3. If the instrument is switched off before pressing the “Prg” key, all modifications to parameters will be lost.

def/▼ **To Activate Manual Defrost**
Press and hold “def” key for at least 5 seconds.

▲/aux **To Activate / Deactivate Auxiliary Output**
Press and hold the “aux” key for 1 second.

Prg/mute **▲/aux** **To Reset Any Alarms With Manual Reset**
Press and hold the “Prg” and “aux” key for at least 1 second.

CAREL

ir33 platform
**Integrated Electronic
 Microprocessor Controller**



User Interface - Display

ICON	FUNCTION	DESCRIPTION	Normal operation			Start up
			ON	OFF	BLINK	
	COMPRESSOR	ON when the compressor starts. Flashes when the activation of the compressor is delayed by safety times.	Compressor on	Compressor off	awaiting activation	
	FAN	ON when the fan starts. Flashes when the activation of the fan is prevented due to external disabling or procedures in progress.	Fan on	Fan off	awaiting activation	
	DEFROST	ON when the defrost is activated. Flashes when the activation of the defrost is prevented due to external disabling or procedures in progress.	Defrost in progress	Defrost not in progress	awaiting activation	
	AUX	Flashes if the anti-sweat heater function is active, ON when the auxiliary output (1 and/or 2) selected as AUX (or LIGHT in firmware version 3.6) is activated.	AUX auxiliary output active (version 3.6 light auxiliary output active)	AUX auxiliary output not active	Anti-sweat heater function active	
	ALARM	ON following pre-activation of the delayed external digital input alarm. Flashes in the event of alarms during normal operation (e.g. high/low temperature) or in the event of alarms from an immediate or delayed external digital input.	Delayed external alarm (before the time 'A7' elapses)	No alarm present	Alarms in norm. operation (e.g. High/low temperature) or immediate or delayed alarm from external digital input	
	CLOCK	ON if at least one timed defrost has been set. At start-up, comes ON for a few seconds to indicate that the Real Time Clock is fitted.	If at least 1 timed defrost event has been set	No timed defrost event set	Alarm clock	ON if real-time clock present
	LIGHT	Flashes if the anti-sweat heater function is active, ON when the auxiliary output (1 and/or 2) selected as LIGHT is activated (in firmware version 3.6 it does not flash in anti-sweat heater mode and comes on when the dead band output is active).	Light auxiliary output on (version 3.6 dead band auxiliary output active)	Light auxiliary output off	Anti-sweat heater function active (version 3.6 does not flash in anti-sweat heater mode)	
	SERVICE	Flashes in the event of malfunctions, for example E2PROM errors or probe faults.		No malfunction	Malfunction (e.g. E2PROM error or probe fault). Contact service	
	CONTINUOUS CYCLE	ON when the CONTINUOUS CYCLE function is activated. Flashes if the activation of the function is prevented due to external disabling or procedures in progress (E.g.: minimum compressor OFF time).	CONTINUOUS CYCLE operation activated	CONTINUOUS CYCLE function not activated	CONTINUOUS CYCLE operation requested	

Summary Table of Alarm and Signals: Display, Buzzer and Relay

Code	Icon on the display	Alarm relay	Buzzer	Reset	Description
rE	flashing	on	on	automatic	virtual control probe fault
E0	flashing	off	off	automatic	room probe S1 fault
E1	flashing	off	off	automatic	defrost probe S2 fault
E2	flashing	off	off	automatic	probe S3 fault
E3	flashing	off	off	automatic	probe S4 fault
E4	flashing	off	off	automatic	probe S5 fault
	No	off	off	automatic	probe not enabled
LO	flashing	on	on	automatic	low temperature alarm
HI	flashing	on	on	automatic	high temperature alarm
AFr	flashing	on	on	manual	antifreeze alarm
IA	flashing	on	on	automatic	immediate alarm from external contact
dA	flashing	on	on	automatic	delayed alarm from external contact
dEF	on	off	off	automatic	defrost running
Ed1	No	off	off	automatic/manual	defrost on evaporator 1 ended by timeout
Ed2	No	off	off	automatic/manual	defrost on evaporator 2 ended by timeout
Pd	flashing	on	on	automatic/manual	maximum pump down time alarm
LP	flashing	on	on	automatic/manual	low pressure alarm
AtS	flashing	on	on	automatic/manual	autostart in pump down
cht	No	off	off	automatic/manual	high condenser temperature pre-alarm
CHT	flashing	on	on	manual	high condenser temperature alarm
dor	flashing	on	on	automatic	door open too long alarm
EE	flashing	off	off	automatic	E2prom error, unit parameters
EF	flashing	off	off	automatic	E2prom error, operating parameters
ccb	Signal				start continuous cycle request
ccE	Signal				end continuous cycle request
dFb	Signal				start defrost call
dFE	Signal				end defrost call
On	Signal				switch ON
off	Signal				switch OFF
rES	Signal				reset alarms w/manual reset / reset HACCP alarms / reset temp. monitoring

CAREL

ir33 platform

Integrated Electronic
Microprocessor Controller



Summary Table of Operating Parameters

CODE	PARAMETER	UOM*	TYPE	MINIMUM	MAXIMUM	DEFAULT
/5	Select Celsius (°C) or Fahrenheit (°F)	flag	C	0	1	For Case Specific Defaults See Serial Label Located Near Electrical Access On Your Case. For Additional Technical Information Call Structural Concepts Technical Service Dept. at 1(800) 433.9489
/c1	Calibration of probe 1	°C/°F	C	-20	20	
/c2	Calibration of probe 2	°C/°F	C	-20	20	
St	Temperature set point	°C/°F	F	r2	r1	
rd	Control delta	°C/°F	F	20	0.1	
dl	Interval between defrosts	hours	F	0	250	
dt1	End defrost temperature, evaporator	°C/°F	F	-50	200	
dP1	Maximum defrost duration, evaporator	min	F	1	250	
d6	Display on hold during defrost	-	C	0	2	
dd	Dripping time after defrost	min	F	0	15	
d/1	Display of defrost probe 1	°C/°F	F	-	-	

* Unit Of Measure

STRUCTURAL CONCEPTS CORPORATION TECHNICAL SERVICE
PHONE NUMBER: 1.800.433.9489 or For Your Master Service Agent See
WWW.STRUCTURALCONCEPTS.COM/Contact/Master_Service_Agents.asp

LIMITED WARRANTY

All sales by Structural Concepts Corporation (SCC) are subject to the following limited warranty. "Goods" refers to the product or products being sold by SCC.

Warranty Scope: Warranty is for equipment sold in the United States, Canada, Mexico and Puerto Rico. Equipment sold elsewhere may carry modified warranty.

Warranty; Remedies; Limitations. SCC warrants that if any Goods are found by an authorized representative of SCC not to be of good material or workmanship within one year of the date of shipments SCC will, at its option after inspection by an authorized representative, replace any defective Good or pay the reasonable cost of replacement for any such defective Goods, provided that written notice of the defect is given to SCC within 30 days of the appearance of such defect. If notice is not given within such period, any claim for breach of warranty shall be conclusively deemed to have been waived and SCC shall not be liable under this warranty. If SCC is unable to repair or replace the defective Goods, SCC shall issue a credit to the Purchaser for all or part of the purchase price, as SCC shall determine. The replacement or payment in the manner described above shall be the sole and exclusive remedy of Purchaser for a breach of this warranty. If any Goods are defective or fail to conform to this warranty, SCC will furnish instructions for their disposition. No Goods shall be returned to SCC without its prior consent.

SCC's liability for any defect in the Goods shall not exceed the purchase price of the Goods. SCC SHALL HAVE NO LIABILITY TO PURCHASE FOR CONSEQUENTIAL DAMAGES OF ANY KIND WHATSOEVER, INCLUDING, BUT NOT LIMITED TO, PERSONAL INJURY, PROPERTY DAMAGE, LOST PROFITS, OR OTHER ECONOMIC INJURY DUE TO ANY DEFECT IN THE GOODS OR ANY BREACH OF SCC, SCC SHALL NOT BE LIABLE TO THE PURCHASER IN TORT FOR ANY NEGLIGENT DESIGN OR MANUFACTURE OF THE GOODS, OR FOR THE OMISSION OF ANY WARNING THEREFROM.

SCC shall have no obligation or liability under this warranty for claims arising from any other party's (including Purchaser's) negligence or misuse of the Goods or environmental conditions. This warranty does not apply to any claim or damage arising for or cause by improper storage, handling, installation, maintenance, or from fire, flood, accidents, structural defects, building settlement or movement, acts of God, or other causes beyond SCC's control.

Except as expressly stated herein, SCC makes no warranty, express, implied, statutory or otherwise as to any parts or goods not manufactured by SCC. SCC shall warrant such parts or Goods only (I) against such defects, (II) for such periods of time, and (III) with such remedies, as are expressly warranted by the manufacturer of such parts of Goods. Notwithstanding the foregoing, any warranty with respect to such parts of Goods and any remedies available as a result of a breach thereof shall be subject to all of the procedures, limitations, and exclusions set forth herein.

THE WARRANTIES HEREIN ARE IN LIEU OF ALL WARRANTIES, EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE. IN PARTICULAR, SCC MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

No representative, agent or dealer of SCC has authority to modify, expand, or extend this Warranty, to waive any of the limitations or exclusions, or to make any different or additional warranties with respect to Goods.

Period of Limitations. No claim, suit or other proceeding may be brought by Purchaser for any breach of the foregoing warranty or this Agreement by SCC or in any way arising out of this Agreement or relating to the Goods after one year from the date of the breach. In the interpretation of this limitation on action for a breach by SCC, it is expressly agreed that there are no warranties of future performance of the goods that would extend that period of limitation herein contained for bringing an action.

Indemnifications. Purchaser agrees to indemnify, hold harmless, and defend SCC if so requested, from any and all liabilities, as defined herein, suffered, or incurred by SCC as a result of, or in connection with, any act, omission, or use of the Goods by Purchaser, its employees or customers, or any breach of this Agreement by Purchaser. Liabilities shall include all costs, claims, damages, judgments, and expenses (including reasonable attorney fees and costs).

Remedies of SCC. SCC's rights and remedies shall be cumulative and may be exercised from time to time. In a proceeding or action relating to the breach of this Agreement by Purchaser, Purchaser shall reimburse SCC for reasonable costs and attorney's fees incurred by SCC. No waiver by SCC of any breach of Purchaser shall be effective unless in writing nor operate as a waiver of any other breach of the same term thereafter. SCC shall not lose any right because it has not exercised it in the past.

Applicable Law. This Agreement is made in Michigan and shall be governed by and interpreted according to Michigan law. Any lawsuit arising out of this Agreement or the Goods may be handled by a federal or state court whose district includes Muskegon County, Michigan, and Purchaser consents that such court shall have personal jurisdiction over Purchaser.

Miscellaneous. If any provision of this Agreement is found to be invalid or unenforceable under any law, the provision shall be ineffective to that extent and for the duration of the illegality, but the remaining provisions shall be unaffected. Purchaser shall not assign any of its rights nor delegate any of its obligations under this Agreement without prior written of SCC. This Agreement shall be binding upon and inure to the benefit of SCC and Purchaser and each of their legal representatives, successors and assigns.

SCC warrants its products to be free of defects in materials and workmanship under normal use and service for a period of one (1) year from the date of delivery.

This warranty is extended only to the original purchaser for use of the Goods. It does not cover normal wear parts such as plastic tongs, tong holders, tong cables, bag holders, or acrylic dividers.

General Conditions. All service labor and/or parts charges are subject to approval by SCC. Contact the Customer Service Department in writing or call 231-798-8888.

All claims must contain the following information: (1) model & serial code number of equipment; (2) the date and place of installation; (3) the name and address of the agency which performed the installation; (4) the date of the equipment failure; and (5) a complete description of the equipment failure and all circumstances relating to that failure.

Once the claim has been determined to be a true warranty claim by SCC's Customer Service Department, the following procedure will be taken: (1) replacement parts will be sent at no charge from SCC on a freight prepaid basis; (2) reimbursement for service labor will be paid if the following conditions have been met - (a) prior approval of service agency was awarded from the Customer Service Department; and (b) an itemized statement of all labor charges incurred is received by the Customer Service Department. The cost of the service labor reimbursement will be based on straight time rates and reasonable time for the repair of the defect.

If problems occur with any compressor, notify SCC's Customer Service Department immediately. Any attempt to repair or alter the unit without prior consent from the Customer Service Department will render any warranty claim null and void. This warranty and protection plan does not apply to any condensing unit or any part thereof which has been subject to accident, negligence, misuse, or abuse, or which has not been operated in accordance with the manufacturer's recommendations or if the serial number of the unit has been altered, defaced, or removed.

Limit of Liability. The limit of liability of SCC toward the exchange cost of the original condensing unit, F.O.B. SCC, Norton Shores, MI, of each motor-compressor assembly replaced during the warranty shall not exceed manufacturer's current established wholesaler's exchange price and in no case shall the labor of removing or replacing the motor-compressor or parts thereof be the responsibility of SCC.