XD 9005F
SWGHE
04/08/2019

Simple. Smart.

XLT Electric Oven & AVI Hood Installation & Operation Manual

Read This Manual Before Using This Appliance.

Current versions of this manual, Rough-In Specifications, Parts & Service Manual, Architectural Drawings, & a list of International Authorized Distributors are available at: www.xltovens.com

For use with the following XLT Electric Oven Versions:		For use with the following AVI Electric Hood Versions:	
Standard (S)	G	Standard (S)	E
World (W)	G	World (W)	E

Intertek 2000887

0359

XLT Ovens
PO Box 9090
Wichita, Kansas 67277
US: 888-443-2751 FAX: 316-943-2769 INTL: 316-943-2751 WEB: www.xltovens.com

WARNING & SAFETY INFORMATION

SAFETY DEPENDS ON YOU

CAUTION

This appliance is for professional use by qualified personnel. This appliance must be installed by qualified persons in accordance with the regulations in force. This appliance must be installed with sufficient ventilation to prevent the occurrence of unacceptable concentrations of substances harmful to health in the room in which it is installed. This appliance needs an unobstructed flow of fresh air for satisfactory operation & must be installed in a suitably ventilated room in accordance with current regulations. This appliance should be serviced by qualified personnel at least every 12 months or sooner if heavy use is expected.

DANGER

Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury, or death. Read the installation, operating and maintenance instructions thoroughly before installing, using, or servicing this equipment.

DANGER

FOR YOUR SAFETY

Do not store or use gasoline or other flammable liquids or vapors in the vicinity of this or any other appliance.

- Do not restrict the flow of ventilation air to the unit. Provide adequate clearance for operating, cleaning, maintaining the unit is in the installed position.
- Keep the area free & clear of combustible material. DO NOT SPRAY AEROSOLS IN THE VICINITY OF THIS APPLIANCE WHILE IT IS IN OPERATION.
- Ovens are certified for installation on combustible floors.
- Electrical schematics are located inside the control box of the oven & and in this manual. Disconnect input power to the unit before performing any maintenance.
- This unit requires a ventilation hood. The installation must conform to local codes.
- This unit must be operated by the same voltage, phase, & frequency of electrical power as designated on the nameplate label located on the side of the unit.
- Minimum clearances must be maintained from combustible & non-combustible construction materials.
- Follow all local codes when installing this unit.
- Follow all local codes to electrically ground the unit.
- Appliance is not to be cleaned with high pressure water.
- XLT ovens are certified for use in stacks of up to three (3) units of XLT products. Integration of other manufacturer's products into an oven stack is not recommended, & voids any warranties. XLT Ovens assumes no liability for mixed product applications.
- Failure to call XLT Customer Service at 1-888-443-2751 prior to contacting a repair company voids any & all warranties.
- PLEASE RETAIN THIS MANUAL FOR FUTURE REFERENCE.
- This appliance operates below 70 dBA.

XLT Ovens has spent millions of dollars designing and testing our products as well as developing Installation & Operation Manuals. These manuals are the most complete and easiest to understand in the industry. However, they are worthless if they are not followed.

We have witnessed store operators and building owners lose many thousands of dollars in lost revenue due to incorrect installations. We highly recommend you follow all instructions given in this manual as well as follow best practices in plumbing, electrical, and HVAC building codes.

Definitions & Symbols

A safety instruction (message) includes a "Safety Alert Symbol" & a signal word or phrase such as **DANGER, WARNING** or **CAUTION**. Each signal word has the following meaning:

DANGER	ISO 7000-0434: Indicates a potentially hazardous situation that, if not avoided, can result in serious injury or death.
HIGH VOLTAGE	IEC 60417-5036: This symbol indicates high voltage. It calls your attention to items or operations that could be dangerous to you & other persons operating this equipment. Read the message & follow the instructions carefully.
WARNING	ISO 7000-0434: Indicates a potentially hazardous situation, that if not avoided, can result in minor to moderate injury or serious damage to the product. The situation described in the CAUTION may, if not avoided, lead to serious results. Important safety measures are described in CAUTION (as well as WARNING), so be sure to observe them.
CAUTION	ISO 7000-0434: Indicates a potentially hazardous situation, that if not avoided, can result in minor to moderate injury or serious damage to the product. The situation described in the CAUTION may, if not avoided, lead to serious results. Important safety measures are described in CAUTION (as well as WARNING), so be sure to observe them.

READ MANUAL	ISO 7000-0790: Read the instructions before using this machine.	**CLASS II EQUIPMENT**	IEC 60417-5172: A class II or double insulated electrical appliance.
PROTECTIVE EARTH	IEC 60417-5019: Terminal which is intended for connection to an external conductor.	**EQUIPOTENTIALITY**	IEC 60417-5021: Having the same electric potential or uniform electric potential.
 **FUSE-LINK**	IEC 60417-5016: Terminal which is intended for connection to an external conductor.		

Warranty – US and Canada

Rev H

Approval Date: 09/28/2017

XLT warrants Version G ovens manufactured after October 16, 2017 to be free from any defect in material and workmanship under normal use for seven (7) years from the date of original purchase by the end user, and further warrants main fan blades, conveyor shafts, and conveyor bearings for ten (10) years. XLT further warrants all ovens/hoods to be free from rust for ten (10) years from the date the equipment is originally purchased. XLT warrants Version E hoods manufactured after October 16, 2017 to be free from any defect in material and workmanship under normal use for seven (7) years from the date of original purchase by the end user purchaser. If the purchase includes a pre-piped Ansul system hood and the ovens both the warranty will be increased to ten (10) years on both pieces of equipment. In the event of a part failure, XLT will furnish a replacement part and pay for all labor associated with the replacement of the part. If upon inspection XLT determines that the part is not defective, all incurred costs will be the responsibility of the end user purchaser. This warranty is extended to the original end user purchaser and is not transferable without prior written consent of XLT. Damages are limited to the original purchase price.

DUTIES OF THE OWNER:

- The owner must inspect the equipment and crates at time of receipt. Damage during shipment is to be immediately reported to the carrier and also to XLT
- The equipment must be installed and operated in accordance with the I&O Manual furnished with the unit
- This warranty shall not excuse the owner from properly maintaining the equipment in accordance with the I&O Manual furnished with the unit
- A copy of the "Initial Start-Up Checklist" must be filled out and returned to XLT when the unit is initially installed, and/or when the unit is removed and installed in another location
- The gas, electric, and HVAC utilities must be connected to the oven and installed by locally licensed contractors
- Failure to contact XLT Ovens prior to contacting a repair company for warranty work voids any and all warranties

WHAT IS NOT COVERED:

- Freight damage
- Overtime charges
- Any part that becomes defective because of utility services (power surges, high or low voltages, high or low gas pressure or volume, contaminated fuel, or improper utility connections)
- Any part that becomes defective because of moisture and/or other contaminants
- Conveyor belts
- Filters
- Exhaust Fans
- Light Bulbs
- Painted or Powder Coated surfaces
- Normal maintenance or adjustments
- This warranty shall not apply if the equipment or any part is damaged as a result of accident, casualty, alteration, misuse, abuse, improper cleaning, improper installation, improper operation, natural disasters, or man-made disasters

CLAIMS HANDLED AS FOLLOWS:

Should any such defect be discovered, XLT must be notified. Upon notification, XLT will arrange for necessary repairs to be made by an authorized service agent. Denial of services upon the arrival of an authorized service agent will release XLT of any and all warranty obligations.

7761 W Kellogg Drive 67209-2003 - PO Box 9090 67277-0090 - Wichita, Kansas
Voice (316) 943-2751 - (888) 443-2751 - Fax (316) 943-2769
www.xltovens.com

Warranty – International

Rev K

Approval Date: 09/28/2017

XLT warrants Version G ovens manufactured after October 16, 2017 to be free from any defect in material and workmanship under normal use for five (5) years from the date of original purchase by the end user, and further warrants main fan blades, conveyor shafts, and conveyor bearings for ten (10) years. XLT further warrants all ovens/hoods to be free from rust for ten (10) years from the date the equipment is originally purchased. XLT warrants Version E hoods manufactured after October 16, 2017 to be free from any defect in material and workmanship under normal use for five (5) years from the date of original purchase by the end user purchaser. If the purchase includes a hood and the ovens both the warranty will be increased to seven (7) years on both pieces of equipment. In the event of a part failure, XLT will furnish a replacement part and pay for all labor associated with the replacement of the part. If upon inspection XLT determines that the part is not defective, all incurred costs will be the responsibility of the end user purchaser. This warranty is extended to the original end user purchaser and is not transferable without prior written consent of XLT. Damages are limited to the original purchase price.

DUTIES OF THE OWNER:

- The owner must inspect the equipment and crates at time of receipt. Damage during shipment is to be immediately reported to the carrier and also to the Distributor/Service Provider
- The equipment must be installed and operated in accordance with the I&O Manual furnished with the unit
- This warranty shall not excuse the owner from properly maintaining the equipment in accordance with the I&O Manual furnished with the unit
- A copy of the "Initial Start-Up Checklist" must be filled out and returned to Distributor/Service Provider when the unit is initially installed, and/or when the unit is removed and installed in another location
- The gas, electric, and HVAC utilities must be connected to the oven and installed by locally licensed contractors
- Failure to contact the Distributor/Service Provider prior to contacting a repair company for warranty work voids any and all warranties

WHAT IS NOT COVERED:

- Freight damage
- Overtime charges
- Any part that becomes defective because of utility services (power surges, high or low voltages, high or low gas pressure or volume, contaminated fuel, or improper utility connections)
- Any part that becomes defective because of moisture and/or other contaminants
- Conveyor belts
- Filters
- Exhaust Fans
- Light Bulbs
- Painted or Powder Coated surfaces
- Normal maintenance or adjustments
- This warranty shall not apply if the equipment or any part is damaged as a result of accident, casualty, alteration, misuse, abuse, improper cleaning, improper installation, improper operation, natural disasters, or man-made disasters

CLAIMS HANDLED AS FOLLOWS:

Should any such defect be discovered, the Distributor/Service Provider must be notified. Upon notification, Distributor/Service Provider will arrange for necessary repairs to be made by an authorized service agent. Denial of services upon the arrival of an authorized service agent will release XLT and Distributor/Service Provider of any and all warranty obligations.

7761 W Kellogg Drive 67209-2003 - PO Box 9090 67277-0090 - Wichita, Kansas
Voice (316) 943-2751 - (888) 443-2751 - Fax (316) 943-2769
www.xltovens.com

This page intentionally left blank.

Responsibility	XLT/Service Company	Owner/ Contractor
Site Survey: Verify electric and gas meter/regulator sizes	X	
Supply wiring from TS1 #R3, R4, R5 to exhaust fan		X
Supply (1) single phase 230 volt 10 amp circuit from breaker panel to XLT Hood		X
Assembly of new hood per XLT Installation & Operation Manual		X
Suspend XLT Hood from ceiling		X
Install new exhaust fan on roof		X
Supply power to XLT Hood		X
Install Duct Cover or Valance above XLT Hood		X
Assembly of new ovens per XLT Installation & Operation Manual		
Stands assembled and set in place	X	
Ovens moved and stacked with proper lifting equipment	X	
Peel all PVC	X	
Assemble shrouds & brackets to XLT Oven/Hood	X	
Connecting fuel to XLT products		
Install piping and drip legs		X
Weld ducting to XLT Hood		X
Check for leaks		X
Install flexible gas hoses	X	
Connect electrical supply	X	
Connection may require Permit and Code Inspections		X
Relocate Make-Up-Air to enter the room at the ends of the ovens		X
Start-up per XLT Installation & Operation Manual:	X	
Gas pressure/leak testing, hood/oven functions, adjust as necessary	X	
Start-Up Checklist must be submitted to XLT to validate Warranty		X

NOTIFY CARRIER OF DAMAGE AT ONCE

Upon receiving of all goods shipped by a Common Carrier, check for any exterior damage that may indicate interior damage. If conditions permit, open all crates & do a full inspection for any damage while the delivery driver is still there. If there is damage, please note on the delivery receipt & call the carrier to make a freight damage claim within 24 hours of receipt. Failure to make a damage claim within the first 24 hours may void the opportunity to have the claim resolved.

XLT Ovens wants you to be totally satisfied with every aspect of owning & using your oven & hood. Your feedback, both positive & negative, is very important to us as it helps us understand how to improve our products & our company. Our goal is to provide you with equipment that we are proud to build & you will be proud to own.

To receive technical support for the oven or hood you purchased, XLT has qualified customer service personnel that can provide assistance on any type of XLT oven problem you may experience. Customer Service is available 24/7/365 or visit www.xltovens.com.

DANGER

Installation of all electric appliances & ventilation exhaust hoods should only be performed by a qualified professional who has read & understands these instructions & is familiar with proper safety precautions. Read this manual thoroughly before installing or servicing this equipment.

NOTE

Notes indicates an area or subject of special merit, emphasizing either the product's capability or common errors in operation or maintenance.

TIP

Tips give a special instruction that can save time or provide other benefits while installing or using the product. The tip calls attention to an idea that may not be obvious to first-time users of the product.

Save this Manual

This document is the property of the owner of this equipment.

XLT Ovens reserves the right to make changes in design & specifications, and/or make additions to or improvements to its product without imposing any obligations upon itself to install them in products previously manufactured.

All Right Hand & Left Hand designations in this manual are from the point of view as if standing directly in front of the glass sandwich door.

Revision History Table

Revision	Comments	Date
E	Added Do Not Exceed 65 Hz On VFD Settings On Pg. 28 And Pg. 110	01/08/2019
F	Added Installing Sandwich Door Image On Pg. 22; Removed The Sandwich Door From Images On Pgs. 20-22.	04/08/2019

TABLE OF CONTENTS

Warning & Safety Information 2
Warranty 4
Installation Responsibilities 7
Oven Description 10
Oven Crate Dimensions 13
Oven Dimensions & Weights 14
Oven Electrical Requirements 16
Oven Only Rough-In Specifications 17
Oven Assembly 19
Oven Connection 24
Oven Fire Suppression 25
Oven Ventilation Guidelines 27
Oven Initial Start-Up 28
Oven Operation 29
Oven Operator Controls 30
Oven Cleaning 34
Oven Maintenance 39
Oven Troubleshooting 40
Hood Installation 42
Hood Description 43
Hood and Shroud Crate Dimensions 45
Hood Dimensions & Weights 46
Hood Exhaust Flow Rates 48
Hood Electrical Requirements 50
Hood Rough-In Specifications 51
Hood Electrical Connections 52
Hood Assembly 64
Hood Connection 81
Hood Initial Start-Up 83
Hood Operator Controls 84
Hood Valance Kit 87
Hood Duct Wrap Kit 90
Hood Cleaning 91
Electrical Schematics 92
Certifications 107
Oven Start-Up Checklist 109
Hood Start-Up Checklist 111
Notes 113

This manual covers the following XLT Oven & AVI Hood models:

Ovens	Hoods
X3G-1832-xxxxx	H3E-1832-xxxxx
X3G-2336-xxxxx	
X3G-2440-xxxxx	H3E-2440-xxxxx
X3G-3240-xxxxx	H3E-3240-xxxxx
X3G-3255-xxxxx	H3E-3255-xxxxx
X3G-3855-xxxxx	H3E-3855-xxxxx

The first 2 digits of the model number after the dash represent the conveyor width and the last two digits indicate the bake chamber length. The five x's after those numbers represents the oven and hood configuration number. The ovens may be used in a single, double, or triple stack configuration. All models have a single control box, which can be mounted on either the right-hand or left-hand side, and are heated by electric elements. All models can be configured for a split belt conveyor.

OVEN DESCRIPTION

Food product is placed on the stainless steel wire conveyor belt on one side of the oven. The conveyor then transports the food through the bake chamber at a user-controlled speed. This provides repeatable and uniform food cooking. The conveyors can be easily configured to move either left-to-right or right-to-left with a simple programming change. A large center sandwich door allows the introduction or removal of food items for cooking at shorter times. Precise temperatures are user adjustable and maintained by a digital control.

An easily removable front panel allows the full cleaning of the oven interior. All exposed oven surfaces both exterior and interior are stainless steel. The conveyor is a one piece design and is removed from the side which has the control box. No tools are required for disassembly and cleaning of the conveyor or oven interior. The oven itself is mounted on lockable swivel casters for easy moving and maintenance.

Accessories such as extended conveyor shelves, base shelves, extended fronts, fire suppression components, and perforated crumb trays are available from XLT. In addition, moving equipment such as carts and lifting jacks are available to help install and move ovens. Please contact XLT Ovens or your Authorized Distributor for more information.


Oven Lid
Sandwich Door
Conveyor
Control Box
Crumb Tray
Front Panel Knob
Front Panel
Product Stop
Locking Swivel Caster


Data Plate
Control Box Lid
Oven Control
Large User Interface
Control Panel
Chain Guard
Document Tray

This page is intentionally left blank.

INTERNATIONAL WOOD CRATES



International Wood Crate Dimensions			
Oven Model	Gas and Electric Ovens		
	X	Y	Z
1832	76 [1930]	29 3/4 [756]	60 3/8 [1534]
2336	84 [2134]	29 3/4 [756]	66 3/8 [1686]
2440	84 [2134]	29 3/4 [756]	66 3/8 [1686]
3240	84 [2134]	29 3/4 [756]	74 3/8 [1889]
3255	99 [2515]	29 3/4 [756]	74 3/8 [1889]
3270	115 1/2 [2934]	29 3/4 [756]	74 3/8 [1889]
3855	99 [2515]	29 3/4 [756]	80 3/8 [2042]
3870	115 1/2 [2934]	29 3/4 [756]	80 3/8 [2042]

DOMESTIC WOOD CRATES



Domestic Wood Crate Dimensions								
Oven Model	Gas Oven				Electric Oven			
	X	Y	Z	Z (With Oven)	X	Y	Z	Z (With Oven)
1832	85 3/4 [2178]	31 3/4 [806]	17 [432]	59 1/2 [1511]	85 3/4 [2178]	31 3/4 [806]	13 1/2 [343]	56 [1422]
2336	85 3/4 [2178]	31 3/4 [806]	17 [432]	63 1/4 [1607]	85 3/4 [2178]	31 3/4 [806]	13 1/2 [343]	59 3/4 [1518]
2440	85 3/4 [2178]	31 3/4 [806]	17 [432]	65 1/2 [1664]	85 3/4 [2178]	31 3/4 [806]	13 1/2 [343]	62 [1575]
3240	85 3/4 [2178]	31 3/4 [806]	17 [432]	73 1/2 [1867]	85 3/4 [2178]	31 3/4 [806]	13 1/2 [343]	70 [1778]
3255	115 3/4 [2940]	31 3/4 [806]	17 [432]	73 1/2 [1867]	115 3/4 [2940]	31 3/4 [806]	13 1/2 [343]	70 [1778]
3270	115 3/4 [2940]	31 3/4 [806]	17 [432]	73 1/2 [1867]				
3855	115 3/4 [2940]	31 3/4 [806]	17 [432]	79 1/2 [2019]	115 3/4 [2940]	31 3/4 [806]	13 1/2 [343]	76 [1930]
3870	115 3/4 [2940]	31 3/4 [806]	17 [432]	79 1/2 [2019]				

METAL SKIDS (Containers Only)



Metal Skid Dimensions								
Oven Model	Gas Oven				Electric Oven			
	X	Y	Z	Z (With Oven)	X	Y	Z	Z (With Oven)
1832	55 [1397]	22 [559]	8 5/8 [219]	51 1/8 [1299]	55 [1397]	22 [559]	6 1/2 [165]	49 [1245]
2336	63 [1600]	22 [559]	8 5/8 [219]	54 7/8 [1394]	63 [1600]	22 [559]	6 1/2 [165]	52 3/4 [1340]
2440	63 [1600]	22 [559]	8 5/8 [219]	57 1/8 [1451]	63 [1600]	22 [559]	6 1/2 [165]	55 [1397]
3240	63 [1600]	22 [559]	8 5/8 [219]	65 1/8 [1654]	63 [1600]	22 [559]	6 1/2 [165]	63 [1600]
3255	78 [1981]	22 [559]	8 5/8 [219]	65 1/8 [1654]	78 [1981]	22 [559]	6 1/2 [165]	63 [1600]
3270	115 [2921]	22 [559]	9 3/4 [248]	66 1/4 [1683]				
3855	78 [1981]	22 [559]	8 5/8 [219]	71 1/8 [1807]	78 [1981]	22 [559]	6 1/2 [165]	69 [1753]
3870	115 [2921]	22 [559]	9 3/4 [248]	72 1/4 [1835]				

NOTE: All dimensions in inches [millimeters], ± 1/4 [6], unless otherwise noted.
All weights in pounds [kilograms] unless otherwise noted.


F
20
H
G
J


F
20
H
G


C
D
B
E
A


F
G

SINGLE OVEN	A	B	C	D	E	F	G	H	J	OVEN WEIGHT	CRATED WEIGHT
1832	18 [457]	32 [813]	48 3/8 [1229]	70 1/4 [1784]	67 1/4 [1708]	47 3/4 [1213]	37 [940]	N/A	N/A	609 [276]	746 [338]
2336	23 [584]	36 [914]	50 3/8 [1280]	70 3/4 [1797]	65 3/4 [1670]	47 3/4 [1213]	37 [940]	N/A	N/A	710 [322]	864 [392]
2440	24 [610]	40 [1016]	54 3/8 [1381]	78 1/4 [1988]	75 1/4 [1911]	47 3/4 [1213]	37 [940]	N/A	N/A	726 [329]	880 [399]
3240	32 [813]	40 [1016]	62 3/8 [1584]	78 1/4 [1988]	75 1/4 [1911]	47 3/4 [1213]	37 [940]	N/A	N/A	755 [342]	915 [415]
3255	32 [813]	55 [1397]	62 3/8 [1584]	93 1/4 [2369]	90 1/4 [2292]	47 3/4 [1213]	37 [940]	N/A	N/A	884 [401]	1064 [483]
3855	38 [965]	55 [1397]	68 3/8 [1737]	93 1/4 [2369]	90 1/4 [2292]	47 3/4 [1213]	37 [940]	N/A	N/A	981 [445]	1166 [529]

DOUBLE STACK	A	B	C	D	E	F	G	H	J	OVEN WEIGHT	CRATED WEIGHT
1832	18 [457]	32 [813]	48 3/8 [1229]	70 1/4 [1784]	67 1/4 [1708]	67 3/4 [1721]	37 [940]	57 [1448]	N/A	1123 [509]	1397 [634]
2336	23 [584]	36 [914]	50 3/8 [1280]	70 3/4 [1797]	65 3/4 [1670]	67 3/4 [1721]	37 [940]	57 [1448]	N/A	1331 [604]	1639 [743]
2440	24 [610]	40 [1016]	54 3/8 [1381]	78 1/4 [1988]	75 1/4 [1911]	67 3/4 [1721]	37 [940]	57 [1448]	N/A	1342 [609]	1650 [748]
3240	32 [813]	40 [1016]	62 3/8 [1584]	78 1/4 [1988]	75 1/4 [1911]	67 3/4 [1721]	37 [940]	57 [1448]	N/A	1389 [630]	1709 [775]
3255	32 [813]	55 [1397]	62 3/8 [1584]	93 1/4 [2369]	90 1/4 [2292]	67 3/4 [1721]	37 [940]	57 [1448]	N/A	1629 [739]	1989 [902]
3855	38 [965]	55 [1397]	68 3/8 [1737]	93 1/4 [2369]	90 1/4 [2292]	67 3/4 [1721]	37 [940]	57 [1448]	N/A	1812 [822]	2182 [990]

TRIPLE STACK	A	B	C	D	E	F	G	H	J	OVEN WEIGHT	CRATED WEIGHT
1832	18 [457]	32 [813]	48 3/8 [1229]	70 1/4 [1784]	67 1/4 [1708]	67 3/4 [1721]	17 [432]	37 [940]	57 [1448]	1603 [727]	2014 [914]
2336	23 [584]	36 [914]	50 3/8 [1280]	70 3/4 [1797]	65 3/4 [1670]	67 3/4 [1721]	17 [432]	37 [940]	57 [1448]	1912 [867]	2374 [1077]
2440	24 [610]	40 [1016]	54 3/8 [1381]	78 1/4 [1988]	75 1/4 [1911]	67 3/4 [1721]	17 [432]	37 [940]	57 [1448]	1927 [874]	2389 [1084]
3240	32 [813]	40 [1016]	62 3/8 [1584]	78 1/4 [1988]	75 1/4 [1911]	67 3/4 [1721]	17 [432]	37 [940]	57 [1448]	1985 [900]	2465 [1118]
3255	32 [813]	55 [1397]	62 3/8 [1584]	93 1/4 [2369]	90 1/4 [2292]	67 3/4 [1721]	17 [433]	37 [941]	57 [1448]	2335 [1059]	2875 [1304]
3855	38 [965]	55 [1397]	62 3/8 [1584]	93 1/4 [2369]	90 1/4 [2292]	67 3/4 [1721]	17 [433]	37 [941]	57 [1448]	2602 [1180]	3157 [1432]

NOTE: All dimensions in inches [millimeters], ± 1/4 [6], unless otherwise noted.
All weights in pounds [kilograms] unless otherwise noted.

16 OVEN ELECTRICAL REQUIREMENTS

Electric Oven Electrical Requirements Per EACH Oven										
Oven Model	STANDARD					WORLD				
	Volts AC	Amps	Hertz	Phase	KW	Volts AC	Amps	Hertz	Phase	KW
1832	208/240	45/39	60	3	16	380/415	31/24	50	3	16/15
2336										
2440		82/65			27		51/44			27/31
3240										
3255		90/80			32		55/48			32/34
3855										
	4 Wire Service - L1, L2, L3 +1 Ground (per oven)					5 Wire Service - L1, L2, L3 N +2 Grounds (per oven)				

FOR EACH OVEN:

- A separate circuit breaker must be provided for each oven deck.
- Electrical connections must be accessible when the ovens are in the installed position.
- Electrical connections must meet all local code requirements.
- Ensure ovens are grounded per local codes.



Control Box Rear - Standard



Control Box Rear - World

These ovens are suitable for installation on either combustible or non-combustible floors, and adjacent to either combustible or non-combustible walls. The motor cover is designed to provide the proper clearance to the back of the oven. The minimum side clearances are 6in. / 150mm, measured from the end of the conveyor.



NOTE

Utilities must be easily accessible when the ovens are in the installed position. Do not install utilities behind the ovens.



NOTE

All installations must conform to local building and mechanical codes. It is required that the ovens be placed under a ventilation hood to provide exhaust ventilation and adequate air supply.

Base Assembly - Single & Double Stack



Base Assembly - Triple Stack



WARNING & SAFETY INFORMATION

XLT ovens can easily be moved and stacked with the proper lifting equipment. The use of XLT approved lifting equipment is highly recommended. Contact XLT for more information.

DANGER

- These ovens are heavy & can tip or fall causing bodily injury.
- NEVER place any part of your body beneath any oven that is suspended by the lifting jacks. A crush hazard exists if the oven falls or slips.
- DO NOT place your hands on the lifting jack vertical pole beneath the jack's winch. As the jack's winch descends when you turn the jack handle, a pinch point is created between the winch & the pole.

CAUTION

BE CAREFUL when rolling the oven on the cart, especially when going up or down ramps & over bumps. Leave the straps/banding on until the oven is near the assembly area.

DANGER

- Make sure that the notch on tube of the winch assembly is aligned with the pin in the tripod base as shown. These alignments are important and keep the jack aligned properly.
- Check for smooth operation. The cable should not be pinched and should pass smoothly over the pulley on top of the pole assembly.
- Inspect cable prior to each use.
- If cable is frayed or shows signs of excessive wear and tear, DO NOT USE until cable is replaced.
- At a minimum replace the cable annually with wire rope that meets or exceeds the jack manufacturer's specifications.
- Do not exceed the stated capacity of the jack.





NOTE The Lifting Pipe hole, marked for the appropriate oven size, must be installed closest to the control box.



Stacking the Ovens

DANGER	Failure to engage the Lifting Jacks into the Lifting Pipe properly and completely will result in damage, injury, or death from a falling oven.
DANGER	• Both jacks should be raised in unison, otherwise they may bind and a dangerous situation will develop. • Do not put any part of yourself under the oven at any time. • The Oven is top heavy. Be careful.



Installing Sandwich Door



Stacking the Ovens



Removing Finger Clips



Finger clips for transportation purposes only. Discard once removed.

NOTE

Physical Location & Spacing Requirements

These ovens are suitable for installation on either combustible or non-combustible floors, and adjacent to either combustible or non-combustible walls. The motor cover is designed to provide the proper clearance to the back of the oven. The minimum side clearances are 6in. / 150mm, measured from the end of the conveyor.

All installations must conform to local building and mechanical codes.

NOTE

Restraint

Because all ovens are equipped with casters, all installations must be configured with a restraint to limit the movement of the oven without depending on the electric power supply cord to limit the oven movement. One (1) restraint kit, which includes one (1) eye bolt, (1) stainless steel clip & a cable, is required for each oven stack, regardless if used on a single, double, or triple configuration. The clip should be installed in the lowest hole of the back wall on the control end of the lowest oven in the stack. The lag eye bolt must be installed into a structural member of a wall or the floor. It is the owner's responsibility to ensure the restraint is installed correctly.

Upon completion of performing any service or cleaning functions that require removal of the restraint, insure that it is correctly re-attached to the oven.



The requirement for fire suppression systems vary by location and the authority having jurisdiction. If you are required to install fire suppression on your oven, a pre-assembled piping kit is available that utilizes pre-existing holes that simplify installation and future service.



This design has been tested and approved to successfully comply with fire suppression codes. It uses only two (2) nozzles per bake chamber, and allows crumb trays, chain guards, and all other accessories to be easily removed. The kit does not interfere with any operations or maintenance.

For detailed information regarding fire suppression, see manual XD-9011 Fire Suppression Installation for AVI Hoods and XLT Ovens.







Ventilation Requirements

A powered ventilation hood is required to remove heat and vapors. Some provision must be made to replenish the amount of air that is extracted from the building. The hood and HVAC installation must meet local building and mechanical codes. Requirements vary throughout the country depending upon location. Proper ventilation is the oven owner's responsibility. The AVI Hood system is designed to meet all requirements for XLT ovens and it is our recommendation that this system be used.

Ventilation Guidelines

Obtain information from the authority having jurisdiction to determine the requirements for your installation. Your ventilation hood supplier and HVAC contractor should be contacted to provide guidance. An air balance test is highly recommended, performed by a licensed contractor. A properly engineered and installed ventilation hood and HVAC system will expedite approval, reduce all maintenance costs, and provide a more comfortable working environment. XLT also recommends that the operator switches for the ovens and the operator switch for the exhaust fan be interlocked so that the exhaust fan gets energized whenever the ovens are turned on. For more information, see the following links at xltovens.com:

Kitchen Ventilation Design Guide 1
Kitchen Ventilation Design Guide 2
Kitchen Ventilation Design Guide 3
Kitchen Ventilation Design Guide 4

Ventilation Performance Test

After the oven and ventilation hood have been installed and are operating, a smoke candle can be used to "see" if the heat and vapors are being completely extracted. The test procedure is outlined below:

- The oven must be operating at 450º-500ºF / 232º-260ºC.
- The conveyor must be turned off.
- The ventilation hood exhaust fan must be turned on.
- Put a smoke candle in a pan on the conveyor belt at the center of the oven.
- Observe the smoke pattern coming out of the oven.
- Repeat the smoke candle test for each oven, as well as when all ovens are operating.

The ventilation hood must capture all of the smoke from the oven.

After the exhaust fan has been adjusted to completely capture and contain the heat, there needs to be a corresponding amount of make up air (MUA) introduced into the building to offset the amount of air volume being removed. An air balance test can determine the proper amount of make-up air flow rates.

All ovens are tested at the factory for functional operation. Operation is verified and adjustments are made to ensure proper function. However, field conditions are sometimes different than factory conditions. **It is necessary to have an authorized service technician verify operation and make field adjustments if needed.**

The Oven Initial Start-Up Checklist, found at the end of this manual, must be completed (both sides) at time of installation, signed by the Customer and returned to XLT Ovens and the Authorized Distributor to initiate Warranty Policy. **If the Start-Up Checklist is not filled out completely and returned to XLT Ovens, then the Warranty will not be honored.**

Start-up Procedure

1. Ensure that all ovens have been installed in accordance with the I&O Manual and that all utilities are connected to the ovens in compliance with local building codes.
2. Fill out Step 1 on the checklist with all information and print legibly.
3. Place all control boxes in service position. Start each oven and complete form.
4. Complete Start-up checklist with owner signature and return to XLT.

CAUTION

Do Not Exceed 65 Hz On VFD Settings.

CAUTION **This oven is not capable of being safely placed in operation in the event of a power failure. No attempt should be made to operate this oven during power failure.**

Turn On

1

Power Oven On
(Hold for 1 second)

Temperature Adjustment

2

Press TEMP button for 3 seconds. To adjust temperature use either the UP or DOWN arrow. If double burner press the TEMP button to change to other temp. Press ENTER to save.

Belt Time Adjustment

3

Press TIME button for 3 seconds. To adjust belt time use either the UP or DOWN arrow. If split belt press the TIME button to change to other time. Press ENTER to save.

Turn Off

4

Power Oven Off
(Hold for 1 second)

Conveyor Belt Times (Min:Sec)		
Oven Models	MINIMUM	MAXIMUM
1832	1:30	17:00
xx36-xx70	1:30	20:00

Oven Operating Temperature Range		
Oven Models	MINIMUM	MAXIMUM
All	300° F	590° F
	150° C	310° C

TIP

Read and understand steps first. Screens will auto exit if no activity is sensed.

Factory Tech Mode

To enter Factory Tech Mode press and hold the 2 arrow buttons for 10 seconds.



Software Version

MC & UI Software Version. Press Down arrow to go to next screen. Image For Reference Only - See XLT For Correct Version.



Serial Number

ENTER button to make changes. Use side to side arrows to scroll to next character position. Use Up/Down arrows to change values and press ENTER to accept and advance.

Elapsed Time

Elapsed time “Total Operation” and “Since Last Filter Cleaning”. Elapsed time total cannot be reset. Press ENTER to advance.

Belt Length

There are four available belt lengths: 32, 36, 40, and 55 with the default set at 55. ENTER to highlight value, arrows up/down to adjust. ENTER to accept and advance.



Belt Width

There are five available belt widths that correspond with the length selected. The default is set at 32. If a belt length of 32 is chosen, then the only option is a 18 belt width. If a belt length of 36 is chosen, then the only option is a 23 belt width. If 40 is chosen, then you can select 24 or 32. If a 55 is chosen, then you can select 32 or 38. ENTER to highlight value, arrows up/down to adjust. ENTER to accept and advance.



Main Fan Type

Factory default is On/Off type. To change, press ENTER key. Use Up/Down arrows to change between STD and VFD. Press ENTER to accept and advance.

Split Belt

MC1 is for left belt and MC2 is for right belt. Factory default is NO. To change press ENTER. Use Up/Down arrows to change to YES (still flashing). Press ENTER to accept and advance.



Dual Burner

MC1 is for the Right Hand Burner and MC2 is for the Left Hand Burner. Factory default is NO. To change press ENTER. Use Up/Down arrows to change to YES (still flashing). Press ENTER to accept and advance. If MC2 doesn't have a jumper error will show.



Fuel Type

Gas or Electric. Factory default is Gas. To Change press ENTER. Use Up/Down arrows and ENTER to accept and advance.



Remote Hood Switch

Factory default is NO. If there is a Remote Hood Switch installed, then press ENTER and NO flashes. Use Up/Down arrows to change to YES. Press ENTER to accept and advance.



Temp Offset Adjust

Factory default is zero. Allows the field tech to make adjustments up to +/- 20 degrees in temperature.

High Temp

Can be reduced in only 10 degree increments from factory default of 590 degrees Fahrenheit. No less than 500 degrees Fahrenheit. To change press ENTER and use Up/Down arrows to change and press ENTER to accept and advance.

Low Temp

The Oven can be reduced to 300 degrees Fahrenheit the factory default is 350 degrees Fahrenheit. If the field tech reduced temp to 300 degrees the control will allow it and display “Valve Change Reqd” To change press ENTER and use Up/Down arrows to change and press ENTER to accept and advance.



Main Fan

Only for units with On/Off main fan. VFD units are 3 phase, no monitoring by this control. This screen display shows Amp load on fan motor.



Belt Direction

If the belt direction needs changed from either Left to Right or Right to Left, then press ENTER and use Up/Down arrows to change the setting. The wire belt is non-directional and doesn’t physically need changed. If the conveyor is a split belt, then use the TIME button to toggle between belts. Press ENTER to accept and advance.



Main Fan Off Delay

To change press ENTER to highlight AUTO. Use Up/Down arrows to change to (TIMED 30:00) and press ENTER to accept and exit.



Beeper Button Test

Press ENTER to enter setting. A beep with each press of a button. Press ENTER to exit.

Menu Mode (Optional)



Menu Operation

1. To enter Menu Mode press MENU.
2. The number in the lower right hand corner will begin flashing.
3. Scroll through the menus by pressing Up/Down arrows (Max of 12 preset menus).
4. To select desired menu press ENTER. The number should have a solid black box around it.
5. To change to another menu selection press MENU and the solid black box will disappear and the number will start flashing.
6. When the number is flashing pressing MENU will exit Menu Mode.

Change Menu Setting

1. To change a setting, when the number is flashing go to desired preset and press ENTER and MENU for 3 seconds.
2. TEMP should start flashing. Use Up/Down arrows to select temp then press ENTER.
3. TIME should start flashing. Use Up/Down arrows to select time then press and hold ENTER and MENU for 3 sec to save preset.

Additional User Options

Lock Settings

1. To lock and unlock oven time and temperature press TIME and ENTER for 3 seconds till the LUI beeps once.
2. Then press TEMP, TIME, and TEMP within 3 seconds to lock settings.
3. A lock or unlock symbol will show up in the lower left corner of the LUI.

Fahrenheit To Celsius

1. To change temperature from Fahrenheit to Celsius press and hold TEMP and ENTER for 3 seconds and the settings will change.



Oven Control LED's:

LED's Status:

1. Power - Green (Illuminated when oven has power)
2. Conveyor - Green (Illuminated when conveyors are active)
3. Heat - Green (Illuminated when the SSR receives power)
4. Main Fan - Green (Illuminated when fan is spinning)
5. Cool Down - Green (Illuminated when oven is in cool down mode)
6. Alarm - Red (Illuminated when an alarm is tripped)

(All LED's on for reference)

Split Belt Conveyor Time Control



Your XLT oven is constructed of stainless steel. Most commercial cleaning agents may be used safely on all stainless steel surfaces. Check application restrictions on product label prior to usage. Observe recommended precautionary and safety measures as dictated by the product manufacturer. Do not use caustic cleaner on the conveyor bearings.

Do not use abrasive cleaners or abrasive pads as they can scratch stainless steel surfaces. Areas with heavy buildup should be sprayed and allowed to soak for up to 5 minutes prior to wiping clean. Always wipe with the "grain" of the surface to maintain appearance.

Do not use caustic cleaners on the control panel and/or electronic components. Only use cleaners compatible with Lexan® on the face of the conveyor control.

The most critical items to be cleaned are the filters on the cooling fans. The filters are held in place by the stainless steel fan guard/filter mounts and can be washed several times. Regular cleaning of the cooling filters is important to maintain air circulation within the control box. Depending upon store conditions, the filters should be cleaned weekly or as they get clogged with dust. Please contact XLT Ovens for replacement parts.



Cooling Filter Maintenance

1. When cooling filters need to be cleaned a alarm will appear on the LUI saying "FILTER".
2. Press the MENU button to enter the "FILTER RESET" screen.
3. Once the filter is cleaned, press ENTER to reset the filter timer. This will take you to another screen which will show you the timer back at 00:00 and will exit after 5 seconds.
4. If you wish to bypass alarm press the MENU button and it will clear the alarm for an additional 2 hours. Then the "FILTER" alarm will appear again.

DANGER

Oven must be cool and all power to the oven and hood turned off before any cleaning or maintenance is done.

CAUTION

If the oven is to be removed from its installed location for cleaning or servicing, the following procedure is to be followed:

1. Shut off main electrical disconnect.
2. Unplug electric cord, if equipped.
3. Unlock casters.
4. Disconnect restraint.
5. When servicing or cleaning is complete, move oven to original location.
6. Connect restraint.
7. Lock casters.
8. Plug in electric cord, if equipped.
9. Turn on main electrical disconnect.
10. Follow normal starting instructions.

TIP

Read and understand the next 11 steps first. They illustrate how to remove components from the oven for cleaning.



Opening the Sandwich Door will provide a grip location for removing the Front Panel.

TIP

CAUTION	Front Panels can weigh up to 75 lbs. [34 kg]. Use caution when lifting.
WARNING	Individuals with pacemakers or internal medical devices should not handle strong rare-earth magnets.






7


8


9





CAUTION

DO NOT spray liquid cleaning agents in the slots and holes in the following locations:

- Rear of Control Box
- Underneath Control Box
- Main Fan Motor Cover

As with any appliance, periodic maintenance is required. Many factors affect this schedule such as product mix and hours of usage. An example schedule is included.

Oven Maintenance Schedule					
		Daily	Weekly	Monthly	Semi-Annual
Cleaning					
	Empty Crumb Trays	□			
	Wipe down Front, Sides, & Top	□			
	Wipe down Control Box & Control Panel *	□			
	Clean or Replace Fan Filters	□			
	Remove large debris from Conveyor		□		
	Wipe down Motor Cover		□		
	Clean Sandwich Window		□		
	Remove debris from Finger Outers			□	
	Remove debris from inside Bake Chamber			□	
	Remove debris from Main Fan Motor			□	
	Clean Finger Outers				□
	Clean inside Bake Chamber				□
	Clean Conveyor Assembly				□
Inspection					
	Check Fan Filters for dirt	□			
	Check Conveyor Wire Belt for Stretch		□		
	Check Conveyor Drive Roller Chain for Stretch			□	
Adjust					
	Conveyor Wire Belt			□	
Lubricate					
	Conveyor Drive Roller Chain				□
Replace					
	Fan Filters				□

* Do not use caustic cleaners on the control panel. Only use cleaners compatible with Lexan® on the face of the conveyor control.

* Do not use water jet to clean ovens.

Contact a factory representative or a local service company to perform all other maintenance and repairs.

DANGER

Oven must be cool and all power to the oven and hood turned off before any cleaning is done.

Proper Cooking

Experimentation is about the only way to determine proper time and temperature settings. While a pizza may look perfectly cooked on the outside, the inside may be undercooked. A thermometer is necessary to determine if food items are being properly cooked. Most health departments have rules and regulations that establish minimum temperatures for internal food temperatures. Most operators want to cook foods as fast as possible in order to serve more customers per hour. However, cooking foods slower is the only way to achieve a proper internal temperature. If your food products look acceptable on the outside, but have an internal temperature that is too low, then lowering the temperature and decreasing the belt speed (thereby increasing the cook time), will be necessary.

Several factors may affect the cooking performance and characteristics:

- Oven temperature (generally affects color)
- Conveyor speed (generally affects doneness)
- Finger arrangement
- Altitude
- Pans versus screens
- Dough thickness
- Cheese type
- Raw ingredient temperature (frozen?)
- Quantity of toppings

XLT ovens can be configured to cook a wide variety of food items. This is accomplished by arranging the fingers to control the baking characteristics. Generally speaking, most cooking is a “bottom up” process. The hot air from the bottom row of fingers has to go through the conveyor (a distance of about 2” / 50.8mm), heat the pan or screen, and then actually cook raw dough. The hot air from the top, on the other hand, basically only has to melt cheese and re-heat precooked toppings. Consequently, most operators will use the oven with the fingers arranged so that a lot more air is directed to the bottom of the pizza than to the top. There are places for an equal number of fingers above and below the conveyor. Available are finger cover plates that have six rows of holes, four rows of holes, two rows of holes, and no holes (or blank cover plates). A typical finger arrangement might have most or even all fingers on the bottom “full open”, that is fingers with all six rows of holes, and only two or three fingers on top with four or six rows of holes. The top fingers can be arranged in a symmetrical pattern or can be shifted asymmetrically to either the entrance or exit end of the conveyor. We encourage you to experiment by trying different finger arrangements, temperatures and belt speeds. XLT Ovens can assist you with your oven/product configurations.

Mechanical Function

If your oven does not function properly, please verify the following conditions:

1. Verify that the power cord to the oven is connected and the disconnect is in the “on” position.
2. Check to see that the circuit breakers in the building electrical service panel have not been tripped or turned off.
3. Check all circuit breakers on the oven control panel to ensure they have not been tripped.
4. Ensure proper voltage, amperage, and wire size.

If your oven still does not function properly, XLT has qualified customer service personnel that can provide assistance on any type of XLT oven problem you may experience. Customer Service is available 24/7/365 at 888-443-2751, or visit www.xltovens.com.

DANGER

Check all local codes prior to installation. Special requirements may be necessary depending upon building material construction. It is the installing contractor's responsibly to ensure that the structure the hood is to be hung from meets all codes and can carry the hood weight.

Purchaser's Responsibility

It is the responsibility of the purchaser:

- Thoroughly review the floor plans and specifications. The exact location of the oven must be determined before installing the hood.
- To unload, uncrate, assemble, and install the hood to it's intended location.
- To ensure that electric utilities are installed on site in accordance with local building codes and with the specifications in this manual.
- To see that electric utilities are connected properly by a qualified installer using the proper hardware.
- To ensure a qualified installer has performed an initial start-up procedure.
- Location should minimize long and twisted duct runs. Make efforts to have a straight clear path to the roof fan curb.
- All hood supporting structures must be strong enough to support the weight of the hood and shrouds. Refer to the Hood Dimensions & Weights page for weight.
- Maintain the proper clearances from combustible materials according to International Mechanical code (IMC), and National Fire Protection Agency (NFPA) 96, and local mechanical codes.
- To Ensure that the AVI Hood is suspended properly from the ceiling structure.



The AVI Hood System consists of three (3) major parts; the Main Canopy, the Shrouds, and the Variable Frequency Drive (VFD) exhaust fan controller.

The Main Canopy serves to collect and transmit heat to the exhaust fan. It houses filters, lights, and switches. The switches control both the hood and ovens. The main canopy size is dependent upon oven size.

The Shrouds assist the efficiency of the main canopy by entrapping heat. They are configurable for either side or end loading or unloading, and are easily removable for cleaning and maintenance.

The VFD converts input power to variable frequency three-phase output power to control the speed of the exhaust fan. All electric utilities for the hood and exhaust fan connect through the electrical box located on the front of main canopy. The capacitive touch buttons are located on the Hood User Interface on the front of main canopy, and interlock the function of the hood and oven(s). There are relays that provide interlocks for equipment such as, HVAC dampers, and/or dedicated MUA units and there is a optional relay for fire suppression.

All AVI hoods are available pre-piped for fire suppression, allowing for simple, in-field installations. For fire suppression detailed information see manual XD-9011 Fire Suppression Installation for AVI Hoods and XLT Ovens.

The AVI hood was designed to conform to the requirements of IMC 2009, which is a Type I hood. It was also designed to have optional fire suppression added to meet requirements of NFPA 96 standard. This was done to allow XLT to better service the requirements of the customer and the associated jurisdictions.

This page is intentionally left blank.

HOOD CRATES



Hood Crate Dimensions			
Oven Model	X	Y	Z
xx32	94 1/4 [2394]	27 [686]	58 3/8 [1483]
xx40	102 1/4 [2597]	27 [686]	64 3/8 [1635]
xx55	117 1/4 [2978]	27 [686]	72 3/8 [1838]
xx70	132 1/4 [3359]	27 [686]	72 3/8 [1838]

SHROUD CRATES



Shroud Crate Dimensions			
Oven Model	X	Y	Z
18xx-2	51 1/4 [1302]	25 1/2 [648]	27 1/2 [699]
18xx-3	66 1/4 [1683]	25 1/2 [648]	27 1/2 [699]
24xx-2	51 1/4 [1302]	25 1/2 [648]	31 1/2 [800]
24xx-3	66 1/4 [1683]	25 1/2 [648]	31 1/2 [800]
32xx-2	51 1/4 [1302]	25 1/2 [648]	39 1/2 [1003]
32xx-3	66 1/4 [1683]	25 1/2 [648]	39 1/2 [1003]
38xx-2	51 1/4 [1302]	25 1/2 [648]	45 1/2 [1156]
38xx-3	66 1/4 [1683]	25 1/2 [648]	45 1/2 [1156]

NOTE: All dimensions in inches [millimeters], ± 1/4 [6], unless otherwise noted.
All weights in pounds [kilograms] unless otherwise noted.



ALL DIMENSIONS ARE FROM FINISHED FLOOR

Oven Model	Hood Dimensions										Hood Weights			Crated Weight (2 Crates)			
	A	B	C	D	E*	F*	G	H	J	K	Single	Double	Triple	Hood	Single	Double	Triple
1832	34 3/8 [873]	88 5/8 [2251]	18 [457]	32 [813]	13 1/2 [343]	30 5/8 [778]	12 [305]	69 5/8 [1768]	89 7/8 [2283]	91 7/8 [2334]	506 [230]	495 [225]	495 [225]	523 [237]	310 [141]	264 [120]	304 [138]
2440	40 3/8 [1026]	96 5/8 [2454]	24 [610]	40 [1016]		33 5/8 [854]					590 [268]	565 [256]	560 [254]	610 [277]	339 [154]	281 [127]	322 [146]
3240	48 3/8 [1229]	96 5/8 [2454]	32 [813]	40 [1016]		37 5/8 [956]					685 [311]	640 [290]	660 [299]	661 [277]	373 [154]	304 [127]	333 [146]
3255	48 3/8 [1229]	111 5/8 [2835]	32 [813]	55 [1397]		37 5/8 [956]					735 [333]	680 [308]	700 [318]	724 [300]	385 [169]	310 [138]	333 [151]
3855	54 3/8 [1381]	111 5/8 [2835]	38 [965]	55 [1397]		40 5/8 [1032]					795 [361]	730 [331]	745 [338]	764 [328]	408 [175]	310 [141]	339 [151]

Exhaust Fan And Curb Dimensions			Crated Weight (Stacked)
31 [787]	31 [787]	67 [1702]	185 [84]

NOTE

All dimensions in inches [millimeters], ± 1/4 [6], unless otherwise noted.
All weights in pounds [kilograms] unless otherwise noted.
* E and F are the minimum distances from a non combustible wall structure.

RECOMMENDED EXHAUST FLOW RATES

	Exhaust Flow Rates VOLUME (min. recommended)						
	Switches On			18xx	24xx	32xx	38xx
	Top	Middle	Bottom				
Single	X			500	500	500	500
				[14.16]	[14.16]	[14.16]	[14.16]
Double	X			500	500	500	500
				[14.16]	[14.16]	[14.16]	[14.16]
			X	506	644	828	966
				[14.33]	[18.24]	[23.45]	[27.35]
	X		X	506	644	828	966
				[14.33]	[18.24]	[23.45]	[27.35]
Triple	X			500	500	500	500
				[14.16]	[14.16]	[14.16]	[14.16]
		X		506	644	828	966
				[14.33]	[18.24]	[23.45]	[27.35]
			X	766	975	1254	1463
				[21.69]	[27.61]	[35.51]	[41.43]
	X	X		506	644	828	966
				[14.33]	[18.24]	[23.45]	[27.35]
	X		X	766	975	1254	1463
				[21.69]	[27.61]	[35.51]	[41.43]
		X	X	766	975	1254	1463
				[21.69]	[27.61]	[35.51]	[41.43]
	X	X	X	766	975	1254	1463
				[21.69]	[27.61]	[35.51]	[41.43]

NOTE All values are CFM [M3/Min] unless otherwise noted. Figures represent TOTAL VOLUME measured at the duct.

In accordance with mechanical codes, make up air must be supplied. For commercial kitchen make up air, the amount is determined by the exhaust hood flow rate requirements & all other exhaust flow rate requirements in the kitchen.

At a minimum, smoke candles must be used for a Capture & Containment (C&C) test. Refer to the Ventilation Requirements disclosed in the Oven section in this manual.

A Test & Balance (TAB) report is recommended after installation has been completed. Below are the minimum items to be included is this report:

- Total airflow on all A/C, Make-Up Air (MUA), & exhaust systems.
- Airflow on each supply & exhaust grille.
- Airflows on exhaust hoods compared to design specifications.

A final air balance report, with any corrections of issues found in the report, will help to insure that your building systems are functioning properly & efficiently.

Refer to "Oven Ventilation Requirements & Guidelines"

	Exhaust Flow Rates VELOCITY (min. recommended)						
	Switches On			18xx	24xx	32xx	38xx
	Top	Middle	Bottom				
Single	X			187.5	187.5	93.75	93.75
				[57.15]	[57.15]	[28.58]	[28.58]
Double	X			187.5	187.5	93.75	93.75
				[57.15]	[57.15]	[28.58]	[28.58]
			X	189.75	241.5	155.25	181.125
				[57.84]	[73.61]	[47.32]	[55.21]
	X		X	189.75	241.5	155.25	181.125
				[57.84]	[73.61]	[47.32]	[55.21]
Triple	X			187.5	187.5	93.75	93.75
				[57.15]	[57.15]	[28.58]	[28.58]
		X		189.75	241.5	155.25	181.125
				[57.84]	[73.61]	[47.32]	[55.21]
			X	287.25	365.625	235.125	274.3125
				[87.55]	[111.44]	[71.67]	[83.61]
	X	X		189.75	241.5	155.25	181.125
				[57.84]	[73.61]	[47.32]	[55.21]
	X		X	287.25	365.625	235.125	274.3125
				[87.55]	[111.44]	[71.67]	[83.61]
		X	X	287.25	365.625	235.125	274.3125
				[87.55]	[111.44]	[71.67]	[83.61]
	X	X	X	287.25	365.625	235.125	274.3125
				[87.55]	[111.44]	[71.67]	[83.61]

NOTE All values are FPM [M/Min] unless otherwise noted. Figures represent VELOCITY measured at the Grease Filter.

NOTE Most building codes require 500 Feet per Minute velocity. Exhaust duct is 1 ft^2. Check with your local building official for requirements.

The VELOCITY readings above are obtained by holding an anemometer 3” away from the Grease Filter. Take several readings in different locations across the filters and average the results.

Inputs into Electrical

	AVI Hood Electric Utility Specifications		
	# of Circuits	Rating	Purpose
Standard	1	208/240 VAC, 1 Phase, 60 Hz, 3 Amp	VFD Controller
	1	120 VAC, 1 Phase, 60 Hz, 1 Amp	Lights
World	1	230 VAC, 1 Phase, 50 Hz, 3 Amp	VFD Controller
	1	230 VAC, 1 Phase, 50 Hz, 1 Amp	Lights

CAUTION

Do not connect to 3 Phase power. 1 Phase Only.

Outputs from Electrical

The AVI Hood system provides:

- Up to (3) switching outputs for HVAC damper and/or dedicated unit.
- One (1) 230 VAC, 10 Amp, variable frequency, three phase power output for the ventilation exhaust fan.
- Relocation cord will physically connect into oven.





All structural members, electrical & fire suppression equipment shown for reference only.

VFD Control Box - Standard (230V / 60Hz)



Input Power to Lights



Input Power to VFD Controller - Standard (230V)



Input Power to VFD Controller - World (230V / 50Hz)



Input Power to VFD Controller - Standard (230V / 60Hz)



Input Power to VFD Controller - World (230V / 50Hz)



Power from VFD to Exhaust Fan - Standard



Power from VFD to Exhaust Fan - World



MUA Damper Relays - Single Output - Voltage & Frequency



Some wiring removed for clarity. See schematic for details.

MUA Damper Relays - Multiple Output - Voltage & Frequency



Some wiring removed for clarity. See schematic for details.

HOOD ELECTRICAL CONNECTIONS

World (230V / 50Hz) -W/Air Proving Switches



Some wiring removed for clarity. See schematic for details.

Fire Alarm Relay - Voltage & Frequency

NOTE

Connect wires from the Junction Box to the Normally Open (NO) contacts in the Fire Suppression cabinet.



Prepare Ovens - Remove Lid Screws - Two (2) Only



Prepare Ovens - Control Box Closeout Bracket



Conveyors have been removed for clarity

Prepare Ovens - Front Shroud Brackets





Prepare Ovens - Bottom Rail Bracket



Prepare Ovens - Control Box Side Closeout



Prepare Ovens - Rear Shroud Brackets



Prepare Hood



Lifting Gear Setup

AVI hoods can easily be moved and stacked with the proper lifting equipment. The use of XLT approved lifting equipment is highly recommended. Contact XLT for more information.





Lifting Jack Setup

DANGER

- Check for smooth operation. The cable should not be pinched & should pass smoothly over the pulley on top of the pole assembly.
- Inspect cable prior to each use.
- If cable is frayed or shows signs of excessive wear & tear, DO NOT USE until cable is replaced.
- At a minimum replace the cable annually with wire rope that meets or exceeds the jack manufacturer's specifications.
- Do not exceed the stated capacity of the jack.



Stacking Hood on the Ovens

DANGER

Failure to engage the Lifting Jacks into the Lifting Pipe properly and completely will result in damage, injury, or death from a falling hood.

DANGER

- Both jacks should be raised in unison, otherwise they may bind and a dangerous situation will develop.
- Do not put any part of yourself under the hood at any time.
- The hood is top heavy. Be careful.



Hang Hood From Ceiling Joists

DANGER

Hood Must Be Suspended From Ceiling Joists



NOTE

This measurement is from the finished floor to the bottom of the suspended hood.

Install Grease Trays, Light Bulbs & Covers, and Grease Filters





Install Shroud Hanging Brackets



Parts Removed For Clarity

Install Corner Posts



Install Bottom Rails

1



2



Install Bottom Rails



Install Control Box Upper Closeout



NOTE If installing a 70” model, the same will apply for the LH side of ovens.

Install Shroud Panels - Front and Ends



Install Take-Off Trays



Install Back Shroud Panel



If installing a 70” model, refer to page 78

NOTE

Install Hood Relocation Cord Assembly



All hoods are outfitted with three (3) switch relocation receptacles, regardless of how many XLT Ovens are installed. For a single oven use “Top” location. For a double stack use “Top” location for upper oven and “Bottom” location for lower oven, leaving “Middle” location open.

Insert and lock each oven control cord into the designated location on the bottom of the hood control box.

Connect Hood Relocation Cord Assembly

1



2



3



4



Variable Frequency Drive Adjustments

All AVI Hoods are functionally tested at the factory. Operation is verified, and adjustments are made to ensure proper operation. However, field conditions are sometimes different than factory conditions. These variables make it necessary to have an authorized service technician verify operation and make field adjustments if needed. The following items must be checked and verified to meet the specifications and requirements stated in this manual prior to the hood being commissioned:

- **Correct fan rotation**
- **Balanced make-up air**

The Initial Start-Up Checklist must be completed at time of installation, signed by the Customer and returned to XLT Ovens to initiate Warranty Policy.

The VFD controller is adjusted at the factory to the values displayed in the chart below.

	VFD Controller Settings					
	Switches On			1832 & 2440	3240 & 3255	3855
	Top	Middle	Bottom			
Single	X			20 Hz	25 Hz	30Hz
Double	X			20 Hz	25 Hz	30Hz
			X	35 Hz	40 Hz	45 Hz
	X		X	35 Hz	40 Hz	45 Hz
Triple	X			20 Hz	25 Hz	30Hz
		X		30 Hz	35 Hz	40 Hz
			X	40 Hz	45 Hz	50 Hz
	X	X		30 Hz	35 Hz	40 Hz
	X		X	40 Hz	45 Hz	50 Hz
		X	X	40 Hz	45 Hz	50 Hz
	X	X	X	45 Hz	50 Hz	55 Hz
Fire Suppression				60 Hz-DO NOT CHANGE		

If you require either more or less air flow, follow these steps:

1. Press & hold the <HOOD LIGHT> and <XLT LOGO> buttons to enter into factory tech mode.
2. Use the Up/Down arrows to reach manual air balance.
3. Press and hold <ENTER> button for 3 seconds. Entire row will flash.
4. Scroll to desired oven setting. Press <ENTER>.
5. +/- should flash and it allows +/- change upto 10 Hz.
6. Press <ENTER> to save changes.
7. Press <ON> to test air balance.

Initial Start Up



NOTE

When XLT Ovens are outfitted with a XLT Hood and the receptacles unplugged from the wall and plugged into the hood., the main switch on the oven is disabled and no longer operates. The Hood User Interface (HUI) on the XLT Hood overrides the oven switch.

Hood Operation

1. Turn the desired oven(s) on by pressing the corresponding oven button. Refer to the Oven start-up section for instructions on how to adjust temperature and conveyor speed. The oven(s), exhaust fan, and make-up air unit will be activated by this switch if the XLT Hood is installed according to this manual.
2. Turn on the lights by pressing the hood lights button on the HUI. (Bulbs not included with hood)
3. When additional ovens are turned on, via the HUI the VFD will automatically increase the exhaust fan speed.
4. When shutting down the ovens, turn the desired oven off by pressing the corresponding button on the HUI. The make-up air unit will shut off. The exhaust fan will shut off after about 15 minutes and the oven will shut off after about 30 minutes.

Resetting Hood Cooling Fan and Grease Timer



1. The Cooling Fan and Grease Filter reset alarm will show up in the lower left hand side of the Hood User Interface. Press the Error Information button to enter reset screen.

2. To reset the Cooling Fan or Grease Filter press the center capacitive touch button with reset above it to set the time back to zero.

3. The following screen will show for 5 seconds and then return to the normal operating screen.

Factory Tech Mode

1. To enter Factory Tech Mode press and hold 2 buttons <HOOD LIGHT> and <XLT LOGO> for 10 sec. to enter.
2. Displays will show message for 3 sec. and beep, auto-advance.

Software Version

MC & UI Software Version. Press Down arrow to go to next screen. Image For Reference Only - See XLT For Correct Version



Serial Number

ENTER button to make changes. Use side to side arrows to scroll through the menu. Use Up/Down arrows to change values and ENTER to accept and advance.

Belt Length

There are four available belt lengths: 32, 40, 55 and 70 with the default set at 55. ENTER to highlight value, arrows up/down to adjust. ENTER to accept and advance.

Belt Width

There are four available belt widths that correspond with the length selected. The default is set at 32. If a belt length of 32 is chosen the only option is a 18 belt width. If 40 is chosen you can select a 24 or 32. If a 55 or 70 is chosen you can select a 32 or 38. ENTER to highlight value, arrows up/down to adjust. ENTER to accept and advance.

Elapsed Time

Elapsed time total operation. Elapsed time total cannot be reset. Press ENTER to advance.

Cooling Filter

Elapsed time since Cooling Filter cleaned. Resets when customer resets it. Press the Error Information button to reset time if needed. Hour Interval is a service tech reference. Press Down arrow to advance.

Grease Filter

Elapsed time since Grease Filters cleaned. Resets when customer resets it. Press the Error Information button to reset time if needed. Hour Interval is a service tech reference. Press Down arrow to advance.



VFD Exhaust Fan

Default YES. Some hoods without VFD, This will not be used. ENTER to accept and advance.



Oven Quantity

Set quantity of ovens (1, 2, 3). Default is 2. ENTER to highlight value, arrows to change, ENTER to accept and advance.

Makeup Air Mode

Common or Per oven. Default common. Common MUA is on with any oven and has 1 speed setting. Per Oven MUA on per oven with up to 3 speed settings. ENTER to highlight values, arrows to change, ENTER to accept and advance.



Prove Air Flow

NO or YES. Default NO. CE and Australia require proving before oven ON. ENTER to highlight value, arrows to change, ENTER to accept and advance.

Manual Makeup Air

Common, 1, 2, or 3. This function can turn all ON or run individuals. ENTER to highlight value, ON to select units. Arrows to change, ENTER to accept and advance.

Manual VFD

This function can run VFD at 5Hz steps from 0-65Hz. ENTER to highlight value, use Up/Down arrows to increase and decrease value. ON to activate at selected speed. ENTER to accept and advance.



Air Balance

User to press ENTER to edit the -/+ value. Default of 0Hz for the +/- value. Once the -/+ value is in Edit Mode (flashing), press and hold ENTER for 3seconds. This allows user to select other lines (the entire line flashes at this point). Up/down arrows to scroll table to get to desired line. Press ENTER again to accept that line and make active. Press ON to turn fan on to setting (icon changes to OFF so user knows to press again to turn it OFF). Use +/- to change Hz for that setting until desired value shown. The Maximum ACT setting is 65Hz. Off when done with that value. Repeat with other settings as needed. Once all done, ENTER to accept and exit.

This is only portion of the VFD table that fits in display. 4 lines available, 2 are the titles, 2 are table values. Scroll Up/Down to see more of the table.

The valance kit size is determined by AVI Hood size & distance from the finished floor to the installed drop ceiling height. The valance kit screws directly to the AVI Hood & does not require any structural support. All kits have provisions for hood fire suppression piping to pass through without modification. The plastic coating must be removed from all parts prior to installation.



AVI Hood valance kits are available for different floor to ceiling heights. Contact XLT Ovens or your designated representative for more information.

Install Valance Brackets



Install Front & Back Panels



Install Corner Panels



Install End Panels







Your AVI hood is constructed of stainless and aluminized steel. Check application restrictions on product label prior to usage. Observe recommended precautionary and safety measures as dictated by the product manufacturer.

Do not use abrasive or caustic cleaners. Abrasive pads will scratch stainless steel surfaces. Areas with heavy buildup should be sprayed and allowed to soak for up to 5 minutes prior to wiping clean. Always wipe with the "grain" of the surface to maintain appearance.

Hood Cleaning & Maintenance Schedule						
		Daily	Weekly	Monthly	Semi-Annual	As Required
Cleaning						
	Wipe down Front, Sides, & Top	□				
	Clean Light Globes	□				
	Empty & Clean Grease Trays	□				□
	Clean or Replace Fan Filter	□				□
	Clean Grease Filters		□			□
	Clean Duct and Exhaust Fan			□		□
Inspection						
	Check Grease Trays	□				
	Check Grease Filters		□			
Adjust						
	No Adjustments Necessary					
Lubricate						
	No Lubrication Required					
Replace						
	Fan Filter					□
	Light Bulbs					□

Schedule provided as a guide only. Frequency of cleaning may vary as needed.

DANGER

Oven must be cool and all power to the oven and hood turned off before any cleaning is done.

CAUTION

Shroud Panels can weigh up to 60 lbs [27 kg]. Use caution when lifting.

CAUTION

DO NOT spray liquid cleaning agents in the slots & holes of the following locations:

- Hood electrical box (located on front of upper portion)
- User Interface (Located on front lower right corner)

Refer to the Hood Installation Section for disassembly and reassembly.

OVEN SCHEMATIC - STANDARD 208/240 VAC LH



X3G-1832
X3G-2336

208/240 VAC 3 PH 60 Hz
XD-9130G-208/240-5300-3 LH
LH Controls Left Side
10/16/2017

C1	Contactor, 70 Amp	M1	Motor, Oven Fan	R1	Oven Fan Motor Relay
CAP	Capacitor 30µF	M2	Motor, Conveyor	S2	Switch, Centrifugal
CB1	Circuit Breaker, 10 Amp, Main	M3	Motor, Cooling Fan	S3	Switch, High Limit
CB2	Circuit Breaker, 63 Amp, Heating Elements	OMC1	Oven Control, Main	SSR1	Solid State Relay, 90 Amp
CB5	Circuit Breaker, 1/2 Amp, Conveyor Motor	OMC2	Oven Control, Split Belt	SSR2	Solid State Relay, 90 Amp
CB6	Circuit Breaker, 1/2 Amp, Conveyor Motor	PB	Power Block	TC	Thermocouple
CS	Current Sensor	PL1	Push Lock, 1-3 Elements	TS2	Terminal Strip
H1-H3	Heating Element, 208 or 240 VAC, 5300 W	PS	Power Supply	WC1	Wago Connector
LUI	Large User Interface	PU	Pick-Up	WC2	Wago Connector

RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow OR-Orange WH-White GY-Gray



X3G-1832
X3G-2336

208/240 VAC 3 PH 60 Hz
XD-9130G-208/240-5300-3 RH
RH Controls Right Side
10/16/2017

C1	Contactor, 70 Amp	M1	Motor, Oven Fan	R1	Oven Fan Motor Relay
CAP	Capacitor 30µF	M2	Motor, Conveyor	S2	Switch, Centrifugal
CB1	Circuit Breaker, 10 Amp, Main	M3	Motor, Cooling Fan	S3	Switch, High Limit
CB2	Circuit Breaker, 63 Amp, Heating Elements	OMC1	Oven Control, Main	SSR1	Solid State Relay, 90 Amp
CB5	Circuit Breaker, 1/2 Amp, Conveyor Motor	OMC2	Oven Control, Split Belt	SSR2	Solid State Relay, 90 Amp
CB6	Circuit Breaker, 1/2 Amp, Conveyor Motor	PB	Power Block	TC	Thermocouple
CS	Current Sensor	PL1	Push Lock, 1-3 Elements	TS2	Terminal Strip
H1-H3	Heating Element, 208 or 240 VAC, 5300 W	PS	Power Supply	WC1	Wago Connector
LUI	Large User Interface	PU	Pick-Up	WC2	Wago Connector

RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow OR-Orange WH-White GY-Gray


X3G-2440
X3G-3240
208 VAC 3 PH 60 Hz
XD-9130G-208/240-4500-6 LH
LH Controls Left Side
10/16/2017
L1
L2
L3
GND
CB1
CN1
PS
CN2
4A FUSE
S3 NC-600°F
MC6
S2
208/240 V XP-5016A
-CCW- Shaft End
MC1
CS
PB
R1
CAP 30 µF
CB2
CB3
C1
C2
MC3
TS2
LUI
WC1
WC2
SSR 1
SSR 2
SSR 3
SSR 4
M3
M2
PU
TC
P11
P2
P9
P8
OMC1
OMC2
P10
P7
P4
P1
Jumper
Optional Split Belt
CB5
CB6
PL1
PL2
H1
H2
H3
H4
H5
H6
Oven Fan Motor Relay
Switch, Centrifugal
Switch, High Limit
Solid State Relay, 90 Amp
Solid State Relay, 90 Amp
Solid State Relay, 90 Amp
Solid State Relay, 90 Amp
Thermocouple
Terminal Strip
Wago Connector
Wago Connector
R1
S2
S3
SSR1
SSR2
SSR3
SSR4
TC
TS2
WC1
WC2
M1 Motor, Oven Fan
M2 Motor, Conveyor
M3 Motor, Cooling Fan
OMC1 Oven Control, Main
OMC2 Oven Control, Split Belt
PB Power Block
PL1 Push Lock, 1-3 Elements
PL2 Push Lock, 4-6 Elements
PS Power Supply
PU Pick-Up
C1 Contactor, 70 Amp
C2 Contactor, 70 Amp
CAP Capacitor 30µF
CB1 Circuit Breaker, 10 Amp, Main
CB2 Circuit Breaker, 63 Amp, Heating Elements
CB3 Circuit Breaker, 63 Amp, Heating Elements
CB5 Circuit Breaker, 1/2 Amp, Conveyor Motor
CB6 Circuit Breaker, 1/2 Amp, Conveyor Motor
CS Current Sensor
H1-H3 Heating Element, 208 or 240 VAC, 4500 W
H4-H6 Heating Element, 208 or 240 VAC, 4500 W
LUI Large User Interface
RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow OR-Orange WH-White GY-Gray


X3G-2440
X3G-3240
208 VAC 3 PH 60 Hz
XD-9130G-208/240-4500-6 RH
RH Controls Right Side
10/16/2017
Optional Split Belt
LUI
TS2
SSR 1
SSR 2
SSR 3
SSR 4
PL1
PL2
PB
CS
CAP
30 µF
208/240 V
XP-5016A
-CCW-
Shaft End
L1
L2
L3
GND
C1 Contactor, 70 Amp
C2 Contactor, 70 Amp
CAP Capacitor 30µF
CB1 Circuit Breaker, 10 Amp, Main
CB2 Circuit Breaker, 63 Amp, Heating Elements
CB3 Circuit Breaker, 63 Amp, Heating Elements
CB5 Circuit Breaker, 1/2 Amp, Conveyor Motor
CB6 Circuit Breaker, 1/2 Amp, Conveyor Motor
CS Current Sensor
H1-H3 Heating Element, 208 or 240 VAC, 4500 W
H4-H6 Heating Element, 208 or 240 VAC, 4500 W
LUI Large User Interface
M1 Motor, Oven Fan
M2 Motor, Conveyor
M3 Motor, Cooling Fan
OMC1 Oven Control, Main
OMC2 Oven Control, Split Belt
PB Power Block
PL1 Push Lock, 1-3 Elements
PL2 Push Lock, 4-6 Elements
PS Power Supply
PU Pick-Up
R1 Oven Fan Motor Relay
S2 Switch, Centrifugal
S3 Switch, High Limit
SSR1 Solid State Relay, 90 Amp
SSR2 Solid State Relay, 90 Amp
SSR3 Solid State Relay, 90 Amp
SSR4 Solid State Relay, 90 Amp
TC Thermocouple
TS2 Terminal Strip
WC1 Wago Connector
WC2 Wago Connector
RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow OR-Orange WH-White GY-Gray


X3G-3255
X3G-3855
208 VAC 3 PH 60 Hz
XD-9130G-208/240-5300-6 LH
LH Controls Left Side
10/16/2017
L1
L2
L3
GND
CB1
CN1
CN2
PS
4A FUSE
S3 NC-600°F
MC6
PB
208/240 V XP-5016A
-CCW- Shaft End
MC1
CS
R1
CAP 30 µF
CB2
CB3
C1
C2
MC3
TS2
LUI
WC1
WC2
SSR 1
SSR 2
SSR 3
SSR 4
M3
CB5
CB6
PL1
PL2
H1
H2
H3
H4
H5
H6
M2
PU
P11
P2
P9
P8
OMC1
P10
P7
P1
P4
TC
Jumper
Optional Split Belt
Oven Fan Motor Relay
Switch, Centrifugal
Switch, High Limit
Solid State Relay, 90 Amp
Solid State Relay, 90 Amp
Solid State Relay, 90 Amp
Solid State Relay, 90 Amp
Thermocouple
Terminal Strip
Wago Connector
Wago Connector
R1
S2
S3
SSR1
SSR2
SSR3
SSR4
TC
TS2
WC1
WC2
M1 Motor, Oven Fan
M2 Motor, Conveyor
M3 Motor, Cooling Fan
OMC1 Oven Control, Main
OMC2 Oven Control, Split Belt
PB Power Block
PL1 Push Lock, 1-3 Elements
PL2 Push Lock, 4-6 Elements
PS Power Supply
PU Pick-Up
WH-White GY-Gray
OR-Orange
C1 Contactor, 70 Amp
C2 Contactor, 70 Amp
CAP Capacitor 30µF
CB1 Circuit Breaker, 10 Amp, Main
CB2 Circuit Breaker, 63 Amp, Heating Elements
CB3 Circuit Breaker, 63 Amp, Heating Elements
CB5 Circuit Breaker, 1/2 Amp, Conveyor Motor
CB6 Circuit Breaker, 1/2 Amp, Conveyor Motor
CS Current Sensor
H1-H3 Heating Element, 208 or 240 VAC, 5300 W
H4-H6 Heating Element, 208 or 240 VAC, 5300 W
LUI Large User Interface
RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow


X3G-3255
X3G-3855
208 VAC 3 PH 60 Hz
XD-9130G-208/240-5300-6 RH
RH Controls Right Side
10/16/2017
Optional Split Belt
Jumper
LUI
TC
CS
CAP
30 µF
208/240 V
XP-5016A
-CCW-
Shaft End
PS
FUSE
4A
SSR 1
SSR 2
SSR 3
SSR 4
PL1
PL2
PB
MC1
MC6
S3
NC-600°F
L1
L2
L3
GND
C1 Contactor, 70 Amp
C2 Contactor, 70 Amp
CAP Capacitor 30µF
CB1 Circuit Breaker, 10 Amp, Main
CB2 Circuit Breaker, 63 Amp, Heating Elements
CB3 Circuit Breaker, 63 Amp, Heating Elements
CB5 Circuit Breaker, 1/2 Amp, Conveyor Motor
CB6 Circuit Breaker, 1/2 Amp, Conveyor Motor
CS Current Sensor
H1-H3 Heating Element, 208 or 240 VAC, 5300 W
H4-H6 Heating Element, 208 or 240 VAC, 5300 W
LUI Large User Interface
M1 Motor, Oven Fan
M2 Motor, Conveyor
M3 Motor, Cooling Fan
OMC1 Oven Control, Main
OMC2 Oven Control, Split Belt
PB Power Block
PL1 Push Lock, 1-3 Elements
PL2 Push Lock, 4-6 Elements
PS Power Supply
PU Pick-Up
R1 Oven Fan Motor Relay
S2 Switch, Centrifugal
S3 Switch, High Limit
SSR1 Solid State Relay, 90 Amp
SSR2 Solid State Relay, 90 Amp
SSR3 Solid State Relay, 90 Amp
SSR4 Solid State Relay, 90 Amp
TC Thermocouple
TS2 Terminal Strip
WC1 Wago Connector
WC2 Wago Connector
RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow OR-Orange WH-White GY-Gray



C1	Contactor, 70 Amp	LR	Line Reactor, 5% Impedance	S2	Switch, Centrifical
CB2	Circuit Breaker, 63 Amp, Heating Elements	M1	Motor, Oven Fan	S3	Switch, High Limit
CB4	Circuit Breaker, 10 Amp, Main	M2	Motor, Conveyor	SSR1	Solid State Relay, 90 Amp
CB5	Circuit Breaker, 1/2 Amp, Conveyor Motor	M3	Motor, Cooling Fan	SSR2	Solid State Relay, 90 Amp
CB6	Circuit Breaker, 1/2 Amp, Conveyor Motor	OMC1	Oven Control, Main	TC	Thermocouple
CB9	Circuit Breaker, 1/2 Amp, High Limit	OMC2	Oven Control, Split Belt	TS2	Terminal Strip
FLT1	Filter, Control Voltage	PL1	Push Lock, 1-3 Elements	VFD	Variable Frequency Drive
H1-H3	Heating Element, 240 VAC, 5300 W	PS	Power Supply	WC1	Wago Connector
LUI	Large User Interface	PU	Pick-Up	WC2	Wago Connector

RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow OR-Orange WH-White GY-Gray



C1 Contactor, 70 Amp
CB2 Circuit Breaker, 63 Amp, Heating Elements
CB4 Circuit Breaker, 10 Amp, Main
CB5 Circuit Breaker, 1/2 Amp, Conveyor Motor
CB6 Circuit Breaker, 1/2 Amp, Conveyor Motor
CB9 Circuit Breaker, 1/2 Amp, High Limit
FLT1 Filter, Control Voltage
H1-H3 Heating Element, 240 VAC, 5300 W
LUI Large User Interface

LR Line Reactor, 5% Impedance
M1 Motor, Oven Fan
M2 Motor, Conveyor
M3 Motor, Cooling Fan
OMC1 Oven Control, Main
OMC2 Oven Control, Split Belt
PL1 Push Lock, 1-3 Elements
PS Power Supply
PU Pick-Up

S2 Switch, Centrifical
S3 Switch, High Limit
SSR1 Solid State Relay, 90 Amp
SSR2 Solid State Relay, 90 Amp
TC Thermocouple
TS2 Terminal Strip
VFD Variable Frequency Drive
WC1 Wago Connector
WC2 Wago Connector

RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow OR-Orange WH-White GY-Gray



C1	Contactor 70 Amp	LR	Line Reactor, 5% Impedance	S2	Switch, Centrifugal
CB2	Circuit Breaker, 63 Amp, Heating Elements	M1	Motor, Oven Fan	S3	Switch, High Limit
CB4	Circuit Breaker, 10 Amp, Main	M2	Motor, Conveyor	SSR1	Solid State Relay, 90 Amp
CB5	Circuit Breaker, 1/2 Amp, Conveyor Motor	M3	Motor, Cooling Fan	SSR2	Solid State Relay, 90 Amp
CB6	Circuit Breaker, 1/2 Amp, Conveyor Motor	OMC1	Oven Control, Main	TC	Thermocouple
CB9	Circuit Breaker, 1/2 Amp, High Limit	OMC2	Oven Control, Split Belt	TS2	Terminal Strip
FLT1	Filter, Control Voltage	PL1	Push Lock, 1-3 Elements	VFD	Variable Frequency Drive
H1-H3	Heating Element, 240 VAC, 4500 W	PL2	Push Lock, 4-6 Elements	WC1	Wago Connector
H4-H6	Heating Element, 240 VAC, 4500 W	PS	Power Supply	WC2	Wago Connector
LUI	Large User Interface	PU	Pick-Up		

RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow OR-Orange WH-White GY-Gray



C1 Contactor 70 Amp
CB2 Circuit Breaker, 63 Amp, Heating Elements
CB4 Circuit Breaker, 10 Amp, Main
CB5 Circuit Breaker, 1/2 Amp, Conveyor Motor
CB6 Circuit Breaker, 1/2 Amp, Conveyor Motor
CB9 Circuit Breaker, 1/2 Amp, High Limit
FLT1 Filter, Control Voltage
H1-H3 Heating Element, 240 VAC, 4500 W
H4-H6 Heating Element, 240 VAC, 4500 W
LUI Large User Interface

LR Line Reactor, 5% Impedance
M1 Motor, Oven Fan
M2 Motor, Conveyor
M3 Motor, Cooling Fan
OMC1 Oven Control, Main
OMC2 Oven Control, Split Belt
PL1 Push Lock, 1-3 Elements
PL2 Push Lock, 4-6 Elements
PS Power Supply
PU Pick-Up

S2 Switch, Centrifugal
S3 Switch, High Limit
SSR1 Solid State Relay, 90 Amp
SSR2 Solid State Relay, 90 Amp
TC Thermocouple
TS2 Terminal Strip
VFD Variable Frequency Drive
WC1 Wago Connector
WC2 Wago Connector

RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow OR-Orange WH-White GY-Gray



C1	Contactor, 70 Amp	LR	Line Reactor, 5% Impedance	S2	Switch, Centrifugal
CB2	Circuit Breaker, 63 Amp, Heating Elements	M1	Motor, Oven Fan	S3	Switch, High Limit
CB4	Circuit Breaker, 10 Amp, Main	M2	Motor, Conveyor	SSR1	Solid State Relay, 90 Amp
CB5	Circuit Breaker, 1/2 Amp, Conveyor Motor	M3	Motor, Cooling Fan	SSR2	Solid State Relay, 90 Amp
CB6	Circuit Breaker, 1/2 Amp, Conveyor Motor	OMC1	Oven Control, Main	TC	Thermocouple
CB9	Circuit Breaker, 1/2 Amp, High Limit	OMC2	Oven Control, Split Belt	TS2	Terminal Strip
FLT1	Filter, Control Voltage	PL1	Push Lock, 1-3 Elements	VFD	Variable Frequency Drive
H1-H3	Heating Element, 240 VAC, 5300 W	PL2	Push Lock, 4-6 Elements	WC1	Wago Connector
H4-H6	Heating Element, 240 VAC, 5300 W	PS	Power Supply	WC2	Wago Connector
LUI	Large User Interface	PU	Pick-Up		

RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow OR-Orange WH-White GY-Gray



X3G-3255
X3G-3855

380 VAC 3 PH 50 Hz
XD-9130G-380-5300-6 RH
RH Controls Right Side
10/16/2017

C1	Contactor, 70 Amp	LR	Line Reactor, 5% Impedance	S2	Switch, Centrifugal
CB2	Circuit Breaker, 63 Amp, Heating Elements	M1	Motor, Oven Fan	S3	Switch, High Limit
CB4	Circuit Breaker, 10 Amp, Main	M2	Motor, Conveyor	SSR1	Solid State Relay, 90 Amp
CB5	Circuit Breaker, 1/2 Amp, Conveyor Motor	M3	Motor, Cooling Fan	SSR2	Solid State Relay, 90 Amp
CB6	Circuit Breaker, 1/2 Amp, Conveyor Motor	OMC1	Oven Control, Main	TC	Thermocouple
CB9	Circuit Breaker, 1/2 Amp, High Limit	OMC2	Oven Control, Split Belt	TS2	Terminal Strip
FLT1	Filter, Control Voltage	PL1	Push Lock, 1-3 Elements	VFD	Variable Frequency Drive
H1-H3	Heating Element, 240 VAC, 5300 W	PL2	Push Lock, 4-6 Elements	WC1	Wago Connector
H4-H6	Heating Element, 240 VAC, 5300 W	PS	Power Supply	WC2	Wago Connector
LUI	Large User Interface	PU	Pick-Up		

RD-Red BK-Black BL-Blue BR-Brown GR/YL-Green Yellow OR-Orange WH-White GY-Gray


HD-9130E-ELE-VFD-S
03/16/2017
HUI
CN1
CN2
PS
FUSE 4A
M1
HMC
In Circuit Board
Oven Power
P3
P8 FS
P13 APS Ex
P20 APS MUA
P9 Power
P25 VHUI
P15 VFD
P7 Cntrls
P10 SRC
P1 Dampers
TS1
TS2
TS3
LH Only
REC4
REC5
REC6
PLUG1
PLUG2
PLUG3
Switch Relocation Cord
Optional
LT1
LT2
M2
M3
MC2
R1
R2
CB1
VFD
MUA APS COM 11
MUA APS NO 12
MUA APS NC 13
Exh APS COM 14
Exh APS NO 15
MUA COM 16
MUA Bot 17
MUA Mid 18
MUA Top 19
Empty 20
1 L1 230V
2 N / L2 230V
3 230V 3 PH
4 230V 3 PH
5 230V 3 PH
6 N / L2
7 Empty
8 Empty
9 FA Out
10 FA In
N 110V Lights (By Installer)
L1 110V Lights (By Installer)
BK (By Installer)
RD (By Installer)
BL (By Installer)
CB1 Circuit Breaker, 10 Amp
HMC Hood Machine Control
HUI Hood User Interface
LT1 Lamp, 60W Bulb
LT2 Lamp, 60W Bulb
M1 Motor, Exhaust Fan
M2 Motor, Cooling Fan
M3 Motor, Cooling Fan
PS Power Supply
R1 Fire Suppression Relay
R2 Fire Suppression Time Delay Relay
REC4 Receptacle, Switch, Top Oven
REC5 Receptacle, Switch, Middle Oven
REC6 Receptacle, Switch, Bottom Oven
SRC Switch Relocation Cord
TS1 Terminal Strip
TS2 Terminal Strip
TS3 Terminal Strip
VFD Variable Frequency Drive
** - Remove Jumpers for APS
RD-Red BK-Black BL-Blue BR-Brown GR-Green YL-Yellow PR-Purple HT-High Temp OR-Orange WH-White GY-Gray


HD-9130E-ELE-VFD-W
03/16/2017
** - Remove Jumpers for APS
TS1 Terminal Strip
TS2 Terminal Strip
TS3 Terminal Strip
VFD Variable Frequency Drive
REC4 Receptacle, Switch, Top Oven
REC5 Receptacle, Switch, Middle Oven
REC6 Receptacle, Switch, Bottom Oven
SRC Switch Relocation Cord
CB1 Circuit Breaker, 10 Amp
HMC Hood Machine Control
HUI Hood User Interface
LT1 Lamp, 60W Bulb
LT2 Lamp, 60W Bulb
M1 Motor, Exhaust Fan
M2 Motor, Cooling Fan
M3 Motor, Cooling Fan
PS Power Supply
R1 Fire Suppression Relay
R2 Fire Suppression Time Delay Relay
RD-Red BK-Black BL-Blue BR-Brown GR-Green YL-Yellow PR-Purple HT-High Temp OR-Orange WH-White GY-Gray
HUI
CN1
PS
CN2
4A FUSE
M1
P25 VHUI
P15 VFD
P9 Power
P13 APS Ex
P20 APS MUA
P8 FS
HMC
P3 Oven Power
In Circuit Board
Lights
Fan
P7
P10 SRC
P1 Dampers
LH Only
TS3
REC4
REC5
REC6
Switch Relocation Cord
Optional
PLUG1
PLUG2
PLUG3
TS2
MUA APS COM 11
MUA APS NO 12
MUA APS NC 13
Exh APS COM 14
Exh APS NO 15
MUA COM 16
MUA Bot 17
MUA Mid 18
MUA Top 19
Empty 20
TS1
1 L1 230V
2 N / L2 230V
3 230V 3 PH
4 230V 3 PH
5 230V 3 PH
6 N / L2
7 Empty
8 Empty
9 FA Out
10 FA In
(By Installer)
N 230V Lights
L1 230V Lights
LT1
LT2
M2
M3
MC2
R1
R2
CB1
VFD
BK (By Installer)
RD (By Installer)
BL (By Installer)



LT1	Lamp, 60W Bulb
LT2	Lamp, 60W Bulb
REC4	Receptacle, Top Oven
REC5	Receptacle, Middle Oven
REC6	Receptacle, Bottom Oven
S1	Switch, Light
S2	Switch, Top Oven
S3	Switch, Middle Oven
S4	Switch, Bottom Oven
TS1	Terminal Strip
TS3	Terminal Strip

RD-Red BK-Black BL-Blue GR-Green HT-High Temp WH-White

HD-9130E-NV
03/16/2017

Product Certifications and Applicable Codes

Standard XLT Oven Certifications [1]:

XLT Gas Ovens:

1. ANSI Z83.11-2016/CSA 1.8-2016 Standard for Gas Food Service Equipment
2. ANSI /NSF 4-2014 Sanitation for Commercial Cooking Rethermalization & Powered Hot Food Holding & Transportation Equipment

XLT Electric Ovens:

1. UL197 Commercial Electric Appliances
2. ANSI /NSF 4-2014 Sanitation for Commercial Cooking Rethermalization & Powered Hot Food Holding & Transportation Equipment

World XLT Oven Certifications[1] :

XLT Gas Ovens:

1. EN 60335-2-42:2003 + A11: 2012, used in conjunction with EN 60335-1:2002, Safety of Household Appliances and Similar Electrical Appliances
2. EN 60335-1-2002 +A11, A04, +A12, A2:2006 +A1 Low Voltage Directive (LVD)
3. EN 55014-1:2006 +A1:2009 +A2:2011 EN 61000-3-2:2014, EN 61000-3-3:2013 Electromagnetic Compatibility. (EMC)
4. EN 55014-2:1997 +A1:2001 +A:2008 Conducted Emissions, Surge Immunity
5. BS EN 203-1:2014, Standard for Safety of Gas Heated Catering Equipment
6. BS EN 203-2-1:2014, Standard for Gas Heated Catering Equipment
7. EN 60335-2-102:2006 Gas Appliance Directive (GAD)

XLT Electric Ovens:

1. EN 60335-2-42:2002 +A1:2008 Safety of Household Appliances and Similar Electrical Appliances
2. EN 60335-1:2010 +A1:2013 Low Voltage Directive (LVD)
3. EN 55014-2:1997 +A1:2001 +A:2008 Conducted Emissions, Surge Immunity
4. EN 6100-6-3:2007 +A1:2011 EMC Immunity for residential, commercial & light industrial
5. EN 55014-1 EMC house hold appliance electric tools & similar appliances
6. EN 6100-3-3 +A1+A2 Voltage fluctuation

Standard & World AVI Hood Certifications [1]:

1. UL 710 Standard for Safety Exhaust Hoods for Commercial Cooking
2. ANSI/NSF 2 Sanitation Food Equipment
3. CAN/ULC S646, Standard for Exhaust Hoods and Related Controls for Commercial and Institutional Kitchens

[1] The noted certifications for XLT ovens and AVI Hood are performed and documented by Intertek Testing Services NA Inc. 165 Main Street, Cortland, NY 13045. Intertek is a nationally and internationally certified testing and accreditation agency.
[2] The certifications for Australia are administered and verified by the Australian Gas Association 2 Park Way, PO Box 122, BRAESIDE, VIC 3195

Oven Initial Start-up Checklist - Remove & Return to XLT Ovens

Step 1: Fill out all information and print legibly

Start-Up Information
Date of Start-Up: _____
Start-Up by: ☐XLT: _____ ☐Other:_____
Phone #: _____

Installer Information
Date of installation: _____
Installed by: ☐XLT: _____ ☐Other:_____
Company:_____
Phone #:_____ Installer:_____

XLT Ovens
PO Box 9090
Wichita, KS 67277
FAX: 316-943-2769

Oven Size: ☐1832 ☐2336 ☐2440 ☐3240 ☐3255 ☐3855

Heat Source: ☐Electric

Contact Information
Store Name: _____Address: _____
City: _____ State: _____ Zip:_____Phone #: _____
E-mail: _____Contact Person: _____

HVAC/Contractor Contact:_____Address: _____
City: _____ State: _____ Zip:_____Phone #: _____ Cell: _____
E-mail: _____

Facility Information ☐Freestanding ☐Strip Mall ☐New construction ☐Existing location ☐Remodel
Oven Location: ☐Against wall ☐In corner ☐Island

Utilities present at installation: ☐Electric Restraint Cable installed on bottom oven: ☐Yes ☐No
Customer or store operator shown how to disassemble and clean ovens and hood: ☐Yes ☐No
Hood manufacturer☐AVI ☐ Other (specify) All Oven/Hood features explained: ☐Yes ☐No
Interlock system for non-AVI hood: ☐Yes ☐No Air balance test performed: ☐Yes ☐No
Smoke test preformed: ☐Yes ☐No

Electrical
Electrical utilities accessible: ☐Yes ☐No Separate electrical circuit per oven: ☐Yes ☐No

I&O Manual presented to store operator: ☐Yes ☐No Ovens ran for 30 min: ☐Yes ☐No
Air-born contaminates: ☐Flour ☐Cornmeal ☐Grease Other _____
On-Site dough prep: ☐Yes ☐No Test cook performed: ☐Yes ☐No
☐Thin Crust ☐Thick Crust ☐Pan ☐Screen
Other Product: _____

Oven Initial Start-up Checklist - Remove & Return to XLT Ovens

NOTE: Peel all PVC during installation (page 7).
Take off front panel and remove finger clips (steps 1-3, page 23).
Check for proper installation and placement of return air/end loss plates (step 6, page 36).

Step 2: Place all control boxes in service position and document settings. Start each oven and complete form below.

Top Oven ☐N/A

Model #: _____
Serial #: _____
Front Belt Speed: _____min _____sec
Back Belt Speed: _____min _____sec ☐N/A

Proper Belt Tension: ☐Yes ☐No
Conveyor Belt Direction: ☐ L to R ☐ R to L
Set Point Temp: Left _____ Right _____
Fingers in proper location: ☐Yes ☐No
Fire Suppression Installed: ☐Yes ☐No

Electrical Supply (per oven):

_____ Volts _____ Amps _____ Hz _____ Phase

Middle Oven ☐N/A

Model #: _____
Serial #: _____
Front Belt Speed: _____min _____sec
Back Belt Speed: _____min _____sec ☐N/A

Proper Belt Tension: ☐Yes ☐No
Conveyor Belt Direction: ☐ L to R ☐ R to L
Set Point Temp: Left _____ Right _____
Fingers in proper location: ☐Yes ☐No
Fire Suppression Installed: ☐Yes ☐No

Electrical Supply (per oven):

_____ Volts _____ Amps _____ Hz _____ Phase

Bottom Oven ☐N/A

Model #: _____
Serial #: _____
Front Belt Speed: _____min _____sec
Back Belt Speed: _____min _____sec ☐N/A

Proper Belt Tension: ☐Yes ☐No
Conveyor Belt Direction: ☐ L to R ☐ R to L
Set Point Temp: Left _____ Right _____
Fingers in proper location: ☐Yes ☐No
Fire Suppression Installed: ☐Yes ☐No

Electrical Supply (per oven):

_____ Volts _____ Amps _____ Hz _____ Phase

NOTE: Do not exceed 65 Hz on VFD settings

Customer Signature: _____ Date: _____

Hood Initial Start-up Checklist - Remove & Return to XLT Ovens

XLT Ovens
PO Box 9090
Wichita, KS 67277
FAX: 316-943-2769

Step 1: Fill out all information and print legibly

Installer Information
Date of installation: _____
Installed by: ☐XLT installer: _____ ☐Other:
Company: _____
Phone #: _____
Installer: _____

Hood Size: ☐1832 ☐2440 ☐3240 ☐3255 ☐3270 ☐3855 ☐3870

Contact Information
Store Name: _____ Address: _____
City: _____ State: _____ Zip: _____ Phone #: _____
E-mail: _____ Contact Person: _____

HVAC/Contractor Contact: _____ Address: _____
City: _____ State: _____ Zip: _____ Phone #: _____ Cell: _____
E-mail: _____

Facility Information ☐Freestanding ☐Strip Mall ☐New construction ☐Existing location ☐Remodel
Oven Location: ☐Against wall ☐In corner ☐Island

Step 2: Verify all information is correct before turning hood on

Model #: _____ Serial #: _____

VFD power supplied:
_____ Volts _____ Amps
_____ Hz _____ Phase
Number of bends in duct run: _____45º _____ 90º

Height from bottom of hood to finished floor:
_____ Feet _____ Inches
Length of duct run (from top of hood to fan):
_____ Feet _____ Inches
Exhaust fan serial #: _____
Rating of exhaust fan: _____ CFM

Hood hung prior to oven installation:	☐Yes ☐No	Oven switch cords connected to Hood:	☐Yes ☐No
Hood hung to local codes:	☐Yes ☐No	Lights operate with switch:	☐Yes ☐No
Switches face front of ovens:	☐Yes ☐No	Light globes installed over bulbs:	☐Yes ☐No
VFD box cover replaced after installation:	☐Yes ☐No	Exhaust fan purchased from XLT:	☐Yes ☐No
All shroud panels properly installed:	☐Yes ☐No	Exhaust fan operates with hood switches:	☐Yes ☐No
Grease filters properly installed:	☐Yes ☐No	Correct fan rotation:	☐Yes ☐No
Grease trays properly installed:	☐Yes ☐No	Fire suppression relay in VFD box utilized:	☐Yes ☐No
Crumb trays easily removable:	☐Yes ☐No	VFD properly programmed:	☐Yes ☐No
Oven power cords connected to Hood:	☐Yes ☐No	Valance Kit:	☐Yes ☐No
Electric Oven	☐ N/A	Duct Valance Kit:	☐Yes ☐No
Air balance test performed:	☐Yes ☐No	Smoke test preformed:	☐Yes ☐No

Notes: _____

Customer Signature: _____ Date: _____



Typical Store Installation

XLT Ovens
PO Box 9090
Wichita, Kansas 67277
US: 888-443-2751 FAX: 316-943-2769 INTL: 316-943-2751 WEB: www.xltovens.com