



*LOCKWASHER AND NUT (OR DOUBLE NUTS) IS REQUIRED TO HOLD GROUND TERMINAL TO GROUND STUD

*ONE PIGGYBACK CONNECTOR USED ON TERMINAL BLOCK: MUST BE PLACED ON MIDDLE TERMINAL FOR CLEARANCE

*MUST HAVE THERMAL GREASE OR THERMAL PAD INSTALLED BETWEEN RELAYS AND MOUNTING SURFACES

*UPPER FLOAT SWITCH NEEDS TURNED UPSIDE DOWN. ADDITIONALLY, IT'S FLOAT NEEDS TURNED UPSIDE DOWN TOO.

*PROBE WIRES RUN DOWN OPPOSITE SIDE FRAME RAIL AS OTHER WATER PAN WIRES