


HFW-2/6 & HFWS-2/4 WIRING DIAGRAM

CAP BULB THERMOSTAT CONFIGURATION



Note: When ordering, ALWAYS specify Part #, Model #, Serial #, Voltage/Phase & type of Gas.


Form #67133 Rev. 3/06

HFW-2/6 & HFWS-2/4 WIRING DIAGRAM

INFINITE CONTROL CONFIGURATION


HEATING ELEMENTS

LIMITING THERMOSTATS



INDICATOR LIGHTS

INFINITE CONTROLS



Note: When ordering, ALWAYS specify Part #, Model #, Serial #, Voltage/Phase & type of Gas.

Form #67132 Rev. 3/06