



DER24P3S PARTS LIST

#	Description	Part code	Qty	#	Description	Part code	Qty
1	Side plate	G20C01-071002	2	44	Convection fan UL240	G20A01-091502	1
2	Cavity right plate	G20A01-070501	1	47	Rear connecting plate	G20C01-022000	2
3	Anti-tip bracket	G20A01-212500	1	48	Cavity top plate	G24C01-070604	1
4	Weight block (2.5KG)	G20A01-210200	1	50	broil heater element 240V 2100W	E24F01-091000	1
5	Foot	G20C01-071500	4	51	Chimney	E24F01-074200Z	1
6	Leg installation plate	G20A01-071100	2	52	Cooling fan	E24F08-200900	1
7	Front plate Beam	G24A01-070200	1	53	Oven lamp-240V	G20C01-180100	1
8	Drawer heat insulation board	G24C01-072100	1	54	Back plate	G24C01-070307	1
9	Cavity left plate	G20A01-070401	1	56	Baffle plate	G24C01-072001	1
10	Front plate	G24C01-070102	1	57	terminal block cover	E20F01-072000	1
11	Drawer slid rail	G24F08-120700	2	59	Roasted motor (UL 240V)	G20A01-200103	1
12	Drawer plate	G24F08-120500-02	1	60	Oven (microcrystalline) radiating plate latch	E24F08-025100	8
13	Drawer inside plate	G24C02-120200-04	1	61	Broil grill	G20C01-215100	1
14	Drawer outside plate	G24F08-120100	1	62	Broil tray	G20C01-215000	1
17	Door body strengthening part	G20C01-101000	2	63	Rack	G24C01-071900	2
18	Door hinge	G24C01-110000	2	64	oven heater element 240V 2100W	E24F01-091200	1
19	Door glass wool	G24C01-103500	1	65	terminal block support	E24F01-034500	1
20	Door glass bracket	G20A10-100900	2	66	Cavity bottom plate	E20F01-070700	1
21	Door inside window	G24F08-101100	1	67	baffle	G20C01-111100	2
22	Outer door glass	GC0097-100400	1	68	harness	E24F08-180300	1
23	Handle	G24B03-101900	2	71	Radition plate 1800W	E24F08-022400	2
24	Door inner seal ring	G24C01-103000	1	72	Radition plate 1200W	E24F08-022300	2
25	Window fixing piece for door	G20C01-102600	4	*	Backsplash assembly	G24F08-011500Z assm	1
26	Internal fixation plate	G20C01-102500	4	*	LED PCB (short)	G20F08-190300-02	1
27	Door inside glass	G24F08-100500	2	*	LED PCB (long)	G20F08-190300-03	1
28	Oven door frame	G24C01-100600	1	*	Complete door assembly	GC0097-100400Z	1
29	Knob	G20A07-030100	6	*	Door inner seal bar	G24C01-103100	1
30	Knob ring	G20A07-030200-00	6	*	Door handle strut	G20C01-100300	2
32	Control panel	E24F08-030300	1	*	Drawer assembly	G24F08-120100Z	1
33	Door stainless steel trim	G24F08-102000	1	*	Cavity ring	G24F08-071200	1
36	Digital timer LED 240V	E24F08-190300	1	*	Re-set switch 140°C 240V	E24F01-076200	1
37	Spring for radiation plate	E24F08-026100	8	*	main terminal block	E20F01-106400	1
38	Left support for radition plate	E24F08-024100	1	*	snap action temperature controller 50°C 240V	C36R05-076200	1
38	Right support for radition plate	E24F08-024200	1	*	indicate light -green 240V	E24F08-031000	2
41	Digital thermo-controller	E24F08-030900	1	*	indicate light- red 240V	E24F08-031001	1
42	cooktop coil switch	E20F01-031600	4	*	cooktop plate component	E20F08-020100-Z	1
				*	Roasted axis	G24A01-200500Z	1