



1 2 3/4 5 6 7 8/9 10/11 12/13 14 15 16/17/18/19 20 21 22 23/24/25 26/27/28 29/30 31 32 33 34 35 36 37 38 39 40 41 42 43/44/45

90 89 88 87 86 85 84 83 82 80 79 77/78 76 75

74/73 72 71/70/69/68 67 66 65 64 63 62 61 60/59/58 57 56 55 54 53 52 51 50 49 48 47 46

## GR2414CW/ GR2415CB/GR2416CSS Spare parts list

Item No.	Description	Part code	Qty per unit
1	Cavity insulation board	C24B01-074500	1
2	Oven bellows	G20C01-215300	1
3	Oven/Broil injector base	G20A01-021100	2
4	Oven injector NG	G20A01-021224	1
4	Broil injector NG	G20A01-021213	1
4	Oven injector LPG	G20A01-021204	1
4	Broil injector LPG	G20A01-021202	1
5	Oven burner aluminum pipe	G20C01-023100	1
6	Grill burner aluminum pipe	G20C01-023300	1
7	Bottom cup mounting plate	G24C01-024200	2
*	Spark plug-for top burner 1050mm (L1050)	G20A01-170406	2
*	Spark plug-for top burner 900mm (L900)	G20A01-170405	1
*	Spark plug-for top burner 680mm (L680)	G20A01-170404	1
8	Mid burner cover	<a href="#">G20A01-040102</a>	2
	Mid burner	G20A01-040101	
8	Mid burner cup	G20A01-040100	2
9	Mid NG injector	G20A01-021206	2
9	Mid LPG injector	G20A01-021201	2
10	Large burner cover	<a href="#">G20A01-040202</a>	1
	Large burner	G20A01-040201	
10	Large burner cup	G20A01-040200	1
11	Large NG injector	G20A01-021224	1
11	Large LPG injector	G20A01-021203	1
12	Small burner cover	<a href="#">G20A01-040002</a>	1
	Small burner	G20A01-040001	
12	Small burner cup	G20A01-040000	1
13	Small NG injector	G20A01-021202	1
13	Small LPG injector	G20A01-021200	1
14	Backsplash assembly	G24C01-011500-01Z Assm	1
		<a href="#">G24C01-011500-02Z Assm</a>	1
		<a href="#">G24C01-011500Z Assm</a>	1
15	Pan support	<a href="#">G24B02-021400</a>	2
*	Cook top	G24C01-020103-01Z	1
		<a href="#">G24C01-020103-02Z</a>	1
		<a href="#">G24C01-020103</a>	1
16	Aluminum pipe-L/B	G24C01-020200	1
17	Aluminum pipe-L/F	G24C01-020300	1
18	Aluminum pipe-R/B	G20C01-020400	1
19	Aluminum pipe-R/F	G20C01-020500	1
20	Lamp switch	C20C01-170800	1
21	24" main gas pipe 24	G24C01-030700	1
22	Oven/Broil valve	G20C01-030600	1
23	Gas valve-Mid 0.76	G20C01-030406	2
24	gas valve-large 0.80	<a href="#">G20C01-030407</a>	1
25	Gas valve-small 0.53	G20C01-030402	1
26	Left connecting plate	G20C01-022100	1
27	Right connecting plate	G20C01-022200	1
28	Control panel	G24C01-030304-01Z	1
		<a href="#">G24C01-030304-02Z</a>	1
		<a href="#">G24C01-030313Z</a>	1
*	Control panel glass wool	G24C01-036000	1
29	Digital timer	G24C01-190300	1
30	Knob	<a href="#">G20A14-030100</a>	7
		<a href="#">G20A14-030101</a>	7
		<a href="#">G20A14-030102</a>	6

Item No.	Description	Part code	Qty per unit
31	Side plate	G20C01-071002-01	2
	Side plate	G20C01-071002-02	2
	Side plate	G20C01-071002	2
*	Complete door assembly	GC0026-100400Z	1
*	Complete door assembly	GC0027-100400Z	1
*	Complete door assembly	GC0027-100400Z	1
32	Internal fixation plate	G24C01-102600	4
33	Door inside glass	G24C01-100500	2
34	Door inner seal ring	G24C01-103000	1
35	Oven door frame	G24C01-100600	1
36	Door handle strut	G20C01-100300	2
37	Window fixing piece for door	G20C01-102600	4
38	Door body strengthening part	G20C01-101000	2
39	Door hinge	G24C01-110000	2
40	Door glass wool	G24C01-103500	1
41	Door inside window	G24C01-101100	1
42	Door inner seal bar	G24C01-103100	1
43	Door outer glass	GC0026-100400	1
		G00027-100400	1
		G00027-100400	1
44	Drawer handle	G24B05-101900-02	1
	Drawer handle	G24B05-101900-02	1
	Drawer handle	G24B05-101900-02	1
45	Door glass bracket	G20A10-100900	2
*	Drawer assembly	G24C02-120202-01Z	1
		G24C02-120202-02Z	1
		G24C02-120202Z	1
46	Drawer handle	E24F01-120600	1
47	Drawer outside plate	G24C01-120102-01	1
	Drawer outside plate	G24C01-120102-02	1
	Drawer outside plate	G24C01-120102	1
48	Drawer handle fixed part	E24F01-031100	1
49	Drawer inside plate	G24C02-120200-04	1
50	Drawer plate	G24C03-120500-02	1
51	Drawer rail assembly	G20A01-120700	2
52	Front plate	G24C01-070100	1
53	Front plate Beam	G24A01-070200	1
55	baffle	G20C01-111100	2
56	Foot	G20C01-071500	4
57	Cavity left plate	G20A01-070400	1
*	Oven burner assembly	G20B01-080100ZAssm	1
58	Oven burner fire board	G20A01-080900	1
59	Oven burner pipe	G20B01-080100	1
60	Spark plug-for oven burner 230mm (L230)	G20C01-170502	1
61	Anti-tip bracket	G20A01-212500	1
62	Leg installation plate	G20A01-071100	2
63	Drawer heat insulation board	G24C01-072100	1
64	Bottom tray (with hole)	G24A01-070700	1
65	Rack	G24C01-071900	2
66	Broil tray	G20C01-215000	1
67	Broil grill	G20C01-215100	1
*	Broil burner assembly	G20C01-090100ZAssm	1

Item No.	Description	Part code	Qty per unit
68	Broil burner fire board	G20C01-090300	1
69	Broil burner infrared radiation net	G20C01-090500	1
70	Broil burner pipe	G20C01-090100	1
71	Spark plug-for grill burner 540mm (L540)	G20C01-170500	1
72	Cavity top plate	G24C01-070601	1
73/74	Chimney	G20C01-074100	1
75	Weight block (2.5KG)	G20A01-210200	1
76	Wiring harness	G24C01-180300	1
77	Power cord	G20A07-160105	1
78	Oven thermocouple	G20C01-072400	1
79	Ignition	G20C01-170106	1
80	Cavity right plate	G20A01-070500	1
81	Back plate	G24C01-070301	1
82	Oven lamp	G20C01-180101	1
83	Cavity back glass wool	G24C01-072900	1
84	Fixed plate	G20C01-034500	3
85	Baffle plate	G24C01-072000	1
86	Rear connecting plate	G20C01-022000	2
87	Diversion plate	G20C01-075000	1
88	Regulator	<a href="#">G20C01-034001</a>	1
89	Vent screw	G20C01-034200	1
90	Glass wool	G24A01-070800	1
*	door seal	<a href="#">G24C01-071200</a>	1