



MO1450TW

Art.	Name	Count	Art.	Name	Count	Art.	Name	Count
P01	door (with inlaid)	1	P27	base plate	1	C09	microswitch	1
P02	door window	1	P28	lower hinge	1	C10	microswitch	1
P03	fuse socket	1	P29	keyboard (with inlai	1	C11	microswitch	1
P04	capacitor holder	1	P31	lever	1	C12	transformer	1
P05	fan shroud	1	P32	button spring	1	C13	wiring harness	1
P06	fan blade	1	P33	button	1	C14	power cord	1
P07	door frame	1	P87	board seal	1	C15	turntable motor	1
P08	choke cover	1	P114	flake(in door frame)	1	C17	p.c board	1
P10	shaft	1	P117	door hook	1	C18	thin film switch	1
P11	roller ring	1	P118	door hook spring	1	C19	thermostat	1
P12	glass tray	1	P124	clamp holder	1	B01	upper foam cushion	1
P13	splash shield	1	P288	magnetron bracket	1	B02	turntable cushion	1
P14	upper hinge	1	C01	H.V.fuse	1	B03	plastic bag	1
P16	cavity	1	C02	h.v .diode	1	B04	manual	1
P17	label	1	C03	h.v. capacitor	1	B05	protection film	1
P18	outer enclosure	1	C04	noisefilter	1	B06	plastic bag	1
P21	lamp socket	1	C05	fan motor	1	B07	lower cushion	1
P22	air duct bracket	1	C06	lamp	1	B08	carton	1
P23	microswitch mounting	1	C07	thermostat 1	1	B09	paper card	1
P26	foot	2	C08	magnetron	1			