

WCR506SS			
S/N	Description	Parts code	Pcs
1	Door assembly	YC150A. 03. 25. 00	1
2	Curved Handle	YC150A. 03. 10. 12	1
3	Lower door hinge	YC150A. 03. 26. 00	1
4	Lower door hinge screw	YC150A. 03. 08. 00	1
5	Bottom Grille	YC150C. 03. 20	1
6	Upper door hinge	YC150A. 03. 19. 00	1
7	Large shelf	YC150A. 03. 21. 03	4
7	Top Burgendy shelf	YC150A. 03. 21. 04	1
8	Small shelf	YC150A. 03. 07	1
9	Shelf roller	YC150A. 03. 22	5
10	Air-board	YC150A. 03. 01. 20	1
11	Big Fan	YC150A. 03. 01. 02	1
12	Evaporator	YC150A. 02. 03	1
13	Control panel film	YC150A. 03. 02. 02	1
14	Control panel box	YC150A. 03. 02. 01. 01	1
15	Display board	YC150A. 03. 22. 04	1
16	Light board	YC150A. 03. 02. 01. 05	1
17	Condenser air-board assembly	YC150C. 02. 04. 00	1
18	Condenser	YC150A. 02. 15	1
19	AC FAN	YC150A. 02. 04. 02	1
20	Fan cover		1
22	Sunction Pipe Assembly	YC150A. 01. 07. 00	1
23	Power board box	YC150A. 02. 01. 10	1
24	Power board	YC510. 03. 01. 01	1
25	Compressor - EYA55U6	YC-TY. LJ. 25	1
26	Compressor bracket	YC150A. 02. 01. 01	1
27	Power cord		1
28	Handle hole hing caps		2
29	Charcoal filter	YC-TY. LJ. 41. 01	1

