





Pic#	Part#	Description
1	31428	FOOT
2	62647	FLUE GRILLE
3	61571	1"XM 1"X15 MM F EXTENSION
4	60556	DISCHARGE PROTECTION
5	60173	WATER DRAIN GRILLE
6	60836	FALSE BOTTOM
7	62242	SURFACE JOINT BLOCK
8	60175	GRILLE
9	62237	HINGE ASSEMBLY
10	62045	HINGE ASSEMBLY
11	60551	MAGNET SUPPORT
12	62229	DOOR ASSEMBLY
13	60609	KNOB RING NUT
14	60610	COOKING INDICATOR
15	60829	PIEZOELECTRIC IGNITER
16	62322	KNOB
17	62317	KNOB
18	60112	INSTRUMENT PANEL ASSEMBLY
19	60995	BASKET
20	61193	BALL VALVE
22	62220	STAINLESS STEEL DISCHARGE
23	61197	BLACK EPDM PIPE
24	62640	GAS PIPE
25	63663	GAS TAP
26	60135	GAS PIPE
27	63996	RAMP
28	62709	WATER PIPE
29	30151	GASKET
30	60307	WATER PIPE
31	60752	FITTING
32	60720	FITTING
33	60167	WATER PIPE
34	60902	WATER TAP
35	61552	GLASS PEEPHOLE ASSEMBLY
36	60259	BURNER
37	61466	ADJUSTMENT
38	61892	PILOT BURNER
39	61074	THERMOCOUPLE
40	61068	IGNITION
41	63265	ELECTRIC CABLE