


Repair Parts

116.878.AB.4

Touch-free, programmable faucet with above-deck electronics

**CHICAGO
FAUCETS®**
Geberit Group

Base Parts:



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive

Des Plaines, IL 60018

Phone: 847-803-5000

chicagofaucets.com


Repair Parts

116.878.AB.4

Touch-free, programmable faucet with above-deck electronics

**CHICAGO
FAUCETS®**
Geberit Group

HyTronic Edge Spout
242.797.AB.1




CHECK-CARTRIDGE
550-009KJKABNF



O-RING, #010
243.391.AB.1




0.35 GPM (1.3 L/min) Vandal Proof Econo-Flo Non-Aerating
Outlet
E39VPJKABCP




VANDAL PROOF KEY
3-024JKRCF

Electronic Module
242.574.00.1



CR-P2 6V Lithium Battery
242.560.00.1



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive
Des Plaines, IL 60018
Phone: 847-803-5000
chicagofaucets.com