

NOTES:

WHEN STEAM HEAT IS USED-
 HC1, HC3, HC5, BC1 ARE STEAM VALVES,
 HC2, HC4, BC2, BC3 ARE NOT USED

WHEN ELECTRIC HEAT IS USED-
 HC1 THRU 5, BC1 THRU 3 ARE
 ELECTRIC CONTACTORS




DIAGRAM STATE
 POWER OFF
 DOORS CLOSED
 TANKS EMPTY

SEE 702224 FOR LEGEND