

**OPERATING and MAINTENANCE INSTRUCTIONS**  
**H161FUA11CM**  
**Correctional Insulated Heated Cabinet**

**ELECTRICAL SPECIFICATIONS: AC Service**

Model No.	Volts	Watts	Amps	Hertz	Phase	NEMA	Location
H161FUA11CM	120	1600	13.3	60	1	5-15P	US
H161FUA11CMCAN	120	1600	13.3	60	1	5-20P	US/CAN
H161FUA11CM208	208	1600	7.7	60	1	6-15-P	US/CAN
H161FUA11CM240	240	1600	6.7	60	1	6-15P	US/CAN

**HOW TO START UNIT:**

1. Plug the power cord into proper wall outlet.
2. Preheat cabinet for 30 minutes.  
**NOTE:** Temperature is pre-set for 180°F/82°C.
3. Put food into cabinet.

**HOW TO SHUT OFF UNIT:**

Unplug power cord from wall outlet

**HOW TO ADJUST TEMPERATURE:**

1. Unplug power cord from wall outlet.
2. Remove top cover.
3. Turn thermostat knob to higher numbers (higher temperatures) or lower numbers (lower temperatures).

**NOTE:** No. 5 setting is approximately 150°F/66°C.  
 Proper food holding temperature is 140°F/60°C or higher.



NEED KNOB THERMOSTAT  
IMAGE

## OPERATING and MAINTENANCE INSTRUCTIONS H161FUA11CM Correctional Insulated Heated Cabinet

### **WARNING**

#### BEFORE CLEANING CABINET:

1. Unplug power cord from wall outlet
2. Allow cabinet to cool
3. Do **NOT** use abrasives or harsh chemicals. Be sure your cleaner is suitable for stainless steel.

#### Cleaning Notes:

1. Wipe up spills as soon as possible.
2. Clean cabinet regularly to avoid heavy dirt build-up.
3. Make a test spot with cleaner.
4. Follow manufacturer's directions on cleaner.
5. Do not mix cleaners.
6. Avoid drips and splashes.

#### HOW TO CLEAN THE UNIT:

	Soil	Cleaner	Method
<b>CABINET</b>  Stainless Steel Inside and Outside	DIRT	Mild detergent* and hot water, or mild abrasive cleaner.	1. Use soft, damp cloth 2. Rinse well with hot water. 3. Wipe dry.
		Steam (no strong alkaline additive).	1. Rinse after steam cleaning. 2. Wipe dry.
	FINGERPRINTS GREASE and OIL	Chemical oven cleaner, for stainless steel. Mild abrasive cleaner; oily waxy cleaner.	1. Apply with clean, soft cloth. 2. Follow oven cleaner manufacturer's directions.
	WATER SPOTS	Mild abrasive cleaner.	1. Apply with damp cloth 2. Rinse and dry.
<i>*Mild detergents include soaps and non-abrasive cleaners.</i>			

#### REPLACEMENT PARTS:

DESCRIPTION	120V	120-CAN	208V	240V
Heater	<a href="#">0811-244</a>	<a href="#">0811-244</a>	<a href="#">0811-245</a>	<a href="#">0811-246</a>
Blower	<a href="#">0769-005-K</a>	<a href="#">0769-005-K</a>	<a href="#">0769-006-K1</a>	<a href="#">0769-006-K1</a>
Blower	<a href="#">0769-093</a>	0769-096	0769-069	0769-069
Fan Vent	<a href="#">0769-165</a>	<a href="#">0769-165</a>	<a href="#">0769-174</a>	<a href="#">0769-174</a>
Plug	<a href="#">0852-106</a>	<a href="#">0713-017</a>	0713-056	0713-056
Cord	<a href="#">0812-465</a>	<a href="#">0812-465</a>	<a href="#">0812-465</a>	<a href="#">0812-465</a>
Thermostat	<a href="#">0848-062-K</a>	<a href="#">0848-062-K</a>	<a href="#">0848-062-K</a>	<a href="#">0848-062-K</a>
Thermometer	<a href="#">5238-030-K</a>	<a href="#">5238-030-K</a>	<a href="#">5238-030-K</a>	<a href="#">5238-030-K</a>
Caster	<a href="#">0569-290</a>	<a href="#">0569-290</a>	<a href="#">0569-290</a>	<a href="#">0569-290</a>
NEMA	5-15	5-20	6-15	6-15

**OPERATING and MAINTENANCE INSTRUCTIONS**  
**H161FUA11CM**  
**Correctional Insulated Heated Cabinet**  
**WIRING DIAGRAM**

