



Pos.	Code	Description
01	7018112100	HOUSING
02	6918108700	REAR PANEL
03	7018109500	BOTTOM
06	6918108200	SEPARATOR
07	7018108700	SIDE LEFT
08	6918107900	BASE
09	7018109700	FRAME
10	7118101600	SUPPORT
11	6118101100	ROD
12	5318140300	GLASS
13	6118103000	SPRING
14	7018108500	BRACKET
15	5318114600	HANDLE
16	7318134000	DOOR
17	7018110100	DRIP PAN
18	6918109500	PIZZA TRAY
19	6118102900	GRID
20	6118101800	SUPPORT
21	7018109000	TRAY
22	5918119100	CONTROL PANEL
23	5918118700	FRONT PIECE
24	5318116700	GLASS
25	5918118900	KEYBOARD
26	5918119000	KEYBOARD
27	5318116800	SUPPORT
28	5218102600	BOARD
29	5518108700	SENSOR
30	7018110200	LASAGNE TRAY
31	5518109700	TURNSPIT
32	ES000	*NOT AVAILABLE
34	5118104600	MOTOR
35	5118104000	GEARMOTOR
36	607702	FAN
37	ES000	*NOT AVAILABLE
38	ES000	*NOT AVAILABLE
39	ES000	*NOT AVAILABLE
40	5118103900	LAMP

DE'LONGHI
CA US AD1079B**AD1079B BLACK**

42	5318114300	FOOT LEFT
44	5318114200	FOOT RIGHT
46	532710	RUBBER PAD
47	5318114400	SPACER
48	ES000	*NOT AVAILABLE
49	6118101300	HOOK
50	7018108400	LEVER
51	5318127400	BLOCK
52	7018109100	ARCHIMEDES SCREW
53	5318119800	RUBBER PAD