



DE'LONGHI

CA US AR1070 CHROME-SILVER

Pos.	Code	Description
01	6018121000	HOUSING
02	6918108700	REAR PANEL
03	7018108800	BOTTOM
06	6918109100	SEPARATOR
07	7018108700	SIDE LEFT
08	6918107900	BASE
09	7018112900	FRAME
10	7118103400	SUPPORT
11	6118101100	ROD
12	5318123200	GLASS
13	6118103000	SPRING
14	7018112800	SUPPORT
15	6118102000	HANDLE
16	7318139300	DOOR
17	7018110100	DRIP PAN
18	7018110200	LASAGNE TRAY
19	6118102900	GRID
20	6118101800	SUPPORT
21	7018109000	TRAY
22	5918123600	CONTROL PANEL
23	5918123700	RING NUT
24	5918123800	RING NUT DKS/ITALORA
25	5918123900	RING NUT
26	611900	SPRING
27	5218106400	THERMOSTAT
28	VN057	SEE NOTE
28	5218101500	TIMER ITALORA
29	5218101900	Change Over Switch
30	5118104400	WARNING LIGHT
31	5518109700	TURNSPIT
32	5318121200	INSULATOR
34	5118104600	MOTOR
35	5118104000	GEARMOTOR
36	607702	FAN
37	ES000	*NOT AVAILABLE
38	ES000	*NOT AVAILABLE
39	ES000	*NOT AVAILABLE

DE'LONGHI**AR1070 CHR-SIL****CA US AR1070 CHROME-SILVER**

40	5118103900	LAMP
41	5318113600	KNOB
42	5318114300	FOOT LEFT
43	5318122800	STOPPER
44	5318114200	FOOT RIGHT
46	532710	RUBBER PAD
47	5318114400	SPACER
48	ES000	*NOT AVAILABLE
49	6118101300	HOOK
50	7018108400	LEVER
51	5318127400	BLOCK
52	7018109100	ARCHIMEDES SCREW
53	5318119800	RUBBER PAD