



DE'LONGHI

CA US AS1070WHITE

Pos.	Code	Description
01	701810111	HOUSING
02	6918108700	REAR PANEL
03	7018108800	BOTTOM
06	6918109100	SEPARATOR
07	7018108700	SIDE LEFT
08	6918107900	BASE
09	7018109300	FRAME
10	7118101600	SUPPORT
11	6118101100	ROD
12	5318140300	GLASS
13	6118103000	SPRING
14	7018108500	BRACKET
15	5318114600	HANDLE
16	7318133100	DOOR
17	7018110100	DRIP PAN
18	7018110200	LASAGNE TRAY
19	6118102900	GRID
20	6118101800	SUPPORT
21	7018109000	TRAY
22	5918118600	CONTROL PANEL
23	5918118300	KNOB
24	5918118400	TIMER KNOB
25	5918118500	KNOB
26	611900	SPRING
27	5218106400	THERMOSTAT
28	VN057	SEE NOTE
28	ES000	*NOT AVAILABLE
28	5218101500	TIMER ITALORA
29	5218101900	Change Over Switch
30	5118104400	WARNING LIGHT
31	5518109700	TURNSPIT
32	ES000	*NOT AVAILABLE
34	5118104600	MOTOR
35	5118104000	GEARMOTOR
36	607702	FAN
37	ES000	*NOT AVAILABLE
38	ES000	*NOT AVAILABLE

DE'LONGHI

CA US AS1070WHITE

39	ES000	*NOT AVAILABLE
40	5118103900	LAMP
42	5318114300	FOOT LEFT
44	5318114200	FOOT RIGHT
46	532710	RUBBER PAD
47	5318114400	SPACER
48	ES000	*NOT AVAILABLE
49	6118101300	HOOK
50	7018108400	LEVER
51	5318127400	BLOCK
52	7018109100	ARCHIMEDES SCREW
53	5318119800	RUBBER PAD