



DE'LONGHI

CA US MX D28313-UX

Pos.	Code	Description
01	5312510231	GRID
02	5312510071	Activated Carbon Filter
03	5312510061	GLASS
04	7312577129	COVER ASSEMBLY
05	5325112900	HINGE LEFT
06	5325113000	HINGE RIGHT
07	7312577149	HANDLE
08	7312576269	PAN ASSY. H.E.
09	5312510091	BLOCK
10	7312576469	BASKET
12	5325103900	BUSH
13	5225100700	THERMOSTAT 145
14	5325102600	EXTENSION
15	536330	BRUSH
16	5312510731	THERMOSTAT KNOB
17	6112510021	PEG
18	6112510001	SPRING
19	5312512141	SPACER
20	5312512151	SPACER LEFT
22	512986	MOTOR
23	5312512161	SPACER RIGHT
24	5912510321	CASING
25	6112510011	SPRING
26	5312510151	HOOK
27	5312510261	PUSH BUTTON
29	536159	TUBE
30	5325120600	STOPPER
33	5912510061	DOOR
34	7312576279	WIRING TCO/LAMP
35	5312510141	RED LENS
36	7312577519	CABLE
37	5312512071	BASE
38	5325106400	BUSH
39	5325146800	BUSH
40	5325148100	RUBBER PAD
41	5312510881	COVER
42	7312577179	TIMER

**DE'LONGHI****CA US MX D28313-UX**

43	5325147600	COVER
44	5325147500	SUPPORT
45	5525106300	CONNECTOR