



DE'LONGHI
US D406DZ

Pos.	Code	Description
01	IC1042	COVER
02	IC1002	BASKET
03	IC1032	WARNING LIGHT
04A	IC1034	Rear Protection
04	IC1033	Front Protection
05	IC1045	POWER SUPPLY CORD
06	IC1035	MICROSWITCH
07	IC1008	THERMOSTAT
08	IC1036	THERMOSTAT
09	IC1010	SWITCH
10	IC1012	TRAY
11	IC1014	CONTAINER
12	IC1015	HANDLE
13	IC1016	FOOT
14	IC1017	HANDLE
15	IC1038	KNOB
16	IC1039	HEATING Element
17	IC1021	SUPPORT
19	IC1047	CONNECTOR
20	IC1048	SUPPORT
21	ES000	*NOT AVAILABLE