





DE'LONGHI
CA US DO1280S

Pos.	Code	Description
01	5318140700	FOOT LEFT
02	532233	RUBBER PAD
04	6918118500	PANEL UPPER
05	7018119000	PANEL LEFT
06	5518122400	UP. HEAT ELEMENT KIT
07	5518122500	LW. HEAT ELEMENT KIT
10	5518124200	SUPPORT LEFT
11	7018119500	PROFILE LEFT
13	6118104500	PIN
14	7018119300	LEVER
15	6118105000	SPRING
16	5318119800	RUBBER PAD
17	5918137600	GLASS
18	6918118600	BASE
19	5018104000	POWER SUPPLY CORD
20	6118109600	HANDLE
21	6118105300	PIN
22	5518124100	SUPPORT RIGHT
23	7018121500	PROFILE RIGHT
24	5311810101	KNOB
25	611900	SPRING
26	7118106400	FRAME
27	5911810001	FRONT PIECE
28	5318139000	SUPPORT
30	5911810011	PUSH BUTTON
31	5311810091	PUSH BUTTON
33	6918118400	TRAY
34	5318138300	SUPPORT
35	5218106100	BOARD
36	ES000	*NOT AVAILABLE
37	5318138400	RUNNER
38	5318140400	PROTECTION
41	5318132700	LAMP HOLDER
42	5511810118	FAN
45	7018121300	PANEL RIGHT
47	5218105900	SENSOR NTC
48	5011851438	WIRING TCO

DE'LONGHI
CA US DO1280S

49	6218100800	SQUADRETTA
50	ES000	*NOT AVAILABLE
51	6918119100	CONVOGLIATORE
52	5318135500	SUPPORTO
53	5118110600	MOTOR
54	5318135000	SPACER
55	5318140600	FOOT RIGHT
56	6011810151	HOUSING
57	6118105400	GRID
58	6111810271	GRILL
59	6118104600	GRID
60	7018120500	LECCARDA DIETETICA NERA
61	7011810541	PLATE
62	6918117500	PASTRY TRAY
63	6918119200	PIZZA STONE