



DE'LONGHI
CA US EO420

Pos.	Code	Description
01	5311810351	FOOT
02	6911810148	HOUSING
03	5111810221	Heating Element Up PZ.1
04	5111810011	Heating Element Low PZ.1
05	5211810271	TIMER
06	5311810171	SUPPORT
07	7311810238	DOOR
08	5311810371	KNOB
09	7011810011	DRIP PAN
10	6111810001	GRID
13	7011810001	PLATE
14	5911810031	PANEL
15	536685	LENS
16	5011852648	WIRING LAMP
17	5311810181	SUPPORT
18	5125104700	MICROSWITCH
19	5011852658	WIRING TCO
23	5311810121	SPACER
24	5218105500	THERMOSTAT 250
25	5311810141	GEAR
26	5311810131	INGRANAGGIO TERMOSTATO
27	5311810151	KNOB GEAR
28	5018104000	POWER SUPPLY CORD