



DE'LONGHI
CA US EOM1230

Pos.	Code	Description
	690083	
	702399	
	709303	ENAMEL PLATE FOR ELECTRIC OVENS
	6118105200	SHAPED GRILL
	6918111800	
	551930	COOKING STONE FOR ELECTRIC OVENS
	7018120500	LECCARDA DIETETICA NERA
001	7018116400	HOUSING
002	690523	REAR PANEL
003	531646	SPACER
004	5518118700	FOOT
005	513148	LAMP
006	690514	SEPARATOR
007	7318148000	CAVITY
008	690085	BOTTOM
009	7018116000	FRAME
010	537384	GLASS
011	5518118800	SUPPORT
012	ES000	*NOT AVAILABLE
013	611228	SPRING
014	7018116100	SUPPORT
015	7318148200	HANDLE
016	7318148100	DOOR
017	7018120500	LECCARDA DIETETICA NERA
018	709303	ENAMEL PLATE FOR ELECTRIC OVENS
019	611229	WIRE RACK
020	702399	
021	5318116900	SUPPORT
022	5918130900	CONTROL PANEL
023	5918131200	RING NUT
024	5918131300	RING NUT DKS/ITALORA
025	5918131000	RING NUT
026	5318129300	KNOB
027	5518101000	THERMOSTAT KIT
028	5218103900	TIMER ITALORA
029	ES000	*NOT AVAILABLE
030	513080	LAMP

DE'LONGHI

CA US EOM1230

031	6118100000	ROD
032	531693	PROTECTION
033	531147	WIRE CLAMP
034	5318102700	GEAR
035	5318125500	EXTENSION
036	611900	SPRING
037	535681	LENS
038	ES000	*NOT AVAILABLE
039	ES000	*NOT AVAILABLE
040	611792	SPRING
041	531847	RUBBER PAD
042	537004	BUSH
045	7018100600	LEVER
046	6918111800	