



**DE'LONGHI**  
**US MW660**

Pos.	Code	Description
01	6919102900	REAR PANEL
02	5319128400	INSULATOR
03	ES000	*NOT AVAILABLE
04	536878	INSULATOR
05	5319128500	INSULATOR
06	5319128700	INSULATOR
07	7019100100	CAVITY
08	5919130700	CONTROL PANEL
09	611900	SPRING
10	5919130400	KNOB
11	5919130500	KNOB
12	5919130600	KNOB
13	513080	LAMP
14	536380	CLOSURE
15	ES000	*NOT AVAILABLE
16	709162	HINGE LOWER
17	5319163200	FRAME
18	7319123300	HOOK
19	612003	SPRING
20	7419155100	DOOR
21	ES000	*NOT AVAILABLE
22	5919131700	FRONT PANEL
23	5319117100	HANDLE
24	6919103300	BASE
25	532710	RUBBER PAD
26	513148	LAMP
27	536289	SUPPORT WITHOUT WHEELS
28	535762	CASTOR
29	VI000	SEE TECNICAL INFORMATION
30	535127	PULLER
31	6119100100	GRID
32	6119100600	GRID
33	536347	RUNNER
34	536684	LENS
35	536685	LENS
37	521514	THERMOSTAT 145°
38	5119108100	MAGNETRON

**DE'LONGHI**  
**US MW660**

39	5119103500	FUSE
40	5119103400	MOTOR
41	5319164300	ARCHIMEDES SCREW
42	612017	SPRING
43	5119103200	Heating Element Up
44	5119103300	Heating Element Low
45	5219102900	THERMOSTAT 170°
46	5118100400	MOTOR
47	5119103100	HEATING Element
48	512112	MOTOR
49	521660	THERMOSTAT
50	534180	CAM
51	534179	LEVER
52	ES000	*NOT AVAILABLE
53	5219102600	Change Over Switch
54	5219102700	TIMER
55	536578	FAN PLASET
56	536683	GASKET
57	611874	SPRING
58	612007	SPRING
59	612008	ROD
60	536482	SUPPORT
61	5219102800	CURRENT LIMITER
62	5119100000	DIODE
63	5119107500	DIODE
64	611916	SPRING
65	512119	TRANSFORMER
66	ES000	*NOT AVAILABLE
67	536365	SUPPORT
68	6119102300	SPRING
69	512113	MICROSWITCH
70	512114	MICROSWITCH
71	5319143100	CAM
72	536367	CAM
73	7018120500	LECCARDA DIETETICA NERA
74	709303	ENAMEL PLATE FOR ELECTRIC OVENS
75	551922	Pirex Baking dish 26cm