



DE'LONGHI

XR630B BLACK-SILVER

CA US XR630B BLA/SIL

Pos.	Code	Description
	6918111800	
	690083	
	709303	ENAMEL PLATE FOR ELECTRIC OVENS
	702399	
	551930	COOKING STONE FOR ELECTRIC OVENS
001	7018110700	HOUSING
002	690523	REAR PANEL
003	531646	SPACER
004	5518106200	FOOT
006	690514	SEPARATOR
007	7318135100	CAVITY
008	6918107400	BOTTOM
009	7018102000	FRAME
011	7118101300	SUPPORT
012	5318101000	GLASS
013	6118101600	SPRING
014	7018107000	SUPPORT
015	6118100900	HANDLE
016	7318137800	DOOR
017	7018120500	LECCARDA DIETETICA NERA
018	709303	ENAMEL PLATE FOR ELECTRIC OVENS
019	611229	WIRE RACK
020	702399	
021	5318116900	SUPPORT
022	5918118100	CONTROL PANEL
023	5918114600	RING NUT
024	5918114800	RING NUT DKS/ITALORA
024	5918114900	RING NUT FAUCIGNY
025	5918114700	RING NUT
026	5318113600	KNOB
027	5518101000	THERMOSTAT KIT
028	521292	TIMER FAUCIGNY
028	521690	TIMER DKS
028	5218100000	TIMER ITALORA
029	ES000	*NOT AVAILABLE
030	513080	LAMP
031	6118100000	ROD

DE'LONGHI

XR630B BLACK-SILVER

CA US XR630B BLA/SIL

032	531693	PROTECTION
033	531147	WIRE CLAMP
034	5318102700	GEAR
035	5318125500	EXTENSION
036	611900	SPRING
037	535681	LENS
038	ES000	*NOT AVAILABLE
039	ES000	*NOT AVAILABLE
041	531847	RUBBER PAD
042	537004	BUSH
043	5318115100	STOPPER SX
044	ES000	*NOT AVAILABLE
045	7018100600	LEVER
046	6918111800	