




# SM-380S BAQUETTE MOULDER PARTS LIST **SINMAG**



## SM380S BAGUETTE MOULDER PARTS LIST

Parts Number	Parts Code	Parts Name
SM380S001	14FM210-01	Transmission Wheel
SM380S002	15PDLXPA1450	Belt
SM380S003	14FM415-010	Connecting Rod
SM380S004	14C665-01	Spring
SM380S005	14FM360-02	Changing Wheel
SM380S006	14FM410-01	Connecting Rod
SM380S007	14FM260-01	Adjusting Housing of Top Roller(left)
SM380S009	14FM180-01	Motor Pulley Wheel
SM380S010	15PDL530	Belt
SM380S011	14FM350-02	Changing Wheel
SM380S012	14FM420-01	Connecting Rod
SM380S013	14FM190-01	Transmission Pulley Wheel
SM380S014	14FM250-01	Adjusting Housing of Top Roller
SM380S015	14FM300-01	Sprocket Wheel
SM380S016	14FM290-01	Sprocket Wheel
SM380S017	14FM305-01	Sprocket Wheel
SM380S018	15LTL06B1*42	Chain
SM380S019	14FM310-01	Sprocket Wheel
SM380S020	14FM295-01	Sprocket Wheel
SM380S021	14FM380S-02	Changing Wheel
SM380S022	15LTL06B1*98	Chain
SM380S023	16BYQBK30-1	Transformer
SM380S024	14FM425-01	Support Rod
SM380S025	14FM370-02	Changing Wheel
SM380S026	14FM455-01	Fixing Block of Top Scraper Holder
SM380S027	14FM480-01	Scraper Shelf
SM380S028	14FM485-01	Scraper Shelf
SM380S029	16KGLE2E-XSMY1	Approach Switch
SM380S030	15SSD1300*780	Transmission Belt
SM380S031	15SSD1140*780	Transmission Belt
SM380S032	15BSL3/8*15	Plastic Knob
SM380S033	16KGLAR22V2R01R	Emergency Switch
SM380S034	16KGLAR22FOP10G	On/Off Switch
SM380S035	13FM090-01	Roller
SM380S036	13FM100-02	Roller
SM380S037	14FM465-01	Spring
SM380S038	14FM455-02	Fixing Block of Top Scraper Holder
SM380S039	14FM580-01	Wool Cushion
SM380S040	15FM520-01	Skin Cover
SM380S041	11FM430-02	Filler Assembles

SM380S042	15LELC3	Castors
SM380S043	14FM235-01	Fixed Rod Of Idler
SM380S044	14FM230-01	Support Seat Of Idler
SM380S045	14FM220-01	Idler
SM380S046	14FM270-02	Eccentric Wheel
SM380S047	11FM405-01	Piece Link
SM380S048	14FM210-01	Drive Gear Wheel
SM380S049	14FM315-01	Support Seat Of Idler
SM380S050	14FM135-01	Roller
SM380S051	14FM155-01	Roller
SM380S052	14FM160-01	Roller
SM380S053	14FM155-01	Roller
<a href="#">SM380S054</a>	14FM160-01	Roller
SM380S055	14FM460-01	Torsion Spring
SM380S056	14FM465-01	Torsion Spring
SM380S057	16MDL380-6	Motor
SM380S058	14FM519-01	Tension Spring
SM380S059	15ZCL6304VV	Bearing
SM380S060	15ZCL6201VV	Bearing
SM380S061	15ZCL6206VV	Bearing
SM380S062	15ZCLBPF4	Bearing
SM380S063	15ZCL6303VV	Bearing