



*Frigidaire*

Factory Parts Catalog

Product No.	FN30LPDC	FN30NGDC
Series	Grill & Cart	Grill & Cart
Market	NECO	NECO
Color	stainless steel	stainless steel
Owner's Guide	FD/FN30IMD	FD/FN30IMD

 **Electrolux**

Electrolux Major Appliances  
 North & Latin America  
 P.O. BOX 212378  
 AUGUSTA, GA 30917


Publication No.  
**5995436473**  
 05/05/10  
 (EN/SERVICE/BJH)  
 099

**GAS GRILL**

Model No.  
**FN30LPD / FN30NGD**

Copyright © 2005 Electrolux Home Products, Inc.  
 All rights reserved.

RECOMMENDED SPARE PARTS



**RECOMMENDED SPARE PARTS**

*Model Index:* A FN30LPD (FN30LPDC)  
 B FN30NGD (FN30NGDC)

POS. NO	PART NO.		DESCRIPTION
1	5304444388	A B	Handle End, hood, left
2	5304444390	A B	Handle End, hood, right
3	5304444452	A B	Handle, hood
4	5304444457	A B	Hood, grill
5 #	5304444392	A B	Guage, temperature
6 #	5304444460	A B	Burner, main, 3 cell
7	5304444398	A B	Flavor Grid, igniter cover, bottom, angle
8	5304444399	A B	Flavor Grid, burner cover, top, angle
9 #	5304444439	A B	Electrode, main burner
10	5304444461	A B	Shelf, warming rack
11	5304444459	A B	Grate, main burner
12	5304444437	A B	Shelf, left side
13 #	5304444675	A -	Regulator, LP
13 #	5304444424	- B	Regulator, NG
14	5304444416	A B	Panel, cart, right side
15	5304444418	A B	Channel, wheel, swivel
16	5304444454	A B	Panel, cart, back
17	5304444455	A B	Base, cart
18	5304445083	A B	Channel, wheel, fixed
19	5304444426	A B	Handle End, door, right
20	5304444425	A B	Handle End, door, left
21	5304444463	A B	Handle, door, 12.525 inch
22	5304444456	A B	Door, cart
23	5304444391	A B	Magnet, door
24	5304444404	A B	Housing, igniter battery
25 #	5304444642	A B	Igniter, 2-pole, no ground, with bracket
26	5304445082	A B	Panel, igniter access
27 #	5304445085	A B	Manifold
28	5304444405	A B	Knob, burner
29	5304444406	A B	Bezel, knob
30 #	5304445069	A -	Valve, burner, main/side, LP
30 #	5304445070	- B	Valve, burner, main/side, NG
31	5304444438	A B	Tray, drip pan
32	5304444427	A B	Panel, cart, left side
33	5304444458	A B	Cover, infrared burner
34	5304444419	A B	Door Stop
35 #	5304444431	A B	Wire, igniter, positive
36 #	5304444432	A B	Wire, igniter, negative
37 #	5304447621	A B	Elbow, gas fitting, manifold/hose
38 #	5304446174	A B	Hose, gas, 10", main supply
39 #	5304447623	A B	Elbow, main connection
40 #	5304447624	A B	Fitting, main connection
*	5304444441	A B	Bolt, valve/manifold
*	5304444442	A B	Bolt, wheel & cart
*	5304444443	A B	Nut, door, bottom pivot
*	5304444444	A B	Screw, door, bottom pivot
*	5304445048	A B	Screw, bezel/valve
*	5304444446	A B	Screw, hood handle end
*	5304444447	A B	Screw, self-tapping
*	5304444449	A B	Wire, igniter, main burner, left & right