


3073SQ-O-HV

Parts View



Part Number	Description	Qty	Part Number	Description	Qty
40010002	8-32 X 3/8" Panhead Screw	6	60090000	1/2" NPT Domed Cord Strain Relief	1
40010076	Silicone Cap for Mechanical Float Sensor	1	60090001	1/2" NPT Nut	1
40010079	10-32 x 3/8 Panhead Screw	4	60090019	MNU Level Sensor Assembly w/ Standpipe & Fan	1
60020016	120V 250W Heater Belt	2	60090041	M3 Gen 3 Control Panel assembled & mounted for NA	1
60020059	Mechanical Float Sensor	1	70020201	NEMA Enclosure Mounting Bracket for M3 Control Panel	1
60020075	Weatherproof NEMA Enclosure	1	60020110	Power Supply Cord, Schucko CEE 7/7 for EU Outlet	1


FRONTLINE
international
187 ASCOT PARKWAY
CUYAHOGA FALLS, OH 44223

TITLE: 3073SQ-O-HV Parts View
PART NUMBER: 3073SQ-O-HV

2/1/24 SHEET 1 OF 3

3073SQ-O-HV

Parts View



Part Number	Description	Qty	Part Number	Description	Qty
10010001	2" 90 Deg. Galv. Elbow	1	10020062	2" PVC Flush Plug	1
10010002	2" X 12" Black Iron Nipple	1	40010054	3" Tank Vent	1
10010015	3/4" Galv. 90 deg. Street Elbow	1	40010077	3" Spring-Loaded Emergency Vent	1
10010022	3/4" Galvanized Union	1	40020008	10-24 x 1/2" Truss Head Screw	36
10010037	3/4" Galv. Close Nipple	1	60020133	3/4" Two Way SS Valve w/ Spring Close	1
10010119	3/4" x 8" Galv. Nipple	1	70020226	Modular Tank Pallet Base Hole Cover	2

FRONTLINE

international

187 ASCOT PARKWAY
CUYAHOGA FALLS, OH 44223

TITLE

3073SQ-O-HV Parts View

PART NUMBER


3073SQ-O-HV

2/1/24

SHEET 2 OF 3


M3 Gen 3 Control Panel w/ Remote Switch Kit

J2 Heater




60020019

J6 Recovery





J12 Heater





60020019

Fill




60020133

J3 Pump






60020119

J7




J8 Power In




J11 Valve Status


J20




J19 MODBUS



MODBUS 2



J18 Sense Pulse




J21 EX-Pump



J12 Float SW



J15 4-20mA Loop



NOTE:
Shield Braid should be
connected to GND

60090019

60020059 Normally Open

TOLERANCES ARE:
.XX: ± .010
.XXX: ± .005
ANGULAR: ± .5°

THIS DRAWING IS
CONFIDENTIAL
PROPERTY OF
FRONTLINE
INTERNATIONAL

FRONTLINE
international
187 ASCOT PARKWAY
CUYAHOGA FALLS, OH 44223
TITLE 3073SQ-O-HV Parts View
Wiring Diagram
DRAWN CCB SHEET 3 OF 3