

Cabinet Exterior – Front View



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOME (Bun Warmer)	1	87685	87723	87823
2	RUBBER BUMPER/FOOT	4	87247	87247	87247
3	KNOB	4	47120	47120	47120
4	8-32 X 3/8 PAN HD PH M/S	4	12389	12389	12389

Cabinet Exterior – Front View



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOME (Bun Warmer)	1	87685	87723	87823
2	RUBBER BUMPER/FOOT	4	87247	87247	87247
3	KNOB	4	47120	47120	47120
4	8-32 X 3/8 PAN HD PH M/S	4	12389	12389	12389

Cabinet Exterior – Front View



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOME (Bun Warmer)	1	87685	87723	87823
2	RUBBER BUMPER/FOOT	4	87247	87247	87247
3	KNOB	4	47120	47120	47120
4	8-32 X 3/8 PAN HD PH M/S	4	12389	12389	12389

Cabinet Exterior – Front View



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOME (Bun Warmer)	1	87685	87723	87823
2	RUBBER BUMPER/FOOT	4	87247	87247	87247
3	KNOB	4	47120	47120	47120
4	8-32 X 3/8 PAN HD PH M/S	4	12389	12389	12389

Cabinet Exterior – Front View



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOME (Bun Warmer)	1	87685	87723	87823
2	RUBBER BUMPER/FOOT	4	87247	87247	87247
3	KNOB	4	47120	47120	47120
4	8-32 X 3/8 PAN HD PH M/S	4	12389	12389	12389

Cabinet Exterior – Front View



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOME (Bun Warmer)	1	87685	87723	87823
2	RUBBER BUMPER/FOOT	4	87247	87247	87247
3	KNOB	4	47120	47120	47120
4	8-32 X 3/8 PAN HD PH M/S	4	12389	12389	12389

Cabinet Exterior – Front View



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOME (Bun Warmer)	1	87685	87723	87823
2	RUBBER BUMPER/FOOT	4	87247	87247	87247
3	KNOB	4	47120	47120	47120
4	8-32 X 3/8 PAN HD PH M/S	4	12389	12389	12389

Cabinet Exterior – Front View



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOME (Bun Warmer)	1	87685	87723	87823
2	RUBBER BUMPER/FOOT	4	87247	87247	87247
3	KNOB	4	47120	47120	47120
4	8-32 X 3/8 PAN HD PH M/S	4	12389	12389	12389

Cabinet Exterior – Front View



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOME (Bun Warmer)	1	87685	87723	87823
2	RUBBER BUMPER/FOOT	4	87247	87247	87247
3	KNOB	4	47120	47120	47120
4	8-32 X 3/8 PAN HD PH M/S	4	12389	12389	12389

Cabinet Exterior – Front View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOME (Bun Warmer)	1	87685	87723	87823
2	RUBBER BUMPER/FOOT	4	87247	87247	87247
3	KNOB	4	47120	47120	47120
4	8-32 X 3/8 PAN HD PH M/S	4	12389	12389	12389

Cabinet Exterior – Front View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOME (Bun Warmer)	1	87685	87723	87823
2	RUBBER BUMPER/FOOT	4	87247	87247	87247
3	KNOB	4	47120	47120	47120
4	8-32 X 3/8 PAN HD PH M/S	4	12389	12389	12389

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View




Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218

Cabinet Exterior – Back View



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	DOOR ASSEMBLY	1	87037	87121	87884
2	KNOB LID LIFT	1	47120	47120	47120
3	8-32 X 3/8 PAN HD PH M/S	1	12389	12389	12389
4	PIVOT PIN (rod to pivot hinge)	1	87069	87125	87885
5	CONDENSATE PAN	1	87034	87109	87937
6	BUN WARMER BASKET	1	87689	87725	87825
7	WATER PAN	1	87690	87726	87826
8	DRIP PAN	1	87082	87116	87218



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C



Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C




Power/Control Unit and Rotisserie – Parts List

Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	MOTOR AND ELEMENT SUPPORT	1	87668	87715	87815
2	HEAT REFLECTOR ASSEMBLY	1	87671	87717	87817
3	CONTROL PANEL COVER	1	87669	87669	87669
4	SWITCH, LIGHTED ROCKER GR	1	42798	42798	42798
5	KNOB, HEAT SWITCH	1	47049	47049	47049
6	SWITCH PLATE	1	87733	87734	87829
7	ROTISSERIE ASSEMBLY (includes Rotisserie and cradles)	1	87739	87127	87882
8	ROTISSERIE	1	87737	87153	87830
9	ROTISSERIE CRADLE	14	87740	87151	87831
10	END SUPPORT, ROTISSERIE	1	87020	87020	87020
11	¼-20 SERRATED NUT	2	46311	46311	46311
12	OFFSET STRIP	1	87079	87079	87079
13	HEAT ELEMENT	1	88160	87122	87915
14	BRACKET, ELEMENT TIE DOWN	1	87080	87080	87080
15	STRAIN RELIEF	1	67060	67060	67060
16	POWER CORD, 15 AMP	1	87085	87085	87085
17	MOTOR ASSEMBLY	1	87713	87713	87713
18	SOCKET SUPPORT TUBE	1	87708	87728	87828
19	LAMP SOCKET	1	11034	11034	11034
20	COATED 40W CLEAR BULB	1	87065C	87065C	87065C




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297




Power/Control Unit - Interior



Item	Part Description	Qty.	Part Number		
			8102	8103	8108
1	INSULATOR TUBE	2	87039	87039	87039
2	8-32 SET SCREW	2	48040	48040	48040
3	INSULATOR BLOCK	1	87158	87158	87158
4	8-32 X ½ PH PAN SCREW	1	42226	42226	42226
5	8-32 SERRATED NUT	1	61151	61151	61151
6	MOTOR ASSEMBLY	1	87713	87713	87713
7	HEAT CONTROL	1	87297	87297	87297



Accessories



Item	Part Description	Qty.	Part No.
1	1 IN. DIAL THERMOMETER	1	8000
2	9 INCH PLASTIC TONGS	1	87092