


Complete Assembly
Part No. 540NSC
BJB Style Lighting
[serial #'s over 551525]

N/5.5E PARTS EXPLOSION DIAGRAM 01/26/21



* 504 Replaced with 501SSS
** 503 Replaced with 501SSD
Both must be replaced

9914 PROGRAMMABLE COOK CONTROLLER
(TIME AND TEMPERATURE, 8 BUTTONS)