

Cleaning Instructions for HT Scale


HOBART



Remove label cassette from the scale.



Using a cotton swab and alcohol, clean the printhead.
Printhead should be cleaned every time a label roll is changed.



Using a cotton swab and alcohol, clean roller on the label cassette.



Wipe down the scale platter, display and housing daily with a clean cloth and mild detergent solution.

NOTICE:

- Do not dampen labels, electronic parts or connections.
- Do not allow water to enter the openings in the housing. This could damage the scale system.
- Do not use a metal tool on the printhead. This could scratch or break the printhead.