




IQ-2700 - wiring diagram



Tem. -Temporizador a la conexión/Start Timer
C₁ -Contactor (Motorreductor)/Contact (gearmotor)
C₂ -Contactor (Compresor)/Contact (Compressor)
Pv. -Presostato ventilador (solo cond.por aire)/Fan Pressostat (only air cooled models)
V. -Ventilador/Fan
S. -Compresor/Compressor
Ip. -Interruptor de paro-marcha/On-off switch
St. -Paro por llenado/Full storage bin stop
lw. -Microflotador falta de agua/ Low water float switch
Ps. -Presostato de seguridad/High pressure safety pressostat
R. -Motoreductor/Gearmotor
L. -Condensador filtro/Electrical interference filter (capacitor)
T1. -Temporizador a la conexión / Start timer
Pt. -Protector térmico motor/ Motor thermal protection

DF. -Detector de fase/Phase sequence relay
C₁ -Contacto auxiliar motorreductor/Auxiliar contact gearmotor
C₂ -Contacto auxiliar autoalimentación/Auxiliar contact feedback
I -Termico compresor/Thermic compressor
II -Termico Motorreductor/Thermic gearmotor
III -Fase cambia/Phase sequence
IV -Ambar llenado/ Yellow full

REGULACION TERMICOS OVERLOAD SETTING	
COMPRESSOR	6 A
GEARMOTOR	3 A