




FRENCH DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:

KRMF706EBS00 (Black Stainless)

KRMF706ESS00 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	12		Cover, Top Hinge	20	W10709365	Screw
		Tech Sheet			Left Hand	21	W10831587	Bushing
	W10738568	English			(Includes Foil)	22		Grille, Toe
	W10738569	French		W10781438	Black		W10707422	Black
	W10730912	Owners Manual		W10781436	Grey		W10707958	Grey
	W11112988	Energy Guide			Right Hand	23	12992601	Screw
2	W10624574	Supply, Power		W10709867	Black	24	12990702	Screw
3	W10734555	Block, Pivot		W10709866	Grey	25	W10141645	Screw
4	W10505487	Gasket	13	W10277839	Lid, HV	26	12990511	Screw
5	W10675033	Board, Control	14	W10731474	Screw	27	W10788814	Supply, LED Power
6	W10415341	Gasket, HV Box	15		Hinge, Center	28	W10754591	Cover, HV Control Box
7	A3076901	Plug, Button			Left Hand	29	W10847850	Switch, Light
8	W10141622	Brake, Roller		W10691674	Black	30	W10577369	Cover, Unit
9	12992602	Screw		W10691675	Grey	31	M0108107	Clamp, Tube
10		Hinge, Top			Right Hand	32	12990302	Screw
	W11027247	Left Hand		W10691700	Black	33	W10913008	Tube, Water
	W11027248	Right Hand		W10691701	Grey	34	W10705239	Retainer, Door
11	W10673840	Screw (Stainless)	16	W10336736	Cover, Roller	35		Cabinet (Not a Servicable Part)
			17		Cover, Corner	36	549193	Clamp, Power Cord
				12587703AP	Grey			
			18	W10833705	Valve, Water			
			19		Assembly, Roller			
				W10515763	Left Hand			
				W10515762	Right Hand			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	17	W10750514	Assembly, Icebox (Foamed)	34	W10438957	Cover, Thermistor
2	W10826118	Housing, Water System	18	W10503486	Enclosure, Evaporator	35	W10738349	Assembly, Evaporator Cover
3	W10736144	Tube, Fill	19	W10525237	Pan, Drain	36	W10465948	Gasket, Evaporator Enclosure
4	W10711460	Reservoir, Water (Also Order Wire Tie Part 8567668)	20	W10785113	Trim, Icebox	37	W10510863	Gasket, Drain Tube
5	W10341329	Valve, Dual Water	21	W10833801	Fan, Icebox	38	W10320706	Gasket, Rear Return
6	W11165806	Housing, Water Filter (Also Order 2300868 - 5/16" Water Connector)	22	W11035765	Assembly, Evaporator	39	W10280988	Gasket, Rear Supply
7	W10811115	Enclosure, Water Valve	23	W10843339	Assembly, LED Module	40	W10392172	Gasket, Fan
8	W10754145	Cover, Waterbox	24	W10799016	Motor, Evaporator Fan (Includes Wire Harness)	41	W10749499	Assembly, Air Tower
9	2223877	Latch, Push	25	W10754348	Assembly, Icebox Fascia (Includes Heater)	42	W10843828	Harness, LED Wire (Includes LED lights)
10	W10754143	Door, Filter Access	26	C3680310V	Switch, Light	43	W10673048	Jumper, Fascia Heater
11	W10680605	Filter, Water	27	W10470981	Gasket, Damper	44	W10723352	Waterline
12	W10315189	Filter, Air	28	W10280983	Insulation	45	W10722983	Connector, Water Tube
13	W10674102	Waterline, Valve To Hinge	29	W10389152	Support, Fan	46	W10713934	Bracket, Connector
14	W10760808	Heater, Fill Tube	30	W10749701	Assembly, Icebox Adapter			FOLLOWING PARTS NOT ILLUSTRATED
15	12990518	Screw	31	W10503491	Retainer, Damper	W10672154		Assembly, Dual Valve Box
16	W10598013	Cover, Icebox	32	W10503492	Support, Damper			
			33	W10248595	Damper, Electronic Control			


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	12990504	Screw	14	W10503218	Assembly, Drain Funnel
2	A3189392	Gasket, Foam	9	W10280385	Thermistor	15	M0500703	Seal
3	W10843353	Assembly, LED Light Module	10	W10363507	Shroud, Evaporator Fan	16	B8381501	Gasket, Drain
4	W11282987	Cover, Evaporator (Freezer)	11	12986101	Blade, Fan	17	W10405166	Cover, Thermistor
5	12990511	Screw	12	W10905511	Grommet, Fan Motor	18	W10496613	Grille, Air (Freezer)
6	12956601	Clip, Fan Motor	13	W11039078	Motor, Evaporator (Includes Harness Thermistor, and Defrost Thermostat)	19	W10531268	Gasket, Dual Evaporator
7	W10847855	Switch, Light						


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Item 2) Left Hand	7	12990204	Screw	22	W10563328	Slide, Icemaker Shut Off
	W10634613	Black Stainless	8		Handle, Door	23	W10832970	Board, Emitter Circuit
	W10634612	Stainless		W10680044	Stainless	24	W10562839	Retainer, Ice Chute
		Right Hand	9	12990504	Screw	25	W11261135	Gasket, Ice Chute
	W10634619	Black Stainless	10		Bumper, Door	26	W10646867	Vent, Thermistor
	W10634618	Stainless		W10407187	Black	27	W10563323	Door, Emitter
2		Gasket, Door		W10407188	Grey	28	W10663692	Tube, Water
	W10873946	Black	11	W10331749	Pin, Door	29		Closer, Door
	W10873944	Grey	12	W10460893	Screw		W10714907	Left Hand
3	W10238319	Screw	13	W10737419	Trivet, 2 Liter		W10714908	Right Hand
4	W11261138	Door, Ice	14	W10737416	Bucket, Gallon	30	W11315303	Clip, Tube
5		Bracket, Stopping	15	12993001	Screw			
	W10708583	Black	16	W10567561	Gasket, Ice Door			
6		Mullion, Door	17	W10737415	Frame, Bin			
	W10752977	Black	18	W10518658	Board, Receiver Circuit			
	W10752974	Grey	19	W10563326	Cover, Receiver			
			20	2198635	Spring, Door			
			21	W10563309	Cover, Emitter			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Item 17)	7	12990518	Screw	15	W11238188	Assembly, Center Pan (Freezer)
	W10634625	Black Stainless	8	W11238210	Assembly, Upper Pan (Freezer)	16		Stop, Pan
	W10634624	Stainless	9	W10709748	Clip, Shaft		W10585151	Left Hand
2		Handle, Door	10	W10562492	Divider, Lower		W10585150	Right Hand
	W10687115	Stainless	11	W10469177	Support, Pan	17		Gasket, Door
3	W10460893	Screw	12	W10564680	Assembly, Pan Front		W10248748	Black
4	W10503522	Shaft	13	489443	Screw (Stainless)		W10248749	Grey
5		Assembly, Bracket	14		Adapter, Upper Pan	18		Badge
	W10795771	Left Hand		W10619221	Left Hand		W10518672	Badge
	W10795769	Right Hand		W10619220	Right Hand	19	W10643690	Axle, Roller
6	W10634640	Assembly, Lower Pan (Freezer)				20	W10248555	Roller, Pan


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10141625	Screw	16	W10758093	Condenser	30	W10626970	Assembly, Suction Tube
2	2188935	Blade, Fan	17	W10391376	Bracket, Valve	31	W10278140	Cover, Condenser (Bottom)
3	W10603296	Baseplate	18	W10342573	Tray, Drip	32	W10815861	Clip, Bottom Cover
4	12990511	Screw	19	W10142255	Screw	33	W10141518	Screw
5	W10776916	Extension, Drain	20	W10248589	Assembly, Evaporator	34	W10697007	Bolt
6	W10696498	Assembly, Valve Body	21	W10709318	Coil, 3 Way Valve	35	W10697017	Clip, Retaining
7	W10303521	Sleeve	22	W10909387	Motor, Condenser Fan	36	2169104	Insulation, Sound Deadening
8	W10660727	Tray, Evaporator	23	10428101	Clip, Heater	37	W10142294	Screw
9	W10622701	Screw	24	W10672162	Assembly, Unit Wire (Includes Power Cord)			REFRIGERANT CHARGE
10	12729128	Heater, Defrost	25	W10286069	Drier			6.00 oz. (R-134A)
11	W10710090	Assembly, Inverter Box	26	W10695094	Compressor			
12	W10248621	Clip, Condenser	27	W10491355	Gasket, Airdam			
13	12477102	Roller	28	12477202	Axle, Roller			
14	12992101	Screw	29	W10406719	Shroud			
15	2183042	Grommet						


SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10737428	Assembly, Tuck Shelf	11	W10788795	Roller	33	W10634635	Assembly, Secondary Mullion Bin
2		Assembly, Secondary Mullion	12		Glide, Compact (Also Order Items 27 and 35)	34		Assembly, Mullion Cover
	W10849115	Black		W11242545	Left Hand		W10733545	Black
	W10849118	Grey		W11242572	Right Hand		W10733546	Grey
3	W10325002	Screw	13	98006631	Screw	35	W10737730	Nut, Rivet
4	W10801137	Assembly, Crisper	14	W10704335	Clip, Drawer Body	36	W10731491	Cover, Side Adapter
5	W11088993	Assembly, Lighted Shelf	15	W10664603	Screw	37		Handle, Door
6	W10847515	Assembly, Crisper Cover	16	W10719660	Ladder, Side		W10680045	Stainless
7		Door, Pantry (Includes Item 8)	17	W10732765	Clip, Glide Door	38	W10460893	Screw
		Left Hand	18	W10730610	Drawer, Pantry	39	W10843353	Assembly, LED Light Module
		Right Hand	19	W10719661	Ladder, Center	40	W10512203	Harness, Side Adapter
	W10733264	Black Stainless	20	12991401	Screw	41		Interface, User
	W10733263	Stainless	21	W10666373	Screw		W10769076	Stainless
		Right Hand	22	W10638123	Guide, Crisper	42	W10826105	Assembly, Produce Preserver
	W10738905	Black Stainless	23	W10709891	Divider, Pantry Pan	43	W10847369	Support, Front
	W10738904	Stainless	24	W11215631	Assembly, Floor	44	W11294548	Assembly, Pantry Center Adapter
8		Gasket, Pantry	25	C3680310V	Switch, Light			
	W10712392	Black	26	W10847852	Switch, Rocker			
	W10685868	Grey	27	W10737605	Screw			
9	W10756314	Assembly, Shelf	28	W10549991	Thermistor			
10		Adapter, Pantry	29	W10711821	Cover, Connector			
	W11294509	Left Hand	30	W10140652	Screw			
	W11294512	Right Hand	31	W10893770	Glass, Crisper			
			32	12702901	Pad, Glide			


DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	5	W10654548	Assembly, Seperator	11	W10403752	Switch, Limit
2		Assembly, User Interface	6	W10435760	Guide, Ice	12	W10712476	Assembly, Switch Jumper Wire
	W11106553	Black	7		Tray, Drip			
				W10654552	Black			
3		Wall, Dispenser False	8		Ring, Trim			
	W10654549	Black		W10654551	Chrome			
4		Assembly, Pad	9	W10470750	Assembly, LED			
	W10663646	Black	10	W10663682	Spring, Torsion			

ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10272364	Screw	5	W10347114	Shaft, Motor	9	W10764668	Assembly, Icemaker
2	W11244792	Assembly, Ice Chute Plate	6	W11185741	Motor, Dispenser	10	W10291905	Gasket
3	2198628	Seal	7	8281163	Screw (Stainless)			
4	W10347120	Clip, Retainer	8	W10564750	Assembly, Ice Container			

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10134625	Apollo Grey
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet
	IC13B	Icemaker Kit

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key