




**30" 4 BURNER DOWNDRAFT DUAL FUEL
SLIDE-IN RANGE**

MODELS:

KSDG950ESS3 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7		Knob	20		Console, Lower Panel
	W11398809	Installation Instructions		W10786065	Stainless		W10743276	Stainless
	W11397129	Use and Care Guide	8		Grate Kit	21	W11379947	Bracket, Anti-Tip
	W11382908	Tech Sheet		W11382964	Black	22	W10162253	Brace, Corner (Left)
	W10400066	Quick Start Guide (English)	9	3196169	Screw		W10162252	Brace, Corner (Right)
	W10400067	Quick Start Guide (French)	10	W10289170	Support, Cooktop (Left)	23	W10555923	Bracket, User Interface
	W10817089	Downdraft Template		W10289169	Support, Cooktop (Right)	24	W10598048	Bracket, Console (Center)
2		Burner Cap Kit	11	W10432544	Griddle	25	W11355689	Keypad Shield
	W11352138	Black (Set of 4)	12		Endcap	26		Grill, Air
3		Console		W10555937	Stainless (Left)		W11383491	Black
	W10901117	Stainless		W10555940	Stainless (Right)	27	W10612719	Gasket, Console/ Cooktop
4	W11352018	Spreader, Flame (Left Front & Right Front)	13		Trim, Vent			FOLLOWING PARTS NOT ILLUSTRATED
	W11352020	Spreader, Flame (Right Rear)		W10636529	Stainless		W11451578	Harness, Main
	W11352021	Spreader, Flame (Left Rear)	14	W10759299	Control MRC2		W10598169	Harness, Display
5		Cooktop	15	W10759325	Assembly, Display		W10575120	Harness, Keypad
	W11117943	Stainless	16	W10558372	Bracket, Control		W11198274	Harness, Down Draft Fan Jumper
6	7101P485-60	Screw, Anti-Tip Kit	17		Bezel		W10653092	Suppressor
				W10785119	Stainless (Kit of 5)			
			18	W10645947	Grommet			
			19	W10854253	Bumper			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	22	W10162257	Duct, Cooktop	44	W11117035	Shield, Wire
2	3196560	Screw	23	3196178	Screw	45	W10162241	Channel, Rear
3		Panel, Side	24	W11430367	Light Assembly	46	W10575377	Cover, Wire
	W10162245	Black	25	W10571723	Bulb, Halogen 40 Watts	47	W11379354	Cover, Back
4	7103P027-60	Nut	26	3400016	Screw	48	W10686408	Kit, Reservoir (Steam Rack)
5	W11491752	Gasket, Door	27	W10586204	Sensor	49	W10554007	Rack, Steam
6	W10544952	Element, Broil	28	3196169	Screw	50	W10554006	Rack, Maximum Capacity
7	W10774342	Element, Bake	29	W10655441	Shield, Power Cord	51	W10911366	Rack, Sliding
8	W10362924	Screw	30	W10031780	Screw	52	W10624592	Cord, Power
9	W11122085	Assembly, Flue	31	W11370463	Rod, Door Switch	53	W10558277	Burner Box, Gas Downdraft
10	W10289168	Box, Burner SI	32	9758701	Spacer, Door	54	W10828882	Bracket, Panel (Right)
11	W10341186	Front Foot Assembly	33	W10774446	Bottom, Oven	55	W10828883	Bracket, Panel (Left)
12	W10162258	Cover, Regulator	34	W10627802	Switch, Door			FOLLOWING PARTS NOT ILLUSTRATED
13	W10541959	Shield, Bake	35	W10281322	Kit, Bare Wire Adapter Block			
14	W10137382	Clip, Panel	36	W10603482	Rack, Ladder		W10162240	Insulation, Back
15	W10390008	Base Rail Assembly (Left)	37	W11353932	Convection Assembly		W10575374	Insulation, Bottom
	W10390007	Base Rail Assembly (Right)	38	W10346153	Baffle, Full Convection		4820F015-59	Insulation, Strap
16	W10058460	Foot, Leveling	39	W10273002	Bracket, Oven Support		7111P017-60	Clamp, Wire
17	3196548	Fuse, Thermal	40	W11379357	Bake Pan		W10289173	Insulation, Wrap
18	3196172	Screw	41	W10162255	Duct, Cover			
19	W10035900	Support, Oven Bottom	42	W10162254	Duct, Cooling			
20	3186034	Bracket, Service	43	W11190724	Assembly, Cooling Fan			
21	W10246624	Block, Terminal						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	6	W10669526	Electrode, Burner	9	W10661850	Assembly, Regulator & Bracket
2	W11186514	Orifice Assembly (Left Front)			(Left Front)	10	W10849722	Orifice (18K) (Left Front)
	W11186509	Orifice Assembly (Left Rear)		W10669525	Electrode, Burner (Left Rear)		W10849719	Orifice (5K) (Left Rear)
	W11186526	Orifice Assembly (Right Front)		W10669524	Electrode, Burner (Right Front)		W10849717	Orifice (15K) (Right Front)
	W11186522	Orifice Assembly (Right Rear)		W10669523	Electrode, Burner (Right Rear)		W10849714	Orifice (9.5K) (Right Rear)
3	W10295996	Bracket, Saddle Valve	7	W11416335	Manifold Assembly	11	W10827923	Spring, Electrode
4	W10552945	Tube, Supply	8	W10566062	Valve, Gas (Left Front & Right Front)	12	W10140571	Seal, Switch Shaft
5	W10669619	Harness, Switch Spark				13	W10475148	Module, Spark
				W11416332	Valve, Gas (Left Rear)			FOLLOWING PARTS NOT ILLUSTRATED
				W10566057	Valve, Gas (Right Rear)		W11396878	Kit, LP Conversion
							W10182767	Tie, Manifold Wire


BLOWER PARTS



BLOWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10661156	Enclosure, Blower	6	W10789431	Kit, Plenum Transition	11	W10661835	Plenum, Side
2	W10572225	Plenum Intake, Gas	7	W10789391	Kit, Blower Installation	12	W10702071	Retainer
3	W10572145	Plenum, Upper	8	W10810492	Kit, Blower	13	W10759311	Gasket, Blower
4	W10575379	Grease, Filter	9	W10788527	Assembly, Capacitor	14	W10642096	Adaptor, Exhaust
5	W10575393	Guard, Filter	10	W10787917	Cover, Capacitor	15	W10789390	Assembly, Plenum Support Bracket

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Door Handle
	W10551000	Stainless
2	9780274	Screw
3	W10518672	Badge
4	W10826568	Liner, Door
5	W10031790	Screw
6	W11223202	Glass, Inner

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10885519	Hinge, Door (Active)
8		Assembly, Outer Door
	W10634271	Stainless
9	W10541911	Bracket, Glass Upper Handle
10	W10327235	Screw
11	W10813140	Rail, Horizontal Support

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10031780	Screw
13	W11091878	Screw
14	W10813139	Rail, Vertical Support
15		Scoop, Door
	W10551024	Stainless
16	W10319024	Washer, Door
17	W11379948	Glass Spacer
18	W10766562	Insulation, Door

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3196169	Screw	3	W10318026	Bracket, Mounting
2		Panel, Drawer Front	4	8004P024-60	Spacer, Side Panel
	W10634248	Stainless	5	W10798390	Baffle, Drawer Panel

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		CLEANERS / POLISHES
	31605	Kit, Cooktop Care
	31463A	Protectant, Cooktop
	W10355051	Cleaner, Cooktop
	W10355016	Cleaner, Stainless Steel
	WA906B	Scraper, Cooktop
	W10355049	Wipes, Stainless Steel Cleaning
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	W10432019	Alt Cleaning Kit
	W10391473	Pad, Cooktop Cleaning
		MISCELLANEOUS
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting
	W10432539	Griddle
	W10432545	Kit, Grill
		TRIM KITS
	W10675026	Black
	W10675027	White
	W10675028	Stainless
		BACKSPLASH ASSEMBLY
	W10655449	Black
	W10655448	White
	W10655450	Stainless