

“Old Style” Front Line Bread Display Cabinet

PRIOR TO APRIL 1, 2011

CA57-RR15-CD-R Right Hinge

CA57-RR15-CD-L Left Hinge

- 1) **CAS-51PO-S (ITEM # 73038)**
Plate swivel caster – no brake, each with hardware
- 2) **CAS-51PO-S-B (ITEM # 73068)**
Plate swivel caster with brake, each with hardware
- 3) **RUNNER-CA57 (ITEM # 73074)**
Pair of tray slides @ 22 7/8" – 15 pair per cabinet
- 4) **DOOR-57-CDFR-MH-R (ITEM # 73075)**
Door w/ hinges on RIGHT / Magnetic handle and hardware
- 5) **DOOR-57-CDFR-MH-L (ITEM # 73076)**
Door w/ hinges on LEFT / Magnetic handle and hardware
- 5) **HINGE-CA57-RH (ITEM # 73077)**
Slip hinge for RIGHT hinged cabinet – male/female w/ hardware
- HINGE-CA57-LH (ITEM # 73078)
Slip hinge for LEFT hinged cabinet – male/female w/ hardware
- 6) **DOOR GASKET – CA57 (ITEM # 73079)**
Door gasket material 12 foot
- 7) **GASKET KIT – CA57 (ITEM # 73080)**
Door gasket material 12 foot with installation tool
- 8) **STRIKE-LG (ITEM # 73019)**
Handle strike plate with hardware
- 9) **HAN-CA (ITEM # 73081)**
Magnetic door handle with hardware
- 10) **STRIKE-MOUNT (ITEM # 73082)**
Angled strike plate holder with hardware
(includes Item #73019)

