

Companion Bread Display Cabinet

CA72-RR18-S-R Right Hinge

CA72-RR18-S-L Left Hinge

- 1) **SS-STRIP-LG (ITEM # 72821)**
Stainless Steel Strip- Large
- 2) **HINGE-CA7218-RH (ITEM # 73029)**
Slip hinge for RIGHT hinged cabinet – male/female w/ hardware
- 3) **HINGE-CA7218-LH (ITEM # 51016)**
Slip hinge for LEFT hinged cabinet – male/female w/ hardware
- 4) **GASKETMAG2121 (ITEM # 72804)**
Magnetic gasket assembly – top door
- 5) **DOOR-72-RR18-S-R (ITEM # 72803)**
Upper door w/ hinges on RIGHT
Integrated handle, magnetic gasket and hinges
- 6) **DOOR-72-RR18-S-L (ITEM # 72802)**
Upper door w/ hinges on LEFT
Integrated handle, magnetic gasket and hinges
- 7) **SS-STRIP-SM (ITEM # 72822)**
Stainless Steel Strip – Small - 2 per cabinet
- 8) **RUNNER-CA72RR (ITEM # 73036)**
Pair of tray slides @ 24 ½" length – 18 pair per cabinet
- 9) **GASKETMAG2141 (ITEM # 72805)**
Magnetic gasket assembly – bottom door
- 10) **DOOR-72-RR12-R (ITEM # 72801)**
Lower door w/ hinges on RIGHT / Magnetic gasket and hardware
- 11) **DOOR-72-RR12-L (ITEM # 72800)**
Lower door w/ hinges on LEFT / Magnetic gasket and hardware
- 12) **CAS-51PO-S (ITEM # 73038)**
Plate swivel caster – no brake, each with hardware
- 13) **CAS-51PO-S-B (ITEM # 73068)**
Plate swivel caster with brake, each with hardware

