

REPLACEMENT PARTS LIST

**M4RC SERIES
UPFLOW, SINGLE STAGE, CONDENSING GAS FURNACES, 92.1% AFUE**



M4RC REPLACEMENT PARTS LIST

UPFLOW, SINGLE STAGE, CONDENSING GAS FURNACES, 92.1% AFUE

DESCRIPTION	M4RC054D24B	M4RC072D35C	M4RC090D35C
Blower Assembly	904682	904683	904684
Blower Housing	297207R	297204R	297209R
Blower Motor	904858	904859	904860
Blower Wheel	667258	667207	667280
Burner Assembly	904927	904928	904929
Capacitor	01-0024	01-0026	01-0026
Control Board	920915	920915	920915
Door Set	904768	904769	904769
Door Switch	632125	632125	632125
Filter (Not Shown)	—	669785	669785
Flame Sensor	632484	632484	632484
Fuse (Not Shown)	632261	632261	632261
Gas Valve	624610	624610	624610
Hard Drain Tube "J" (Not Shown)	663706	663706	663706
Heat Exchanger	904869	904870	904871
Header Box	904802	904803	904803
High Temperature Hose (Not Shown)	263967R	263967R	263967R
Ignitor	1017743S	1017743S	1017743S
Igniter Bracket (Not Shown)	299261	299261	299261
In-Line Drain Assembly	664435	664435	664435
Inlet Air Finish Flange	664633	664633	664633
Inducer Limit Switch	626599	626599	626599
Inducer Motor	904798	904798	904798
Inducer Orifice	669712	669715	669717
Inshot Burner	661134	661134	661134
Main Air Limit	—	—	626613R
Manifold	664238	664239	664240
Motor Mount	904951	904980	904951
Orifice (Natural Gas)	661047	661047	661047
Orifice (LP Gas)	661056	661056	661056
Pressure Switch (Condensate)	632491	632491	632491
Pressure Switch (Inducer)	632487	632493	632493
Roll-Out Switch	626558	626559	626559
Set of Wires (Not Shown)	M0036003R	M0036007R	M0036007R
Soft Drain Tube, 23" (Not Shown)	664434	664434	664434
Soft Drain Tube, "J" 30" (Not Shown)	663707	663707	663707
Soft Tube, 6.5" (Not Shown)	663727	663727	663727
Top Panel	2B3552R	2B3553R	2B3553R
Transformer	622341	622341	622341

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

M4RC COMPONENT LOCATION

