

NEWCO "R" and "L" Model Series Common OEM Parts.

All Parts Listed Below Are Common To "R" And "L" Model Brewers Unless Specified Otherwise.

Description	Fits	Part #	Description	Fits	Part #
Brewbaskets / Brew Rails & Parts			Plates, (Name, Switch) & Associated Parts		
<i>Brewbaskets Listed Below Use Standard Brew Rails.</i>					
Basket, 8-Sided Universal Black	P,A,F	100385-3	Nameplate, Newco	P,A,F	100058
Color Change, 8-Sided Univ.	P,A,F	781153	Nameplate, Blank, 3/4"	P,A,F	100138
Basket, Low Profile - LPA/LPF*	A,F	100051	Nameplate, Blank, 1"	P,A,F	201103
Basket, Low Profile - Black Only*	A,F	100051-1	Switch Plate, 2 Station	P,A,F	100142
Brew Rail, Right (Standard)	P,A,F	100076	Switch Plate, 3 Station	P,A,F	100059
Brew Rail, Left (Standard)	P,A,F	100077	Switch Plate, 2 Station - LPA/LPF	A,F	100372
<i>Brewbaskets Listed Below Use Rails Shown</i>			Tinnerman Clip. #6	P,A,F	100184
New Style Black Basket,	P,A,F	110985	Receiving Pan & Parts R & L		
-Right Hand Brew Rail	P,A,F	511033	Receiving Pan, Pourover	P	100045
-Left Hand Brew Rail	P,A,F	511034	Receiving Pan, S/S (For R-Auto)	A,F	100039
Screw, Brew Rail (8/32 x 1/4)	R,L	100242	Receiving Pan, S/S (For LPA / LPF)	A,F	100373
Cord, Power R & L			Gasket, Receiving Pan	P,A,F	100132
Power Cord, 15 amp, 120 V, 14/3	P,A,F	100022	Solenoid Valve / Parts (RC2AF / RD3AF Only)		
Covers & Associated Parts R & L			Solenoid Valve Ass'y.	F	100083
Cover, Pour-In Dish (Brown)	P,A,F	100128	-Bracket, Solenoid Valve	F	100137
Cover, Pour-In Dish (Black).	P,A,F	100128-1	-Connector, Male 1/4"Cx1/8"NPT	F	100155
Cover, W/One Wrnr/Pour-In	P,A,F	100084	-Elbow, Male, 1/4 F x 1/4 NPT	F	100037
Cover, W/One Blk. Wrnr & Pour-In	P,A,F	100084-1	-Elbow, Male, 1/4 Flare x 1/8 NPT	F	100177
Pour-In Dish Ass'y. (S/S)	P,A,F	100015	-Male Connector, 1/4"F x 1/4" NPT	F	201104
Dust Cover With Chain (Brown)	P,A,F	100180	-Needle Valve. 3/8" F x 1/4" NPT	F	100171
Dust Cover With Chain (Black).	P,A,F	100180-1	-Screw, 10-32 x 1/4 PHSMS	F	100613
Tinnerman Clip, Cover. (#6 J-Type).	P,A,F	100184	-Solenoid Valve, KIP	F	100255
Screw, For Brewer Cover	P,A,F	100065	-Solenoid Valve, 120V (Skinner)	F	100250
Faucets & Associated Parts R & L			-Swivel Nut Connector.	F	100161
Faucet, Tomlinson	A,F	100110	-Union Tee. 1/4" NPT	F	100169
Bonnet Ass'y, Faucet	A,F	100610	Repair Kit, Solenoid Valve.	F	101527
-Faucet Handle	A,F	100617	Solenoid Valve / Parts (LPF Model Only.)		
-Pin	A,F	100639	Parts Below are in Addition to Parts in 100083 Above.		
-Spring	A,F	100786	Solenoid Valve Ass'y.	F	100656
-Seat Cup	A,F	102675	-Solenoid Valve, KIP	F	100255
-Seat Only	A,F	110041	-Flow Control .190 GPM	F	152190
-Aerator	A,F	100619	- Flow Washer. .190	F	100289
Retainer Bonnet	A,F	100437	- Body, Flow Control Pipe	F	100293
Retainer Washer	A,F	100469	- Cap, Compression	F	100296
Bonnet Repair Kit	A,F	201256	- Screen, Flow Control	F	100299
Faucet Coil Ass'y Complete	A,F	100087	- Gasket, Flow Control. Nylon	F	790019
Flex Tube Assembly Faucet	A,F	100011	Repair Kit, Solenoid Valve.	F	101527
Feet R & L			Spanner Nut, Skinner Valve	F	202079
Bumper Foot with Screw	P,A,F	100078	Solenoid Valve / Parts (RC2A / RD3A Only)		
Labels R & L			Solenoid Valve Ass'y,	A	100092
Label, Caution (Red)	P,A,F	100253	-Elbow, Male, 1/4 Flare x 1/4 NPT	A	100037
Label, Caution: Hot Surfaces"	P,A,F	100254	-Bushing, Reduce, 3/8 x 1/4 NPT	A	100173
Label, "Hot Liquid, Handle w/Care."	P,A,F	110120	-Washer, Flow Control, .250, Red	A	100290
			-Cap, Compression	A	100296
			-Gasket, Flow Control	A	790019

NEWCO Enterprises, Inc.

Technical Service 800-556-3926 Customer Service 800-325-7867

www.newcocoffee.com

NEWCO "R" and "L" Model Series Common OEM Parts.

All Parts Listed Below Are Common To "R" And "L" Model Brewers Unless Specified Otherwise.

Description	Fits	Part #	Description	Fits	Part #
Solenoid Valve / Parts (RC2A / RD3A Only) Continued			Tank Parts & Fittings Cont. R & L		
-Solenoid Valve, Automatic	A	100251	-Nut, 9-16-24 x 11/16 Hex.	P,A,F	100431
Repair Kit, Solenoid Valve.	A	201158	Vacuum Breaker, Brass	P,A,F	202090
Spanner Nut, Skinner Valve	A	202079	-Bulkhead Outlet Fitting	P,A,F	100135
Solenoid Valves / Parts (LPA Model Only)			-Gasket, Bulkhead, Brass	P,A,F	100030
Solenoid Valve Ass'y.	A	100640	Tank Heater, 1200W, 120V	P,A,F	203002
-Valve, Solenoid	A	100251	Thermostat & Assoc. Parts (See P. 32) R & L		
-Elbow, Male, 1/4 F x 1/4 NPT	A	100037	Bracket, Hi-Limit Thermostat	P,A,F	100269
-Bushing, Reduce, 3/8 x 1/4 NPT	A	100173	Bracket, Main Thermostat	P,A,F	100013
-Screw, 8-32 x 1/4 SPHMS	A	100242	Clip, Thermostat, Capillary	P,A,F	100209
-Washer, Flow Control.	A	100289	Grommet, Thermostat	P,A,F	100175
-Cap, Compression- Flow Control	A	100296	Screw, for Main Thermostat	P,A,F	100065
-Gasket, Flow Control	A	790019	Thermostat, Hi-Limit (White Cell)	P	110574
Sprayhead / Sprayhead Tube & Parts R & L			Thermostat, Hi-Limit Reset	P,A,F	111592
Sprayhead, S/S, 5-Hole	P,A,F	100024	Thermostat, Main - Cotherm	P,A,F	100448
Sprayhead Tube Ass'y	P,A,F	100009	14GA, Lead Vio/Bk 12" Tef. 1S - 1S	P,A,F	103011
-Sleeve, 3/8" Comp.	P,A,F	100166	14GA, Lead Vio/Bk 7" Tef. 1S - 1S	P,A,F	108215
-Gasket, Sprayhead	P,A,F	100025	Timers & Assoc. Parts R & L		
-Nut, 3/8" Comp.	P,A,F	100170	Timer, 1-Button	A,F	100401
-Sprayhead Tube	P,A,F	102555	Timer, 2 Button (Start / Stop)	A,F	100405
Nut, Sprayhead (7/16 - 20)	P,A,F	201173	-Timer Only	A,F	101365
Switches R & L			-Timer Bracket	A,F	102419
Switch, Warmer	P,A,F	100085	-Start Switch	A,F	100343
Switch, Master On/Off	P,A,F	100500	-Stop Switch	A,F	201161
Start Switch	P,A,F	100343	Timer Only W/Harness 2-Button	A,F	100417
Stop Switch w/Spades	P,A,F	201161	Timer Only W/Harness 1-Button	A,F	100416
Tanks			Harness, Timer (For 100401)	A,F	103238
Tank, Pour-over - R Only	P,A,F	100040	Harness, Timer (For 100405)	A,F	103236
Tank Only, Faucet Model - R Only	F	100271	Plate, 1-Button Timer, Plastic	A,F	100136
Tank Only, Faucet Model - LPF	F	100364	Plate, 2-Button Timer, Plastic	A,F	100127
Tank Ass'y Complete Faucet - R	F	100457	Tubing / Discharge Tubes R & L		
Tank Ass'y Complete Faucet - LPF	F	100375	Discharge, Tube Ass'y. Auto	P,A,F	100118
Tank Ass'y Complete PO - R Only	P	100455	Discharge, Tube Ass'y. Ext. Flow	P,A,F	100117
Tank Parts & Fittings R & L			Discharge, Tube Ass'y. Int. Flow	P,A,F	101186
Tank Heater Ass'y. 1400W, 120V	P,A,F	102580	Warmer Plates & Assoc. Parts R & L		
-Gasket, Brass	P,A,F	100409	Warming Plate Ass'y, Black	P,A,F	100010
-Nut, 1/2-20 Jam, Brass	P,A,F	100190	-Warming Element, 100W, 120V	P,A,F	100187
Bulkhead, Faucet Coil	A,F	100029	-Warming Plate, Black	P,A,F	100008
Brass Gasket	P,A,F	100030	Screw, Warming Plate	P,A,F	100160
Nut, 9/16-24 x 11/16 Hex	P,A,F	100431			
Bulkhead Fct. Coil Outlet Ass'y	A,F	100607-10			
-Coupling, Bulkhead Outlet	A,F	100607			
-Gasket, Brass	A,F	100030			

NEWCO Enterprises, Inc.

Technical Service 800-556-3926 Customer Service 800-325-7867

www.newcocoffee.com