


Parts Breakdown



Model BS-VE-3200-S 10272



Parts Breakdown


Model **BS-VE-3200-S** 10272

060098




060035

060019




Parts Breakdown

Model **BS-VE-3200-S** 10272




Parts Breakdown

Model BS-VE-3200-S 10272




Parts Breakdown

Model BS-VE-3200-S 10272




Parts Breakdown

Model BS-VE-3200-S 10272




Parts Breakdown

Model **BS-VE-3200-S** 10272



Parts Breakdown

Model BS-VE-3200-S 10272



Parts Breakdown

Model BS-VE-3200-S 10272

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
62199	Front Cover for Steering Wheel for 10272	06226	24156	Scraper Bracket for 10272	060074	64827	Complete Strap with Iron Handle for 10272	060175
64825	Steel Cover for Steering Shaft for 10272	06229	62201	Switch for 10272	060076	62197	Complete Car Iron Wheel for 10272	060181
45115	Washer for 10272	060003	17707	Scraper for 10272	060078	24155	Bolt for 10272	060184
62202	Metal Tray for 10272	060009	17708	Scraper for 10272	060080	26129	Long Screw for Aluminum Guide for 10272	060187
62185	Base with Facial Steel or Iron Roller for 10272	060011	62186	Steel Handle for 10272	060081	44012	Lower Shaft Nut for 10272	060190
62152	Motor Base for 10272	060012	44013	Micro Switch for 10272	060089	24136	Pulley for 10272	060193
62061	Long Door Hinge for 10272	060014	62208	Complete Aluminum Housing for 10272	060098	64826	Upper Flywheel Complete for 10272	060197
62210	Full Arm Shield for 10272	060019	24154	Pin for 10272	060103	62206	Complete Upper Cylindrical Flywheel for 10272	060202
23716	Belt for 10272	060027	62078	Tightening Knob for 10272	060107	24137	Pulley for 10272	060209
45116	Pin for 10272	060029	16869	Knob for 10272	060108	62204	Motor Tension Screw for 10272	060222
62184	Spacer for 10272	060033	62192	Aluminum Front Plate for 10272	060116	17717	Cover for 10272	060229
62209	Arm Shaft for 10272	060035	62188	Flywheel Scraper Holder for 10272	060119	62200	Aluminum Housing for 10272	060239
24135	Shaft for 10272	060038	62203	Motor Pulley for 10272	060124	62099	Door Hinge for 10272	060245
24139	Shaft for 10272	060042	45066	Guide for 10272	060127	62102	Front Plate Screw for 10272	060248
62205	Steel Square Brackets for 10272	060048	23718	Guide Assembly for 10272	060128	62103	Butterfly Screw for 10272	060249
62065	Aluminum Flange for 10272	060049	62193	Blade Protector for 10272	060131	17719	Cover for 10272	060251
62066	Aluminum Front for 10272	060051	62164	Complete Control Box for 10272	060134	31436	Housing Only for Switch for 10272	060252
62207	Complete Front Plate for 10272	060054	62132	Hairpin Spring for 10272	060138	16873	Start Switch for 10272	060253
62170	Steel Door Hook for 10272	060062	17711	Clip for 10272	060140	16874	Stop Switch for 10272	060254
15587	Fluted Guide Pair for 10272	060063	45067	Bearing 6200 for 10272	060148	62143	Screw for Roller Port Guide for 10272	060255
23714	Guide for 10272	060064	16871	Bearing for 10272	060149	45068	Screw for 10272	060256
62070	Steel Guide Support for 10272	060065	16872	Bearing for 10272	060150	45069	Screw for 10272	060257
26128	Aluminum Guide for 10272	060066	62196	Complete Pulley for 10272	060157	62195	Wheel Shaft for 10272	060259
15590	Nylon Filler Black for 10272	060069	62194	Complete Flat Wheel for 10272	060161	26130	Short Screw for Aluminum Guide for 10272	060261
62151	Motor Base Rubber for 10272	060070	40168	Seal Model for 10272	060164	39416	Motor 220/60/1 for 10272	
62071	Rubber Stopper for 10272	060071	62091	Aluminum Support for 10272	060167			