


Parts Breakdown

Model DW-CN-0076 44437



Parts Breakdown

Model DW-CN-0076 44437

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
30621	Power Cord for 44437	1	67307	LED Lights for 44437	20	67321	Front Door Glass for 44437	39
67292	Base for 44437	2	67308	Side Cover Left for 44437	21	67322	Heating Tube Plate for 44437	40
67293	Tray for Heater for 44437	3	67309	Advertisement Light Box for 44437	22	67323	Left Panel of Heater for 44437	41
67294	Heater Element for 44437	4	67310	Nut for 44437	23	67324	Bracket for Heater for 44437	42
67295	Door Pin for 44437	5	67311	Wire Fence for 44437	24	67325	Front Door Knob Left for 44437	43
67296	Upper Hinge Back for 44437	6	67312	Side Cover Right for 44437	25	67326	Front Door Knob Right for 44437	44
67297	Upper Hinge Front for 44437	7	79322	Left Shelf Bracket for 44437	26	67327	Lamp Holder Left for 44437	45
67298	Bottom Hinge Front for 44437	8	79336	Right Shelf Bracket for 44437	27	67328	Lamp Holder Right for 44437	46
71644	On/Off Switch for 44437	9	30747	Left Shelf Bracket for 44437	28	67329	Transparent Lamp Cover Right for 44437	47
71640	Temperature Thermostat for 44437	10	30750	Right Shelf Bracket for 44437	29	67330	Transparent Lamp Cover Left for 44437	48
67299	Control Panel for 44437	11	67313	Bottom Shelf Bracket Left for 44437	30	71662	Control 125°C for 44437	49
60218	Indicator Light for 44437	12	67314	Bottom Shelf Bracket Right for 44437	31	71661	Control 150°C for 44437	50
67300	Bottom Panel for 44437	13	67315	Bottom Shelf for 44437	32	71647	Base Feet for 44437	51
67301	Back Door Knob Left for 44437	14	67316	Middle Shelf for 44437	33	67331	Glass Clamp for 44437	52
67302	Back Door Frame for 44437	15	67317	Upper Shelf for 44437	34	67332	LED Lighting for 44437	53
67303	Back Door Knob Right for 44437	16	60735	Water Receiver for 44437	35	70686	Temperature Display for 44437	54
67304	Front Door Frame for 44437	17	67318	Ventilated Board for 44437	36	70860	Socket for 44437	55
67305	Cabinet Frame for 44437	18	67319	Back Door Glass for 44437	37	67333	Heater Brace for 44437	56
67306	Top Cover for 44437	19	67320	Side Glass for 44437	38	71638	Socket A for 44437	57