


# Parts Breakdown

Model MS-IT-0250-U 13620



# Parts Breakdown

## Model MS-IT-0250-U 13620

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AJ185	Pipette for 13620	A1	15093	Washer for 13620	B17	15129	Screw TC for 13620	B67
33969	Thumb Screw for Sharpener for 13620	A2	AJ189	Sail Support for 13620	B18	15130	Nut for 13620	B68
33970	Washer for 13620	A3	15096	Strain Relief for 13620	B20	AJ201	Grain Head Hunting for 13620	B69
33971	Screw for 13620	A4	AJ190	Blade Cover Tie Rod for 13620	B21	15132	Screw for 13620	B70
33972	Sharpener Shaft for 13620	A5	15098	Deflector Screw for 13620	B22	AJ202	Group Plate for 13620	B71
33973	Screw for 13620	A6	17687	Slice Deflector for 13620	B23	15134	Screw TC for 13620	B72
33974	Nut for 13620	A7	15099	Screw for 13620	B24	15135	Slide Bar Spring for 13620	B73
33975	Screw for 13620	A8	33953	Circlip for 13620	B25	AJ203	Round Bar for 13620	B74
33976	Washer for 13620	A9	33954	Circlip for 13620	B26	15137	Carriage for 13620	B75
33977	Screw for 13620	A10	AJ191	Bearing for 13620	B27	33966	Carriage Screw for 13620	B76
33978	Push Knob for Sharpener for 13620	A11	33956	Pulley for 13620	B28	15140	Carriage Nut for 13620	B77
33979	Ball Bearing for 13620	A12	15100	Belt TB2310 1/8 8 Ribs for 13620	B29	15141	Pin for 13620	B78
33980	Spring for 13620	A13	AJ192	Spindle Pin for 13620	B30	AJ204	Bearing for 13620	B79
33981	Washer for 13620	A14	33958	Screw for 13620	B31	15143	Screw for 13620	B80
33982	Screw for 13620	A15	15101	Screw TC for 13620	B32	15144	Wing Nut for 13620	B81
33983	Washer for 13620	A16	13586	Blade 250E/F/R 40-3-210 for 13620	B33	15145	Plate for 13620	B82
33984	Sharpener Housing for 13620	A17	15103	Screw for 13620	B34	15146	Motor Adjustment Bar for 13620	B83
33985	Grinding Shaft for 13620	A18	AJ193	Blade Cover for 13620	B35	15147	Spring for Adjustment Bar for 13620	B84
33914	G Stone 40x08x06 for 13620	A19	14976	Wrist Guard Plate for 13620	B46	AJ205	Motor Dom for 13620	B85
33987	Washer for 13620	A20	AJ194	Pressing Knob for 13620	B47	15149	Screw for 13620	B86
33988	Nut for 13620	A21	AJ195	Screw T.P.S.V. for 13620	B48	AJ206	Vent for 13620	B87
17212	Omcan F Stone 45x08x06 for 13620	A22	AJ196	Press for 13620	B49	15151	Motor Pin for 13620	B88
33990	Honing Shaft for 13620	A23	15115	Pin for 13620	B50	15152	Circlip for 13620	B89
33991	Sharpener Cover for 13620	A24	15117	Lock for 13620	B52	14933	Foot for 13620	B90
33992	Spring for 13620	A25	15118	Meat Plate for 13620	B53	AJ207	Flat Guard Screw for 13620	B91
15082	Casing for 13620	B1	15119	Screw for 13620	B54	AJ208	Allen Screw for 13620	B93
15083	Screw for 13620	B2	15121	Meat Plate Support for 13620	B56	25162	Bottom Cover for 13620	D4
AJ186	Graduated Knob for 13620	B3	AJ197	Arm Knob for 13620	B57	18933	Micro Switch for 13620	D10
AJ187	Chrome Screw for 13620	B4	15122	Screw for Support Bar for 13620	B58	60345	Tie Rod for 13620	D11
15085	Rivet for 13620	B5	AJ198	Square Bar for 13620	B59	33994	Screw for 13620	D13
15086	Screw for 13620	B6	15124	Screw for 13620	B60	33995	Safety Switch Holder for 13620	D14
15087	Plate for 13620	B7	15125	Washer for 13620	B61	33996	Pivot Chuck for 13620	D15
AJ188	Switch for 13620	B8	15126	Cam for 13620	B62	15081	Complete Meat Tray Assembly for 13620	
15088	Capacitor 12.5UF 370-470V for 13620	B9	15127	Cam Screw for 13620	B63	33964	Slide Support Complete for 13620	
15089	Clamp for 13620	B10	AJ199	Little Group for 13620	B64	41167	Complete Sharpening Assembly for 13620	
15090	Screw TC for 13620	B11	AJ200	Little Group Pin for 13620	B65			
15092	Screw TE for 13620	B16	15128	Screw TC for 13620	B66			