


Parts Breakdown

Model MS-IT-0300-V 13647


Stand



Parts Breakdown

Model MS-IT-0300-V 13647


Guide



Parts Breakdown

Model MS-IT-0300-V 13647


Blade Assembly



Parts Breakdown

Model MS-IT-0300-V 13647


Meat Tray Assembly



Parts Breakdown

Model MS-IT-0300-V 13647


Blade Guard



Parts Breakdown

Model MS-IT-0300-V 13647


Electrical Components



Parts Breakdown

Model MS-IT-0300-V 13647


Sharpening Assembly



Parts Breakdown

Model MS-IT-0300-V 13647

Food Tray Assembly



Parts Breakdown

Model **MS-IT-0300-V** 13647

Stand

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
31881	Housing for 13647	1	31892	Cam Plate for 13647	13	31902	Set Screw - Capped for 13647	24
31882	Guide Plate for 13647	2	31893	Set Screw 8x10 TC for 13647	14	31903	Nut 8 for 13647	25
31883	Guide Plate Support for 13647	3	31894	Bolt 5x20 for 13647	15	31904	Set Screw 6x8 TP for 13647	26
31884	Guide Plate Shaft for 13647	4	31895	Nut 5 for 13647	16	31905	Washer 5 for 13647	27
31885	Bracket for 13647	5	31896	Screw TPSV 5x10 for 13647	17	31906	Screw TE 6x12 for 13647	28
17865	Index Knob for 13647	6 - 8, 21	31897	Screw TC 5x10 for 13647	18	31907	Washer 6 for 13647	29
31887	Index Knob Bushing for 13647	9	31898	Screw TE 6x12 for 13647	19	31908	Screw TE 8x40 for 13647	30
31888	Wavy Washer for 13647	10	31899	Tapping Screw 2.9x12 for 13647	20	31891	Cam Assembly for 13647	
17851	Cam for 13647	11	31900	Washer 8 for 13647	22			
31890	Cam Guide for 13647	12	31901	Copper Rivet for 13647	23			

Guide

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
31909	Carriage Slide Bar for 13647	1	31925	Slide Bar Spring for 13647	17	31941	Set Screw 5x8 TC for 13647	33
31910	Slide Bar Cover for 13647	2	31926	Nut 6 for 13647	18	31942	Set Screw PVC for 13647	34
31911	Bottom Plate for 13647	3	31927	Washer 6 for 13647	19	31943	Rubber Washer 15 for 13647	35
31912	Top Plate for 13647	4	31928	Set Screw 6x30 for 13647	20	31944	Carriage Plate Spring for 13647	36
17863	Carriage Handle for 13647	5	31929	Screw TE 8x40 for 13647	21	31945	Washer 5 for 13647	37
31914	Flat Bar for 13647	6	31930	Washer 8 for 13647	22	31946	Acorn Cap for 13647	38
31915	Bearing Support Bar for 13647	7	31931	Nut 8 for 13647	23	31947	Set Screw 5x20 TP for 13647	39
31916	Carriage Support for 13647	8	31932	Washer 8 for 13647	24	31948	Set Screw PVC for 13647	40
31917	Carriage Rail for 13647	9	31933	Bushing for 13647	25	31949	Screw TE 8x20 for 13647	41
31918	Bracket for 13647	10	31934	Set Screw 6x12 for 13647	26	31950	Screw TPSV 4x10 for 13647	42
31919	Plate Bracket for 13647	11	31935	Bearing 626 for 13647	27	31951	Flat Latch for 13647	43
31920	Carriage Plate Rod for 13647	12	31936	Bearing 608 for 13647	28	31952	Threaded Stud 8 for 13647	44
31921	Slide Bar Cap for 13647	13	31937	Bearing Pin 8 for 13647	29	31953	Nut 6 for 13647	45
31922	Rail Support for 13647	14	31938	Screw TPSV 5x10 for 13647	30	31954	Screw TC 4x5 for 13647	46
31923	Slide Bar Support for 13647	15	31939	Screw TE 8x20 for 13647	31			
31924	Spacer Plate for 13647	16	31940	Screw TE 8x25 for 13647	32			

Parts Breakdown

Model MS-IT-0300-V 13647

Blade Assembly

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
15182	Blade Shield for 13647	1	31964	Pulley for 13647	10	31973	Tie Rod Spacer for 13647	20
31956	Blade for 13647	2	31965	Bearing Spacer for 13647	11	31974	Thumb Screw for 13647	21
31957	Aluminum Plate for 13647	3	31966	Bearing 6004 2RS for 13647	12	31975	Washer for 13647	22
31958	Bottom Cover for 13647	4	31967	Clip for 13647	14	31976	Plate Stop for 13647	23
31959	Foot for 13647	5	31968	Clip for 13647	15	31977	Support Rail for 13647	24
31960	Blade Shield Knob Screw for 13647	6	31969	Set Screw for 13647	16	31978	Washer 8 for 13647	25
31961	Washer 4 for 13647	7	31970	Set Screw 6x8 TC for 13647	17	31979	Screw TE 8x20 for 13647	26
31962	Set Screw 5x8 TP for 13647	8	31971	Set Screw PVC for 13647	18	31980	Tapping Screw for 13647	27
31963	Bearing and Shaft for 13647	9	31972	Tie Rod for 13647	19			

Meat Tray Assembly

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
31981	Support for Pusher Arm for 13647	1	31993	Spring 9x15 for 13647	13	32005	Washer 4x25 for 13647	25
31982	Washer 8 for 13647	2	31994	Stud Brake for 13647	14	32006	Bearing 608 ZZ for 13647	26
31983	Screw TE 8x20 for 13647	3	31995	Presser Brake for 13647	15	32007	Bearing Spindle for 13647	27
31984	Set Screw 5x20 for 13647	4	31996	Hand Grip Safety Guard for 13647	16	32008	Pusher Arm for 13647	28
31985	Set Screw 5x16 for 13647	5	17862	Meat Grip Handle for 13647	17	32009	PVC Washer 15x25 for 13647	29
31986	Set Screw 6x8 TC for 13647	6	31998	Screw TPSV 4x10 for 13647	18	32010	Presser Spacer for 13647	30
31987	Rod Brake for 13647	7	31999	Screw TPSV 45x12 for 13647	19	32011	Presser Plate for 13647	31
31988	Set Screw 6x19 for 13647	8	32000	Presser Handle Bracket for 13647	20	32012	Set Screw 6x6 TC for 13647	32
31989	Spring 3.5x19 for 13647	9	32001	Rod and Spring for 13647	21	32013	Presser Shaft for 13647	33
31990	Spring 13.5x10 for 13647	10	32002	Screw Chrome for 13647	22	32014	Hex Pin 8x31 for 13647	34
31991	Iron Plate for 13647	11	32003	Washer 8 for 13647	23	32015	Locking Nut for 13647	35
31992	Brake Stud for 13647	12	32004	Screw TPSV 4x10 for 13647	24	32016	Complete Arm Assembly for 13647	

Blade Guard

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
32017	Nut 5 for 13647	1	32021	Safety Ring Extension for 13647	5	32025	Meat Deflector for 13647	9
32018	Washer 5 for 13647	2	32022	Support Ring for 13647	6	32026	Thumb Screw 5 MA for 13647	10
32019	Set Screw 54x30 / 5x25 for 13647	3	32023	Support Ring for 13647	7	32027	Acorn Cap for 13647	11
32020	Ring for 13647	4	32024	Set Screw 6x12 for 13647	8			

Parts Breakdown

Model MS-IT-0300-V 13647

Electrical Components

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
17861	Capacitor for 13647	1	14859	Power Cord for 13647	11	32040	Motor Hinge for 13647	18
32029	Capacitor Bracket for 13647	2	32035	Wing Nut for 13647	12	32041	Set Screw 5x8 TC for 13647	19
32030	Washer 5 for 13647	3	32036	Washer 6A Wide for 13647	13	32042	Screw TC 4x10 for 13647	20
32031	Screw 5x10 TC for 13647	4	32037	Motor Bracket for 13647	14	32043	Terminal Block for 13647	21
32032	Switch - On / Off for 13647	5 - 7	32038	Adjustment Rod for 13647	15	32044	Tapping Screw for 13647	22
17866	Motor for 13647	9 - 11, 16	32039	Motor Support Shaft for 13647	17	32045	Stop Plate for 13647	23

Sharpening Assembly

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
32046	Sharpener Support Bracket for 13647	1	32056	Sharpener Push Button for 13647	11	32066	Screw TE 8x20 for 13647	21
32047	Screw TPSV 6x12 for 13647	2	32057	Spring for 13647	12	32067	Washer 8 for 13647	22
32048	Shaft for Sharpener for 13647	3	32058	Screw TC for 13647	13	32068	Sharpener Cover for 13647	23
32049	Set Screw 5x40 for 13647	4	32059	Washer 3 for 13647	14	32069	Sharpener Cover Knob for 13647	24
32050	Set Screw 5x30 for 13647	5	32060	Sharpener Pin for 13647	15	32070	Screw TC 6x12 for 13647	25
32051	Nut 6 for 13647	6	32061	Sharpener Pin for 13647	16	32071	Set Screw 6x8 TC for 13647	26
32052	Sharpener Screw for 13647	7	32062	Sharpener Body for 13647	17	33032	Finishing Stone for 13647	27
32053	Ball Bearing for 13647	8	32063	Screw TC 4x20 for 13647	18	18016	Grinding Stone for 13647	28
32054	Washer 6 for 13647	9	32064	Washer 4 for 13647	19	15156	Complete Sharpening Assy for 13647	
32055	Nut 6 for 13647	10	32065	Sharpener Tie Rod for 13647	20			

Food Tray Assembly

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
32073	Screw TE 8x35 for 13647	1	32083	Screw TE 8x20 for 13647	11	32093	Presser Plate for 13647	21
32074	Washer 8 for 13647	2	32084	Washer 8 for 13647	12	32094	Set Screw 6x8 TC for 13647	22
32075	Carriage Plate Support V for 13647	3	32085	Stud 5 MA for 13647	13	32095	End Block for 13647	23
32076	Carriage Plate Support H for 13647	4	32086	Carriage Plate - Small for 13647	14	32096	Inside Block for 13647	24
32077	Nut for 13647	5	32087	Washer 6x18 for 13647	15	32097	Set Screw 6x8 TC for 13647	25
32078	Washer 6x18 for 13647	6	32088	Nut 6 for 13647	16	32098	Rubber Washer for 13647	26
17860	Carriage Safety Guard for 13647	7	32089	Meat Grip Handle for 13647	17	32099	Spacer for 13647	27
32080	Stud 6x50 for 13647	8	32090	Aluminum Spacer for 13647	18	32100	Bracket for 13647	28
32081	Spacer for 13647	9	32091	Wavy Washer for 13647	19	32101	Stud PVC for 13647	29
32082	Carriage Plate - Large for 13647	10	32092	Stud 12 MA for 13647	20	32102	Presser Rod for 13647	30