


# Parts Breakdown

Model MS-IT-0350-L 13637

Sold Complete



# Parts Breakdown

## Model MS-IT-0350-L 13637

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
15204	Housing for 13637	A1	34771	Clip for 13637	A39	34805	Set Screw for 13637	A76
34736	Screw for 13637	A2	34772	Bearing for 13637	A40	34806	Cam Plate for 13637	A77
34737	Stop Plate for 13637	A3	15206	Bearing Spacer for 13637	A41	34807	Screw for 13637	A78
34738	Strain Relief for 13637	A4	34773	Bearing and Shaft for 13637	A42	34808	Screw TC for 13637	A79
34739	Set Screw for 13637	A5	34774	Belt for 13637	A43	34809	Index Knob for 13637	A80
34740	Bushing for 13637	A6	34775	Spindle Pulley for 13637	A44	34810	White Bushing for 13637	A81
34741	Set Screw for 13637	A7	34776	Set Screw for 13637	A45	34811	Copper Rivet for 13637	A82
15205	Tie Rod for 13637	A8	13599	Blade 350x57x4x280 for 13637	A46	34812	Meat Deflector for 13637	A83
34742	Nut for 13637	A9	34778	Screw for 13637	A47	34813	Deflector Screw for 13637	A84
34743	Tie Rod Knob for 13637	A10	34779	Blade Shield for 13637	A48	34814	Screw Chrome for 13637	A85
34744	Foot for 13637	A11	34780	Thumb Screw for 13637	A49	21657	Carriage Rail for 13637	A86
34745	Sharpener Support Bracket for 13637	A12	34781	Meat Grip for 13637	A50	34815	Screw TC for 13637	A87
34746	Sharpener Tie Rod for 13637	A13	34782	Set Screw for 13637	A51	34816	Pin for 13637	A88
34747	Washer for 13637	A14	34783	Washer PVC for 13637	A52	21658	Bearing for 13637	A89
34748	Screw TE for 13637	A15	34784	Rubber Washer for 13637	A53	34817	Set Screw for 13637	A90
34749	Screw TC for 13637	A16	34785	Meat Grip Spring for 13637	A54	15209	Carriage Support for 13637	A91
34750	Washer for 13637	A17	34786	Meat Grip Handle Screw for 13637	A55	34818	Set Screw PVC for 13637	A92
34751	Sharpener Support Pin for 13637	A18	34787	Meat Grip Handle for 13637	A56	34819	Slide Bar Spring for 13637	A93
34752	Sharpener Screw for 13637	A19	34788	Meat Grip Support Shaft for 13637	A57	34820	Carriage Slide Bar for 13637	A94
34753	Screw TC for 13637	A20	34789	Meat Tray Adjustment Plate for 13637	A58	34821	Indicator Light for 13637	A95
34754	Washer for 13637	A21	34790	Set Screw for 13637	A59	34822	Switch - On / Off for 13637	A96
34755	Sharpener Pin for 13637	A22	34791	Set Screw for 13637	A60	34823	Screw TC for 13637	A97
18016	Omcan G Stone 50x08x06 for 13637	A23	37448	Meat Tray for 13637	A61	34824	Capacitor Bracket for 13637	A98
34757	Nut for 13637	A24	34792	Sharpener Tie Rod for 13637	A62	15210	Capacitor for 13637	A99
34758	Set Screw for 13637	A25	34793	Pin for 13637	A63	34825	Wing Nut for 13637	A100
34759	Sharpener Spring for 13637	A26	34794	Meat Tray Support Arm for 13637	A64	34826	Motor Bracket for 13637	A101
34760	Ball Bearing for 13637	A27	34795	Carriage Knob for 13637	A65	34827	Screw for 13637	A102
34761	Screw for 13637	A28	15207	Carriage Handle for 13637	A66	34828	Motor for 13637	A103
34762	Sharpener Push Button for 13637	A29	34796	Nut for 13637	A67	31235	Adjustment Rod for 13637	A104
34763	Washer for 13637	A30	34797	Guide Plate for 13637	A68	34829	Washer for 13637	A105
34764	Screw TC for 13637	A31	34798	Guide Plate Support for 13637	A69	34830	Hinge for 13637	A106
34765	Sharpener Body for 13637	A32	34799	Screw TE for 13637	A70	34831	Motor Support Shaft for 13637	A107
34766	Sharpener Pin for 13637	A33	34800	Wavy Washer for 13637	A71	14859	Power Cord for 13637	A109
33032	45x9x6 Sharpening Stone for 13637	A34	34801	Cam for 13637	A72	37449	Bottom Cover for 13637	C4
34768	Sharpener Cover for 13637	A35	34802	Set Screw - Capped for 13637	A73	15211	Complete Pulley Assy. for 13637	
34769	Small Bushing for 13637	A37	15208	Guide Plate Pin for 13637	A74	34804	Complete Cam Assy. for 13637	
34770	Clip for 13637	A38	34803	Cam Guide for 13637	A75	15212	Complete Sharpening Assy. for 13637	