

PS12		
SUPP	ACCPAC	DESCR
M101	11-P101	#M101 MAIN HOUSING
M102	11-P102	#M102 GAUGE PLATE
M103	11-P103	#M103 MEAT HOLDER
M104	11-P104	#M104 GUARDING BLADE DISC
M105	11-P105	#M105 BLADE
M106	11-P106	#M106 BLADE GUARDING RING
M107	11-P107	#M107 SLIDING SUPPORT COVER
M108	11-P108	#M108 END WEIGHT
M109	11-P109	#M109 END WEIGHT BUSHING
M110	11-P110	#M110 HANDLE
M111	11-P111	#M111 PLASTIC BUMPER
M112	11-P112	#M112 MOTOR
M113	11-P113	#M113 MOTOR BRACKET
M114	11-P114	#M114 POWER CORD
M115	11-P115	#115 OLD BLADE GUARD BOLTS **DO NOT USE**USE 11-P15B**
	11-P15B	#M115 NEW BLADE GUARD BOLTS REPLACES 11-P115
M116	11-P116	#M116 BALL BEARING 6204
M117	11-P117	#M117 BELT WHEEL
M118	11-P118	#M118 PIN OF BELT WHEEL
M119	11-P119	#M119 DRIVE BELT SV. 400
M120	11-P120	#M120 SUPPORTING BASE
M121	11-P121	#M121 CABLE JACKET
M122	11-P122	#M122 MEAT DEFLECTOR
M123	11-P123	#M123 BUTTON COVER
M124	11-P124	#M124 ON/OFF SWITCH
M125	11-P125	#M125 CAPACITOR 20 uF PS12/PS12D
M126	11-P126	#M126 CAPACITOR HOLDER
M127	11-P127	#M127 SCREW OF ORIENTED STAFF
M128	11-P128	#M128 THICKNESS ADJUSTING KNOB
M129	11-P129	#M129 SPRING GASKET
M130	11-P130	#M130 CAM 300
M131	11-P131	#M131 BASE COVER FOR P-12
M132	11-P132	#M132 CAM PIN
M133	11-P133	#M133 SLIDING AXLE
M134	11-P134	#M134 SLIDER
M135	11-P135	#M135 RUBBER FOOT
M136	11-P136	#M136 SLIDING AXLE BRACKET
M137	11-P137	#M137 RELAY 110V
M138	11-P138	#M138 SPRING OF SLIDING AXLE
M139	11-P139	#M139 TOWING BRACKET SLIDING AXLE

M140	11-P140	#M140 SLIDE GUIDE
M141	11-P141	#M141 SLIDE SUPPORT
M142	11-P142	#M142 SLIDE SUPPORT ADJUSTING KNOB
M143	11-P143	#M143 SHARPENER COVER
M144	11-P144	#M144 BUTTON
M145	11-P145	#M145 FINE GRINDING WHEEL
M146	11-P146	#M146 PIN
M147	11-P147	#M147 SPRING CLEANING WHEEL
M148	11-P148	#M148 COARSE GRINDING WHEEL
M149	11-P149	#M149 SHARPENER TIGHTEN KNOB
M150	11-P150	#M150 SUPPORTING BASE OF OUTER RING
M151	11-P151	#M151 4.751 WHEEL
M152	11-P152	#M152 PIN OF RUBBING STONE
M153	11-P153	#M153 SHARPENER BASE OF SUBASSEMBLY
M154	11-P154	#M154 PIN OF BLADE GUARDING RING
M155	11-P155	#M155 PIN OF FOOD TRAY
M156	11-P156	#M156 MEAT BLOCKING BOARD
M157	11-P157	#M157 BRACKET OF SLIDING AXLE
M158	11-P158	#M158 SMALL BELT WHEEL OF MOTOR
M159	11-P159	#M159 SLIDE TRANSMITTING WHEEL
M160	11-P160	#M160 SLIDING SUPPORT HANDLE
M161	11-P161	#M161 BEARING FOR AXLE 608RZ
M162	11-P162	#M162 BELT WHEEL ASSEMBLY
M163	11-P163	#M163 SHARPENER ASSEMBLY
M164	11-P164	#M164 20 SPRING GASKET FOR BEARING
M165	11-P165	#M165 47 SPRING GASKET FOR HOLE
M166	11-P166	#M166 BLADE GUARD NUT
M167	11-P167	#M167 FIXED-ARM HANDLE BOLT
M168	11-P168	#M168 PLATE GUARD BOLT
M169	11-P169	#M169 PLATE GUARD NUT
M170	11-P170	#M170 BRACKET KNOB BOLT
M171	11-P171	#M171 BRACKET KNOB NUT
M172	11-P172	#M172 BRACKET BUTTON BOLT
M173	11-P173	#M173 LOCKING SCREW
M174	11-P174	#M174 SLIDE AXLE BRACKET BOLT
M175	11-P175	#M175 SLIDE AXLE BOLT
M176	11-P176	#M176 SPRING GASKET
M177	11-P177	#M177 WASHER
M178	11-P178	#M178 BOLT
M179	11-P179	#M179 FULCRUM BEARING SHIM
M180	11-P180	#M180 FULCRUM BEARING BOLT
M181	11-P181	#M181 BLADE GUARD RING SUPPORT
M182	11-P182	#M182 TRAY BEARING COVER A

M183	11-P183	#M183 TRAY BEARING COVER B
M184	11-P184	#M184 OIL SEALFOR BELT WHEEL
M185	11-P185	#M185 HANDLE FOR CARRIAGE PS-12 AND FOR PS-12D
M186	11-P186	#M186 MICROSWITCH
M187	11-P189	#M187 MICRO SWITCH FIXED BLOCK
M188	11-P188	#M188 BLADE SCREW

# Mod.PS-12

