


## Exploded View : CD12-HC



NOTE: FOR LEFT HAND HINGE DETAILS, SEE PARTS LISTING.

# CD12-HC Cooler

(84-7012-XXX) 120V, 60 Hz.

Item No.	Part No.	Pepsi Part No.	Description	Item No.	Part No.	Pepsi Part No.	Description
1	47-0530-089	510204	Level Leg ½ x 3 x 1 ¾ AF	18	<a href="#">47-0080-011</a>	1005559	Insert Bronze ⅝ OD x ¼"
2	47-0035-106	1024441	Duct, CD Small Air	19	<a href="#">47-0090-012</a>	81559	Hinge, DC/CD RH Top Door
3	47-0034-438		Panel CD12 Back Discharge	20	47-7641-739	1004006	Door Assy CD12
4	<a href="#">53-0377-032</a>	510362	Bracket (Clip) Shelf Support	21	<a href="#">47-0140-017</a>	60136	Gasket, CD12 Door Mag. M-218
5	47-0034-085		Pilaster Strip, 40%"	22	<a href="#">47-0200-176</a>	1002187	Shelf, CD10/12 Flat
6a	80-0011-227F1	1027020	Ref. Chassis ¼ HP CD <b>HC R290</b>	23	<a href="#">47-0034-003</a>		Clip, CD14HB Shelf Stopper
6b	80-0011-227E1		Ref. Chassis ¼ HP CD <b>HC R290</b>	24a	47-0130-250	1000819	Price Holder 18¾" Black
7	47-0033-411	1020397	Bracket, CD ¼ HP Lift Rod Lock	24b	47-0130-130		Price Holder 18¾" Blue
8	47-0120-183	1008303	Grill, CD10/12 Plastic Front	25	47-0530-669	1027015	LED, 11.5" L11 - 11.5 Series
9	<a href="#">47-0400-038</a>		SCW ST 8-32 X ¾ PH FT HD BLK	26	47-0450-288		Connector, 12" Butt
10	<a href="#">47-0120-166</a>	1002413	Handle, Recess Dr Charcoal Gray	27	47-0130-738		Cap, CD12-HC Top LED
11	47-0090-072		Insert, Door Handle	28	47-0530-671	1027017	LED, 35.5" L11 - 35.5 Series
12	<a href="#">47-0090-082</a>	1009577	Pin, Pivot Bottom	29	47-0450-283		Connector, 12" Wire Lead
13	<a href="#">53-0149-069</a>	510108	Spring Door	30	47-0130-739		Cap, CD12-HC Bottom Side LED
14	<a href="#">47-0090-013</a>	80977	Hinge, DC/CD RH Bottom Door	31	47-0130-740		Cap, CD10/12-HC Top LED
15	<a href="#">47-0264-308</a>	83973	SCW MA ¼ - 20 X ¾ PAN HD QUAD	32	<a href="#">47-0440-087</a>		Driver, LED 20W
16	<a href="#">53-0267-006</a>	83974	Washer ¼ Split Lock Zinc	33	<a href="#">47-0440-007</a>	1003097	Outlet, 3 Wire
17	<a href="#">47-0090-081</a>	1009576	Pin, Pivot Top	34	<a href="#">18-7218-001</a>	1007217	Cord, Power 14/3 SJTW-A 12'

**Left Hand Hinge Parts:**

47-0090-015	1001724	Hinge, LH Bottom Door
<a href="#">47-0090-014</a>	1001725	Hinge, LH Top Door

**Accessories:**

47-0011-091	1004688	Shelf, 600ml Gravity
<a href="#">47-0034-128</a>	61726	Key, Door T-Handle
47-0060-177		Gasket Seal UL Ref CD ¼ HP
47-0130-506	1005148	Shelf Glide CD10/12, CD4148 Blue
47-0130-586		Shelf Glide CD10/12, CD4148 White
47-0520-214	57175	Caster Kit – Uni-Directional
<a href="#">47-0520-216</a>	1001844	Caster Kit – Swivel Type
47-0520-223	43455	Kit, CD10/12 Door Lock
47-0520-245	1001883	Kit, Casters Transfer - No Wheels
47-0520-279		Kit, Electrics for EM2X3121U
47-8811-932		Decal, Door Pepsi CD10/12
47-8812-932		Decal, Side Pepsi CD12