

PARTS LIST

Note: The parts marked "Δ" may cause undue microwave exposure.
The parts marked "*" are used in voltage more than 250V.

REF. NO.	PART NO.	DESCRIPTION	Q'TY	CODE
ELECTRIC PARTS				
1- 1	FPWBFA383WRKZ	Noise filter	1	AN
1- 2	QSOCLA026WRZZ	Oven lamp socket	1	AF
1- 3	RV-MZA335WRZZ	Magnetron	2	BA
Δ 1- 4	FMOTEA495WRKZ	Blower motor	1	BF
1- 5	RTRN-A724WRZZ	Power transformer	2	BF
* 1- 6	FACCDAL12WRKZ	Power supply cord	1	BB
1- 7	FH-HZA070WRE0	Oven thermistor (1) & Magnetron thermistor	2	AM
* 1- 8	FW-QZA117WRK0	High voltage rectifier assembly	1	AU
1- 9	FFS-BA033WRKZ	Monitor switch (V-5220Q) and fuse 20A assembly	2	**
1-10	QFS-TA015WRE0	Temperature fuse 120C (OVEN)	1	AG
1-11	QSW-MA085WRE0	Secondary interlock switch and Door sensing switch	3	AF
* 1-12	RC-QZA325WRZZ	High voltage capacitor	2	AP
1-13	RLMPTA081WRZZ	Oven lamp	1	AK
1-14	RMOTDA209WRE0	Stirrer motor	2	AR
1-15	QFS-TA014WRE0	Temperature fuse 150C (MG.)	2	AG

CABINET PARTS

2- 1	FDAI-A275WRTZ	Base plate assembly	1	BC
2- 2	PSHEGA009WREZ	Rubber sheet D	2	AF
2- 3	PSHEGA010WREZ	Rubber sheet E	2	AE
2- 4	GCOVAA283WRW0	Rear cabinet	1	AX
2- 5	FFTASA072WRY0	Oven lamp access cover assembly [R-22GV-F]	1	AM
2- 5	FFTASA064WRY0	Oven lamp access cover assembly [R-22GT-F]	1	AN
2- 5-1	PCUSU0407WRP0	Cushion [R-22GV-F]	1	AA
2- 5-1	PCUSUA585WRPZ	Cushion [R-22GT-F]	1	AF
2- 5-2	PREFHA059WRP0	Reflector [R-22GT-F only]	1	AF
2- 6	GCABUA531WRP0	Outer case cabinet [R-22GV-F]	1	AY
2- 6	GCABUA860WRPZ	Outer case cabinet [R-22GT-F]	1	BD
2- 7	FFPF-A016WRK0	Vibration-proof sheet	1	AU
2- 8	TMAPCA772WRRZ	Schematic diagram	1	AE

CONTROL PANEL PARTS

3- 1	DPWBFC507WRUZ	Control unit [R-22GV-F]	1	BN
3- 1	DPWBFC452WRKZ	Control unit [R-22GT-F]	1	BN
3- 1A	QCNCMA308DRE0	4-pin connector (CN-A)	1	AC
3- 1B	QCNCMA312DRE0	3-pin connector (CN-B)	1	AB
3- 1C	QCNCMA039DRE0	3-pin connector (CN-H)	1	AB
3- 1D	QCNCWA030DRE0	12-pin connector (CN-G)	1	AE
3- 1E	QLUGPA012DRE0	Tab terminal (TB1, TB2)	2	AB
C1	VCEAB51EW228M	Capacitor 2200 uF 25V	1	AE
C2	VCKYD11HF104Z	Capacitor 0.1 uF 50V	1	AB
C3	VCEAB31AW476M	Capacitor 47 uF 10V	1	AA
C4	VCKYD11HF104Z	Capacitor 0.1 uF 50V	1	AB
C5	VCEAB31AW476M	Capacitor 47 uF 10V	1	AA
C6	VCKYD11HF104Z	Capacitor 0.1 uF 50V	1	AB
C7	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
C8-9	VCKYD11HF104Z	Capacitor 0.1 uF 50V	2	AB
C20	VCEAB31HW104M	Capacitor 0.1 uF 50V	1	AM
C21	VCEAB31EW106M	Capacitor 10 uF 25V	1	AA
C30	VCEAB31AW476M	Capacitor 47 uF 10V	1	AA
C31	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
C60	VCKYD11HF104Z	Capacitor 0.1 uF 50V	1	AB
C61	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
C62	VRD-Q12EP104J	Resistor 100k ohm 1/4W	1	AA
C63	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
C64	VRD-Q12EP562J	Resistor 5.6k ohm 1/4W	1	AA
C70	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
C100	VCEAB31AW476M	Capacitor 47 uF 10V	1	AA
C101	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
CF1	RCRS-A010DRE0	Ceramic resonator CST4.00MGW	1	AD
D1-4	VHD10EDB10+-1T	Diode (10EDB10)	4	AB
D20-22	VHD1SS270A/-1	Diode (1SS270A)	3	AA
D23	VHD10EDB10+-1T	Diode (10EDB10)	1	AB
D70	VHD1SS270A/-1	Diode (1SS270A)	1	AA
D100-101	VHD1SS270A7-1	Diode (1SS270A)	2	AA
IC1	RH-IZA633DRE0	LSI	1	AW
IC2	RH-IZA980DRE0	IC (AT24C02-10PC2.5)	1	AN

REF. NO.	PART NO.	DESCRIPTION	QTY	CODE
IC3	RIC--A025BDE0	IC (KID65004AP)	1	AE
LED1	VHPSL3966T/1B	Light emitting diode	1	AS
Q1	RIC--A022BDE0	IC (KI2A7805PI)	1	AE
Q2	VSDTA123ES/-3	Transistor (DTA123ES)	1	AA
Q3	RH-TZA036CBE0	Transistor (KRC101M)	1	AA
Q20	VSDTB143ES/-3	Transistor (DTB143ES)	1	AC
Q21	RH-TZA036CBE0	Transistor (KRC101M)	1	AA
Q22-23	VSDTB143ES/-3	Transistor (DTD143ES)	2	AC
Q60	RH-TZA037CBE0	Transistor (KRA101M)	1	AA
R3-5	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	3	AA
R30	VRD-Q12EF101J	Resistor 100 ohm 1/4W	1	AA
R31	VRD-Q12EF153J	Resistor 15k ohm 1/4W	1	AA
R32	VRD-Q12EF272J	Resistor 2.7k ohm 1/4W	1	AA
R33	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	1	AA
R40	VRD-Q12EF272J	Resistor 2.7k ohm 1/4W	1	AA
R50-58	VRD-Q12EF101J	Resistor 100 ohm 1/4W	9	AA
R60	VRD-Q12EF112J	Resistor 1.1k ohm 1/4W	1	AA
R61	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	1	AA
R62	VRD-Q12EF333J	Resistor 33k ohm 1/4W	1	AG
R63	VRD-Q12EF272J	Resistor 2.7k ohm 1/4W	1	AA
R64	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	1	AA
R65	VRD-Q12EF682J	Resistor 6.8k ohm 1/4W	1	AA
R66	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	1	AA
R70-71	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	2	AA
R80-88	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	9	AA
R100	VRN-R12EK821F	Resistor 820 ohm (F) 1/4W	1	AA
R101	VRD-Q12EF333J	Resistor 33k ohm 1/4W	1	AG
R102	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	1	AA
RY1	RRLY-A071DRE0	Relay (OJE-SS-112LM)	1	AG
RY2-3	RRLY-A094DRE0	Relay (OMIF-S-112LM)	2	AN
SP1	RALM-A014DRE0	Buzzer (PKM22EPT)	1	AG
T1	RTRNPA094DRE0	Touch control transformer	1	AQ
CT1	RTRN-026CHRE0	Current transformer	1	AH
VRS1	RH-VZA034DRE0	Varistor (10G471K)	1	AD
ZD2	VHEHZ4A2///-1	Zener diode (HZ4A2)	1	AA
3- 2	FPNLCB148WRK0	Control panel frame with key unit [R-22GV-F]	1	AZ
3- 2	FPNLCB468WRK0	Control panel frame with key unit [R-22GT-F]	1	AZ
3- 2-1	FUNTKA774WRE0	Key unit [R-22GV-F]	1	AT
3- 2-1	FUNTKA773WRE0	Key unit [R-22GT-F]	1	AT
3- 2-2	HDECAA195WRP0	Decoration metal fittings	1	AP
3- 2-3	PCUSUA417WRP0	Cushion	1	AB
3- 3	LANGTA243WRW0	Control panel mounting angle	1	AF
3- 4	XEPS730P10XS0	Screw; control unit mounting	5	AA
3- 5	XEPS740P12000	Screw; control panel mounting angle mounting	2	AA
3- 6	LX-BZA138WREZ	Screw; decoration panel mounting for earth	1	AB

OVEN PARTS

4- 1	PGLSPA632WREZ	Lamp glass	1	AG
4- 2	PDUC-A345WRY0	Exhaust duct assembly	1	AP
4- 3	*****	Oven cavity (Not a replaceable part)	1	--
4- 4	PFILWA063WRPZ	Oven light screen (Inside)	1	AD
4- 5	MLEVPA153WRP0	Switch lever A	1	AC
4- 6	MLEVPA154WRP0	Switch lever B	1	AC
4- 7	MLEVPA155WRP0	Switch lever C	1	AC
4- 8	MSPRCA075WRE0	Switch spring A	1	AB
4- 9	MSPRCA076WRE0	Switch spring B	2	AB
4-10	PHOK-A081WRP0	Latch hook	1	AP
4-11	MHNG-A216WRM0	Lower oven hinge	1	AG
4-12	MSPRCA101WRE0	Switch lever spring C	1	AC
4-13	PCUSU0407WRP0	Cushion	2	AA
4-14	PGLSPA067WRYZ	Ceramic shelf	1	BH
4-15	FPLT-A013WRYZ	Stirrer antenna upper assembly	1	AX
4-16	FPLT-A009WRY0	Stirrer antenna lower assembly	1	AV
4-17	LANGKA762WRP0	Partition angle R	1	AE
4-18	LANGQA228WRW0	Oven lamp mounting plate	1	AF
4-19	LBNDKA075WRP0	Capacitor holder	1	AD
4-20	PGIDHA054WRW0	Water-proof cover	1	AF
4-21	NSFTPA031WRP0	Antenna motor shaft	2	AH
4-22	LANGQA622WRPZ	Noise filter angle	1	AK
4-23	PCUSUA417WRP0	Cushion	1	AB
4-24	MHNG-A215WRM0	Upper oven hinge	1	AG
4-25	PCUSUA413WRP0	Cushion	1	AG
4-26	PCUSUA415WRP0	Cushion	1	AC
4-27	PDUC-A729WRP0	Air duct	1	AL

REF. NO.	PART NO.	DESCRIPTION	QTY	CODE
4-28	PDUC-A564WRW0	Mg exhaust duct	1	AP
4-29	PCUSUA414WRP0	Cushion	1	AD
4-30	LANGKA679WRPZ	Fixing angle S	1	AD
4-31	HDECQA147WRM0	Corner cap right	1	AE
4-32	LANGFA195WRW0	Chassis support	1	AH
4-33	LBSHC0006YBE0	Cord bushing	1	AD
4-34	LANGQA593WRPZ	Blower motor angle	1	AH
4-35	FFTL-A003WRK0	Air intake filter assembly	1	AV
4-36	HDECEA001WRP0	Decoration sash	1	AR
4-37	HDECQA146WRM0	Corner cap left	1	AE
4-38	PCUSGA409WRP0	Cushion	2	AE
4-39	PCOVPA422WRPZ	Splash cover	1	BK
4-40	LANGQA512WRP0	Thermistor angle	1	AE
4-41	LANGTA408WRWZ	Lamp glass mounting plate	1	AK
4-42	PCUSUA626WREZ	Cushion	1	AC
4-43	PCUSUA268WRP0	Cushion	1	AA
4-44	LSUB-A133WRPZ	Thermo contactor	1	AD

DOOR PARTS

5	CDORFB029WRKZ	Door assembly	1	BU
5- 1	DDORFB192WRKZ	Door panel assembly	1	
5- 2	GCOVAA242WRY0	Door case	1	BD
5- 3	FHNDMA011WRY0	Door lever assembly	1	AP
5- 4	GCOVHA350WRP0	Choke cover	1	AR
5- 5	JHNDMA039WRM0	Door handle	1	AX
5- 6	LANGKA766WRP0	Outside window fixing plate	2	AF
5- 7	PCUSGA430WRP0	Cushion	2	AM
5- 8	PGLSPA457WRE0	Door glass	1	AV
5- 9	PPACGA142WRP0	Door case packing	2	AF
5-10	PGID-0024WRP0	handle guide	4	AC
5-11	PGID-0025WRP0	Handle spacer	1	AC
5-12	PSPA-A102WRE0	Door case spacer	2	AE
5-13	XHTS740P08RV0	Screw : 4mm x 8mm	9	AG
5-14	FANGKA200WRY0	Latch fixing angle	1	AQ
5-15	FLEVFA019WRY0	Joint lever	1	AP
5-16	LSTPCA002WRM0	Latch head	2	AM
5-17	MLEVPA220WRP0	Head lever	1	AM
5-18	MSPRCA097WRE0	Latch spring	1	AG
5-19	HBDGCA068WRE0	Door badge [R-22GV-F]	1	AF
5-19	HBDGCA065WRE0	Door badge [R-22GT-F]	1	AF
5-20	PCUSGA486WRP0	Handle cushion	1	AM

MISCELLANEOUS

6- 1	TINSEB105WRRZ	Instruction manual	1	AG
6- 2	TLABHA024WRR0	Menu sticker	1	AH
6- 3	FW-VZC037WREZ	Switch harness	1	AS
6- 4	FW-VZC036WREZ	Main wire harness	1	BG
6- 5	LHLDWQ005YBE0	Purse lock LL	1	AA
6- 6	LBNDKA079WRE0	Wire holder	2	AB
6- 7	LHLDWQ004YBE0	Purse lock L	1	AA
6- 8	TCAUAA130WRR0	Lamp caution	1	AC
6- 9	QW-QZA238WRE0	High voltage wire	2	AF
6-10	TCAUAA288WRRZ	Monitor caution label	1	AD
6-11	TCAUAA165WRR0	DHHS caution label	1	AB
6-12	FW-VZC039WREZ	Supply harness	1	AL
6-13	LHOLDA004WRE0	Cord holder	1	AA
6-14	TCAUAA181WRR0	Filter caution label	1	AC
6-15	TCAUAA165WRR0	User caution	1	AC

SCRE,NUTS AND WASHERS

7- 1	XCEWW30P08000	Screw : 3mm x 8mm	6	AB
7- 2	XBPS730P28KSO	Screw : 3mm x 28mm	2	AB
7- 3	XNES730-24000	Nut : 3mm x 2.4mm	2	AE
7- 4	LX-BZA164WREZ	Special screw	16	AC
7- 5	LX-BZA116WRE0	Special screw	2	AD
7- 6	XOTS740P10RV0	Screw : 4mm x 10mm	3	AB
7- 7	LX-BZA139WREZ	Special screw1	1	AA
7- 8	XOTS740P08000	Screw : 4mm x 8mm	6	AA
7- 9	XCHWW40P08000	Screw : 4mm x 8mm	2	AB
7-10	LX-EZA004WRE0	Special screw	2	AA
7-11	LX-BZA152WREZ	Special screw	1	AB
7-12	LX-BZA138WREZ	Special screw	11	AB
7-13	LX-BZA132WREZ	Special screw	4	AB

REF. NO.	PART NO.	DESCRIPTION	Q'TY	CODE
7-14	LX-BZA041WRE0	Specail screw	2	AA
7-15	XJPS740P10000	Screw : 4mm x 10mm	2	AA
7-16	XOTWW40P08000	Screw : 4mm x 8mm	29	AB
7-17	LX-CZA095WREZ	Special screw	3	AB
7-18	XOTS740P06000	Screw : 4mm x 6mm	1	AA

HOW TO ORDER REPLACEMENT PARTS

To have your order filled promptly and correctly, please furnish the following information.

1. MODEL NUMBER 2. REF. NO. 3. PART NO. 4. DESCRIPTION

Order Parts from the authorized SHARP parts Distributor for your area.

Defective parts requiring return should be returned as indicated in the Service Policy.

PACKING AND ACCESSORIES





